

Wireless Charger C3C Instruction

Product Features & Specifications

1. Combination of ABS and fire-proof PC.
2. Intelligent identification of bright light design, automatic identification of charging equipment.
3. In normal temperature and not turn hot when charging.

Material: ABS and fire-proof PC	Input Voltage/Current: 5V/2A 9V/1.7A Output Voltage/Current: 5V/1A 9V/1.1A
Input interface: Micro	
Transmission distance: ≤8MM	Charging efficiency: ≥73%
Dimension: Φ100*13mm	Weight: 85g

Using Guide

The product includes wireless charger. When using this product, please connect the USB cable directly to the wireless charger USB port.

Connect the adapter to charge

1. Connect the wireless charger to the adapter with USB cable.
2. When Power on, the indicator of wireless charger will shortly flashing and off, the product is under standby mode.
3. Put the mobile phone with wireless charging function on the wireless charger, when mobile phone is under charging, then indicator will keep shining as white .

After the mobile phone full charging, the indicator of the wireless charger will off automatically.

5. If the indicator of the wireless charger is under quick flash mode, means the wireless charger is in abnormal working condition.

(For example: ①The transmitter coil and the receiver coil are not kept in same position;; ②transmitter or receiver is abnormal etc)

Note: At present, Android support the function of the full charging feedback, the feedback is like the above, the rest of the phones with full charging while the charging board won't be prompted.

Mobile phone charging mode

- 1, Ensure that the wireless charger is connected to the power supply
- 2, When the wireless charging emitter enters the standby mode, the indicator light flashes off automatically
3. Put the mobile phone with wireless charging function on the wireless charger center, when the mobile phone is under charging , the indicator will keep shining as white.
- 4, If the phone does not display charging, please move your mobile phone location.

Warning

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Attentions

- 1、 Please do not crush or collision;
- 2、 Please do not disassemble, dispose into fire or water, to avoid short-circuit and leakage.
- 3、 Please do not use C3C at severe high temperatures, humid or corrosive environments, to avoid circuit damage and leakage currents.
- 4、 Please do not places C3C too close with magnetic strip or Chip magcard (ID, debit card), to avoid the magcard failure.
- 5、 Please keep implantable medical devices (cardiac pacemaker, implanted cochlea etc.) away from C3C at lease 20cm, to avoid C3C interference or potential interference the medical devices.
- 6、 Please take care of Children to ensure they are not use C3C as plaything, in case of any accident.

The pictures in this guider are only for information, take practicality as standard.

Including: Wireless charger, Power Line and User's Guider

Charging adapter is not including, if need please buy it separately.

After Sales

The warranty time of C3C is 12 months. If it malfunctions in warranty time, please send C3C with invoice back to ICON service center. ICON will maintained or offer other services according the testing result. Please make sure C3C work with specified mobile device. Artificial damage or not normal use cause of any damage, ICON assumes no responsibility. For any query, please call to ICON service center or visit ICON website for inquiry. ICON reserve all the right for the final explanation.