# CALIBRATION DATA PROBE CALIBRATION DATA



# **COMOSAR E-Field Probe Calibration Report**

Ref: ACR.121.5.24.BES.A

# ATTESTATION OF GLOBAL COMPLIANCE CO. LTD.

1-2/F, BUILDING 19, JUNFENG INDUSTRIAL PARK, CHONGQING ROAD, HEPING COMMUNITY, FUHAI STREET

BAO 'AN DISTRICT, SHENZHEN, GUANGDONG, CHINA MVG COMOSAR DOSIMETRIC E-FIELD PROBE

**SERIAL NO.: 2023-EPGO-414** 

Calibrated at MVG
Z.I. de la pointe du diable
Technopôle Brest Iroise – 295 avenue Alexis de Rochon
29280 PLOUZANE - FRANCE

Calibration date: 04/30/2024



Accreditations #2-6789 Scope available on www.cofrac.fr

The use of the Cofrac brand and the accreditation references is prohibited from any reproduction

### Summary:

This document presents the method and results from an accredited COMOSAR Dosimetric E-Field Probe calibration performed at MVG, using the CALIPROBE test bench, for use with a MVG COMOSAR system only. The test results covered by accreditation are traceable to the International System of Units (SI).




	Name	Function	Date	Signature
Prepared by:	Pedro Ruiz	Measurement Responsible	4/30/2024	fedurfui,
Checked & approved by:	Jérôme Luc	Technical Manager	4/30/2024	JES
Authorized by:	Yann Toutain	Laboratory Director	Gann	TOUTANN

Yann Toutain ID Signature numérique de Yann Toutain ID Date : 2024.04.30 19:35:52 +02'00'

	Customer Name		
	ATTESTATION OF GLOBAL		
Distribution :	COMPLIANCE		
	CO. LTD.		

Issue	Name	Date	Modifications
A	Pedro Ruiz	4/30/2024	Initial release





# TABLE OF CONTENTS

1	Dani	ce Under Test	
1	Devi	ce Under Test4	
2	Prod	uct Description4	
	2.1	General Information	4
3	Mea	surement Method4	
	3.1	Sensitivity	4
	3.2	Linearity	
	3.3	Isotropy	5
	3.4	Boundary Effect	5
4	Mea	surement Uncertainty	
5	Calil	oration Results6	
	5.1	Calibration in air	6
	5.2	Calibration in liquid	7
6	Veri	fication Results8	
7	List	of Equipment9	



#### 1 DEVICE UNDER TEST

Device Under Test			
Device Type	COMOSAR DOSIMETRIC E FIELD PROBE		
Manufacturer	MVG		
Model	SSE2		
Serial Number	2023-EPGO-414		
Product Condition (new / used)	Used		
Frequency Range of Probe	0.15 GHz-7.5GHz		
Resistance of Three Dipoles at Connector	Dipole 1: R1=0.222 MΩ		
	Dipole 2: R2=0.226 MΩ		
	Dipole 3: R3=0.248 MΩ		

#### 2 PRODUCT DESCRIPTION

# 2.1 GENERAL INFORMATION

MVG's COMOSAR E field Probes are built in accordance to the IEC/IEEE 62209-1528 and FCC KDB865664 D01 standards.



Figure 1 – MVG COMOSAR Dosimetric E field Probe

Probe Length	330 mm
Length of Individual Dipoles	2 mm
Maximum external diameter	8 mm
Probe Tip External Diameter	2.5 mm
Distance between dipoles / probe extremity	1 mm

#### MEASUREMENT METHOD

The IEC/IEEE 62209-1528 and FCC KDB865664 D01 standards provide recommended practices for the probe calibrations, including the performance characteristics of interest and methods by which to assess their effect. All calibrations / measurements performed meet the fore-mentioned standards.

#### 3.1 <u>SENSITIVITY</u>

The sensitivity factors of the three dipoles were determined using a two step calibration method (air and tissue simulating liquid) using waveguides as outlined in the standards for frequency range 600-7500MHz and using the calorimeter cell method (transfer method) as outlined in the standards for frequency 150-450 MHz.



#### 3.2 LINEARITY

The evaluation of the linearity was done in free space using the waveguide, performing a power sweep to cover the SAR range 0.01W/kg to 100W/kg.

#### 3.3 ISOTROPY

The axial isotropy was evaluated by exposing the probe to a reference wave from a standard dipole with the dipole mounted under the flat phantom in the test configuration suggested for system validations and checks. The probe was rotated along its main axis from 0 to 360 degrees in 15degree steps. The hemispherical isotropy is determined by inserting the probe in a thin plastic box filled with tissue-equivalent liquid, with the plastic box illuminated with the fields from a half wave dipole. The dipole is rotated about its axis (0°-180°) in 15° increments. At each step the probe is rotated about its axis (0°-360°).

#### 3.4 BOUNDARY EFFECT

The boundary effect is defined as the deviation between the SAR measured data and the expected exponential decay in the liquid when the probe is oriented normal to the interface. To evaluate this effect, the liquid filled flat phantom is exposed to fields from either a reference dipole or waveguide. With the probe normal to the phantom surface, the peak spatial average SAR is measured and compared to the analytical value at the surface.

The boundary effect uncertainty can be estimated according to the following uncertainty approximation formula based on linear and exponential extrapolations between the surface and  $d_{\rm be}$  +  $d_{\mathrm{step}}$  along lines that are approximately normal to the surface:

$$\mathrm{SAR}_{\mathrm{uncertainty}} [\%] = \delta \mathrm{SAR}_{\mathrm{be}} \, \frac{\left(d_{\mathrm{be}} + d_{\mathrm{step}}\right)^2}{2 d_{\mathrm{step}}} \frac{\left(e^{-d_{\mathrm{be}}/(\delta \rho)}\right)}{\delta/2} \quad \mathrm{for} \, \left(d_{\mathrm{be}} + d_{\mathrm{step}}\right) < 10 \; \mathrm{mm}$$

where

 $\mathsf{SAR}_{uncertainty}$ is the uncertainty in percent of the probe boundary effect

is the distance between the surface and the closest zoom-scan measurement  $d_{be}$ 

point, in millimetre

is the separation distance between the first and second measurement points that  $\Delta_{\text{step}}$ 

are closest to the phantom surface, in millimetre, assuming the boundary effect

at the second location is negligible

δ is the minimum penetration depth in millimetres of the head tissue-equivalent

liquids defined in this standard, i.e.,  $\delta \approx 14$  mm at 3 GHz;

⊿SAR<sub>be</sub> in percent of SAR is the deviation between the measured SAR value, at the

distance  $d_{\text{be}}$  from the boundary, and the analytical SAR value.

The measured worst case boundary effect SARuncertainty[%] for scanning distances larger than 4mm is 1.0% Limit, 2%).



#### 4 MEASUREMENT UNCERTAINTY

The guidelines outlined in the IEC/IEEE 62209-1528 and FCC KDB865664 D01 standards were followed to generate the measurement uncertainty associated with a SAR probe calibration using the waveguide or calorimetric cell technique depending on the frequency.

The estimated expanded uncertainty (k=2) in calibration for SAR (W/kg) is +/-11% for the frequency range 150-450MHz.


The estimated expanded uncertainty (k=2) in calibration for SAR (W/kg) is +/-14% for the frequency range 600-7500MHz.

#### 5 CALIBRATION RESULTS

Ambient condition			
Liquid Temperature 20 +/- 1 °C			
Lab Temperature	20 +/- 1 °C		
Lab Humidity	30-70 %		

#### 5.1 CALIBRATION IN AIR

The following curve represents the measurement in waveguide of the voltage picked up by the probe toward the E-field generated inside the waveguide.



From this curve, the sensitivity in air is calculated using the below formula.

$$E^{2} = \sum_{i=1}^{3} \frac{V_{i} \left(1 + \frac{V_{i}}{DCP_{i}}\right)}{Norm_{i}}$$

where

Vi=voltage readings on the 3 channels of the probe DCPi=diode compression point given below for the 3 channels of the probe Normi=dipole sensitivity given below for the 3 channels of the probe

Page: 6/10



Normx dipole 1 (μV/(V/m) <sup>2</sup> )	Normy dipole $2 (\mu V/(V/m)^2)$	Normz dipole 3 ( $\mu$ V/(V/m) <sup>2</sup> )
0.60	0.98	0.88

DCP dipole 1	DCP dipole 2	DCP dipole 3
(mV)	(mV)	(mV)
115	104	98

#### 5.2 <u>CALIBRATION IN LIQUID</u>

The calorimeter cell or the waveguide is used to determine the calibration in liquid using the formula below.

$$ConvF = \frac{E_{liquid}^2}{E_{air}^2}$$

The E-field in the liquid is determined from the SAR measurement according to the below formula.  $E_{liquid}^2 = \frac{\rho \, SAR}{\sigma}$ 

$$E_{liquid}^2 = \frac{\rho SAR}{\sigma}$$

where

 $\sigma$ =the conductivity of the liquid

ρ=the volumetric density of the liquid

SAR=the SAR measured from the formula that depends on the setup used. The SAR formulas are given below

For the calorimeter cell (150-450 MHz), the formula is:

$$SAR = c \frac{dT}{dt}$$

where

c=the specific heat for the liquid

dT/dt=the temperature rises over the time

For the waveguide setup (600-75000 MHz), the formula is:

$$SAR = \frac{4P_W}{ab\delta} e^{\frac{-2z}{\delta}}$$

a=the larger cross-sectional of the waveguide

b=the smaller cross-sectional of the waveguide

 $\delta$ =the skin depth for the liquid in the waveguide

Pw=the power delivered to the liquid


Page: 7/10




The below table summarize the ConvF for the calibrated liquid. The curves give examples for the measured SAR depending on the voltage in some liquid.

<u>Liquid</u>	Frequency (MHz*)	<u>Con∨F</u>
HL750	750	2.04
HL850	835	1.89
HL900	900	1.91
HL1750	1750	2.28
HL1800	1800	1.99
HL1900	1900	2.08
HL2000	2000	2.24
HL2300	2300	2.20
HL2450	2450	2.16
HL2600	2600	2.06
HL5250	5250	1.53
HL5600	5600	1.24
HL5750	5750	1.37


(\*) Frequency validity is +/-50MHz below 600MHz, +/-100MHz from 600MHz to 6GHz and +/-700MHz above 6GHz






#### VERIFICATION RESULTS

The figures below represent the measured linearity and axial isotropy for this probe. The probe specification is +/-0.2 dB for linearity and +/-0.15 dB for axial isotropy.





Page: 8/10



# 7 LIST OF EQUIPMENT

Equipment Summary Sheet					
Equipment Description	Manufacturer / Model	Identification No.	Current Calibration Date	Next Calibration Date	
CALIPROBE Test Bench	Version 2	NA	Validated. No cal required.	Validated. No cal required.	
Network Analyzer	Rohde & Schwarz ZVM	100203	08/2021	08/2024	
Network Analyzer – Calibration kit	Rohde & Schwarz ZV-Z235	101223	07/2022	07/2025	
Multimeter	Keithley 2000	4013982	02/2023	02/2026	
Signal Generator	Rohde & Schwarz SMB	106589	03/2022	03/2025	
Amplifier	MVG	MODU-023-C-0002	Characterized prior to test. No cal required.	Characterized prior to test. No cal required.	
Power Meter	NI-USB 5680	170100013	06/2021	06/2026	
USB Sensor	Keysight U2000A	SN: MY62340002	10/2022	10/2025	
Directional Coupler	Krytar 158020	131467	Characterized prior to test. No cal required.	Characterized prior to test. No cal required.	
Fluoroptic Thermometer	LumaSense Luxtron 812	94264	09/2022	09/2025	
Coaxial cell	MVG	SN 32/16 COAXCELL_1	Validated. No cal required.	Validated. No cal required.	
Wa∨eguide	мvg	SN 32/16 WG2_1	Validated. No cal required.	Validated. No cal required.	
Liquid transition	MVG	SN 32/16 WGLIQ_0G600_1	Validated. No cal required.	Validated. No cal required.	
Wa∨eguide	MVG	SN 32/16 WG4_1	Validated. No cal required.	Validated. No cal required.	
Liquid transition	MVG	SN 32/16 WGLIQ_0G900_1	Validated. No cal required.	Validated. No cal required.	
Wa∨eguide	MVG	SN 32/16 WG6_1	Validated. No cal required.	Validated. No cal required.	
Liquid transition	MVG		Validated. No cal required.	Validated. No cal required.	
Wa∨eguide	MVG	SN 32/16 WG8_1	Validated. No cal required.	Validated. No cal required.	
Liquid transition	MVG	SN 32/16 WGLIQ_1G800B_1	Validated. No cal required.	Validated. No cal required.	
Liquid transition	MVG		Validated. No cal required.	Validated. No cal required.	

Page: 9/10



Wa∨eguide	MVG	SN 32/16 WG10_1	Validated. No cal required.	Validated. No cal required.
Liquid transition	MVG	SN 32/16 WGLIQ_3G500_1	Validated. No cal required.	Validated. No cal required.
Wa∨eguide	мvg	SN 32/16 WG12_1	Validated. No cal required.	Validated. No cal required.
Liquid transition	MVG	SN 32/16 WGLIQ_5G000_1	Validated. No cal required.	Validated. No cal required.
Wa∨eguide	MVG	SN 32/16 WG14_1	Validated. No cal required.	Validated. No cal required.
Liquid transition	MVG	SN 32/16 WGLIQ_7G000_1	Validated. No cal required.	Validated. No cal required.
Temperature / Humidity Sensor	Testo 184 H1	44225320	06/2021	06/2024



# **COMOSAR E-Field Probe Calibration Report**

Ref: ACR.139.8.25.BES.A

# ATTESTATION OF GLOBAL COMPLIANCE CO. LTD.

1-2/F, BUILDING 19, JUNFENG INDUSTRIAL PARK, CHONGQING ROAD, HEPING COMMUNITY, FUHAI **STREET** 

BAO 'AN DISTRICT, SHENZHEN, GUANGDONG, CHINA MVG COMOSAR DOSIMETRIC E-FIELD PROBE

**SERIAL NO.: 2023-EPGO-414** 

Calibrated at MVG Z.I. de la pointe du diable Technopôle Brest Iroise – 295 avenue Alexis de Rochon 29280 PLOUZANE - FRANCE

Calibration date: 05/06/2025



Scope available on www.cofrac.fr

#### Summary:

This document presents the method and results from an accredited COMOSAR Dosimetric E-Field Probe calibration performed at MVG, using the CALIPROBE test bench, for use with a MVG COMOSAR system only. The test results covered by accreditation are traceable to the International System of Units (SI).



Ref: ACR.139.8.25.BES.A

	Name	Function	Date	Signature
Prepared by:	Pedro Ruiz	Technical Manager	5/19/2025	feducifuiz
Checked & approved by:	Pedro Ruiz	Technical Manager	5/19/2025	frámfung
Authorized by:	Kim Rutkowski	Quality Manager	5/19/2025	Signed by: Kinberley ROTKOWSKI
				3D680547AD17461

	Customer Name		
	ATTESTATION		
Distribution :	OF GLOBAL		
Distribution .	COMPLIANCE		
	CO. LTD.		

Issue	Name	Date	Modifications
A	Pedro Ruiz	5/19/2025	Initial release



# TABLE OF CONTENTS

1	Dev:	ice Under Test4	
2	Prod	luct Description4	
	2.1	General Information	
3	Mea	surement Method4	
	3.1	Sensitivity	
	3.2	Linearity	
	3.3	Isotropy	
	3.4	Boundary Effect	5
	3.5	Probe Modulation Response	6
4	Mea	surement Uncertainty6	
5	Cali	bration Results6	
	5.1	Calibration in air	6
	5.2	Calibration in liquid	7
6	Veri	fication Results8	
7	List	of Equipment9	



#### 1 DEVICE UNDER TEST

Device Under Test			
Device Type COMOSAR DOSIMETRIC E FIELD PROBI			
Manufacturer	MVG		
Model	SSE2		
Serial Number	2023-EPGO-414		
Product Condition (new / used)	Used		
Frequency Range of Probe	0.15 GHz-7.5GHz		
Resistance of Three Dipoles at Connector	Dipole 1: R1=0.222 MΩ		
	Dipole 2: R2=0.226 MΩ		
	Dipole 3: R3=0.248 MΩ		

#### 2 PRODUCT DESCRIPTION

# 2.1 GENERAL INFORMATION

MVG's COMOSAR E field Probes are built in accordance to the IEC/IEEE 62209-1528 and FCC KDB865664 D01 standards.



Figure 1 – MVG COMOSAR Dosimetric E field Probe

Probe Length	330 mm
Length of Individual Dipoles	2 mm
Maximum external diameter	8 mm
Probe Tip External Diameter	2.5 mm
Distance between dipoles / probe extremity	1 mm

#### 3 MEASUREMENT METHOD

The IEC/IEEE 62209-1528 and FCC KDB865664 D01 standards provide recommended practices for the probe calibrations, including the performance characteristics of interest and methods by which to assess their effect. All calibrations / measurements performed meet the fore-mentioned standards.

#### 3.1 <u>SENSITIVITY</u>

The sensitivity factors of the three dipoles were determined using a two step calibration method (air and tissue simulating liquid) using waveguides as outlined in the standards for frequency range 600-7500MHz and using the calorimeter cell method (transfer method) as outlined in the standards for frequency 150-450 MHz.



#### 3.2 LINEARITY

The evaluation of the linearity was done in free space using the waveguide, performing a power sweep to cover the SAR range 0.01W/kg to 100W/kg.

#### 3.3 ISOTROPY

The axial isotropy was evaluated by exposing the probe to a reference wave from a standard dipole with the dipole mounted under the flat phantom in the test configuration suggested for system validations and checks. The probe was rotated along its main axis from 0 to 360 degrees in 15degree steps. The hemispherical isotropy is determined by inserting the probe in a thin plastic box filled with tissue-equivalent liquid, with the plastic box illuminated with the fields from a half wave dipole. The dipole is rotated about its axis (0°-180°) in 15° increments. At each step the probe is rotated about its axis (0°-360°).

#### 3.4 BOUNDARY EFFECT

The boundary effect is defined as the deviation between the SAR measured data and the expected exponential decay in the liquid when the probe is oriented normal to the interface. To evaluate this effect, the liquid filled flat phantom is exposed to fields from either a reference dipole or waveguide. With the probe normal to the phantom surface, the peak spatial average SAR is measured and compared to the analytical value at the surface.

The boundary effect uncertainty can be estimated according to the following uncertainty approximation formula based on linear and exponential extrapolations between the surface and  $d_{\rm be}$  +  $d_{\mathrm{step}}$  along lines that are approximately normal to the surface:

$$\mathrm{SAR}_{\mathrm{uncertainty}} [\%] = \delta \mathrm{SAR}_{\mathrm{be}} \frac{\left(d_{\mathrm{be}} + d_{\mathrm{step}}\right)^2}{2d_{\mathrm{step}}} \frac{\left(e^{-d_{\mathrm{be}}/(\delta \rho)}\right)}{\delta/2} \quad \mathrm{for} \ \left(d_{\mathrm{be}} + d_{\mathrm{step}}\right) < 10 \ \mathrm{mm}$$

where

 $\mathsf{SAR}_{uncertainty}$ is the uncertainty in percent of the probe boundary effect

is the distance between the surface and the closest zoom-scan measurement  $d_{be}$ 

point, in millimetre

is the separation distance between the first and second measurement points that  $\Delta_{\text{step}}$ 

are closest to the phantom surface, in millimetre, assuming the boundary effect

at the second location is negligible

δ is the minimum penetration depth in millimetres of the head tissue-equivalent

liquids defined in this standard, i.e.,  $\delta \approx 14$  mm at 3 GHz;

⊿SAR<sub>be</sub> in percent of SAR is the deviation between the measured SAR value, at the

distance  $d_{\text{be}}$  from the boundary, and the analytical SAR value.

The measured worst case boundary effect SARuncertainty[%] for scanning distances larger than 4mm is 1.0% Limit, 2%).



#### 3.5 PROBE MODULATION RESPONSE

MVG's probe were evaluated experimentally with various modulated signal and the deviation from CW response were found neglectable in the used power range of the probe. So the correction to taking into account the linearization parameters for different modulation is null, therefore the CW factor given in this report can be used whatever the measured modulation

#### MEASUREMENT UNCERTAINTY

The guidelines outlined in the IEC/IEEE 62209-1528 and FCC KDB865664 D01 standards were followed to generate the measurement uncertainty associated with a SAR probe calibration using the waveguide or calorimetric cell technique depending on the frequency.

The estimated expanded uncertainty (k=2) in calibration for SAR (W/kg) is +/-11% for the frequency range 150-450MHz.


The estimated expanded uncertainty (k=2) in calibration for SAR (W/kg) is +/-14% for the frequency range 600-7500MHz.

#### 5 CALIBRATION RESULTS

Ambient condition				
Liquid Temperature 20 +/- 1 °C				
Lab Temperature	20 +/- 1 °C			
Lab Humidity	30-70 %			

#### 5.1 CALIBRATION IN AIR

The following curve represents the measurement in waveguide of the voltage picked up by the probe toward the E-field generated inside the waveguide.



From this curve, the sensitivity in air is calculated using the below formula.

$$E^{2} = \sum_{i=1}^{3} \frac{V_{i} \left(1 + \frac{V_{i}}{DCP_{i}}\right)}{Norm_{i}}$$

Page: 6/10





where

Vi=voltage readings on the 3 channels of the probe DCPi=diode compression point given below for the 3 channels of the probe Normi=dipole sensitivity given below for the 3 channels of the probe

Normx dipole 1 ( $\mu$ V/(V/m) <sup>2</sup> )	Normy dipole $2 (\mu V/(V/m)^2)$	Normz dipole 3 ( $\mu$ V/(V/m) <sup>2</sup> )
0.58	0.91	0.92

DCP dipole 1	DCP dipole 2	DCP dipole 3
(mV)	(mV)	(mV)
113	102	100

#### 5.2 CALIBRATION IN LIQUID

The calorimeter cell or the waveguide is used to determine the calibration in liquid using the formula below.

$$ConvF = \frac{E_{liquid}^2}{E_{air}^2}$$

The E-field in the liquid is determined from the SAR measurement according to the below formula.  $E_{liquid}^2 = \frac{\rho \, ^{SAR}}{\sigma}$ 

$$E_{liquid}^2 = \frac{\rho SA}{\sigma}$$

where

 $\sigma$ =the conductivity of the liquid

ρ=the volumetric density of the liquid

SAR=the SAR measured from the formula that depends on the setup used. The SAR formulas are given below

For the calorimeter cell (150-450 MHz), the formula is:

$$SAR = c \frac{dT}{dt}$$

where

c=the specific heat for the liquid

dT/dt=the temperature rises over the time

For the waveguide setup (600-75000 MHz), the formula is:

$$SAR = \frac{4PW}{ab\delta}e^{\frac{-2z}{\delta}}$$

Page: 7/10




where


a=the larger cross-sectional of the waveguide b=the smaller cross-sectional of the waveguide  $\delta$ =the skin depth for the liquid in the waveguide Pw=the power delivered to the liquid

The below table summarize the ConvF for the calibrated liquid. The curves give examples for the measured SAR depending on the voltage in some liquid.

<u>Liquid</u>	Frequency (MHz*)	<u>ConvF</u>
HL450	450	2.31
HL750	750	2.30
HL850	835	2.23
HL900	900	2.18
HL1750	1750	2.33
HL1800	1800	2.74
HL1900	1900	2.25
HL2000	2000	2.38
HL2300	2300	2.37
HL2450	2450	2.29
HL2600	2600	2.19
HL5250	5250	1.54
HL5600	5600	1.44
HI 5750	5750	1 41


(\*) Frequency validity is +/-50MHz below 600MHz, +/-100MHz from 600MHz to 6GHz and +/-700MHz above 6GHz






#### VERIFICATION RESULTS

The figures below represent the measured linearity and axial isotropy for this probe. The probe specification is +/-0.2 dB for linearity and +/-0.15 dB for axial isotropy.





Page: 8/10

Template\_ACR.DDD.N.YY.MVGB.ISSUE\_COMOSAR Probe vM

This document shall not be reproduced, except in full or in part, without the written approval of MVG. The information contained herein is to be used only for the purpose for which it is submitted and is not to be released in whole or part without written approval of MVG.



# 7 LIST OF EQUIPMENT

Equipment Summary Sheet						
Equipment Description	Manufacturer / Model	Identification No.	Current Calibration Date	Next Calibration Date		
CALIPROBE Test Bench	Version 2	NA	Validated. No cal required.	Validated. No cal required.		
Network Analyzer	Rohde & Schwarz ZVM	100203	08/2021	08/2026		
Network Analyzer – Calibration kit	Rohde & Schwarz ZV-Z235	101223	07/2022	07/2027		
Multimeter	Keithley 2000	4013982	02/2023	02/2026		
Signal Generator	Rohde & Schwarz SMB	183277	05/2022	05/2026		
Amplifier	MVG	MODU-023-C-0002	Characterized prior to test. No cal required.	Characterized prior to test. No cal required.		
Power Meter	NI-USB 5680	170100013	06/2021	06/2026		
USB Sensor	Keysight U2000A	SN: MY62340002	10/2024	10/2027		
Directional Coupler	Krytar 158020	131467	Characterized prior to test. No cal required.			
Fluoroptic Thermometer	LumaSense Luxtron 812	94264	09/2022	09/2025		
Coaxial cell	MVG	SN 32/16 COAXCELL_1	Validated. No cal required.	Validated. No cal required.		
Wa∨eguide	MVG	SN 32/16 WG2_1	Validated. No cal required.	Validated. No cal required.		
Liquid transition	MVG	SN 32/16 WGLIQ_0G600_1	Validated. No cal required.	Validated. No cal required.		
Wa∨eguide	MVG	SN 32/16 WG4_1	Validated. No cal required.	Validated. No cal required.		
Liquid transition	MVG	SN 32/16 WGLIQ_0G900_1	Validated. No cal required.	Validated. No cal required.		
Wa∨eguide	MVG	SN 32/16 WG6_1	Validated. No cal required.	Validated. No cal required.		
Liquid transition	MVG	SN 32/16 WGLIQ_1G500_1	Validated. No cal required.	Validated. No cal required.		
Wa∨eguide	MVG	SN 32/16 WG8_1	Validated. No cal required.	Validated. No cal required.		
Liquid transition	MVG	SN 32/16 WGLIQ_1G800B_1		Validated. No cal required.		
Liquid transition	MVG	SN 32/16 WGLIQ_1G800H_1		Validated. No cal required.		

Page: 9/10



Ref: ACR.139.8.25.BES.A

Wa∨eguide	MVG	SN 32/16 WG10_1	Validated. No cal required.	Validated. No cal required.
Liquid transition	MVG	SN 32/16 WGLIQ_3G500_1	Validated. No cal required.	Validated. No cal required.
Wa∨eguide	MVG	SN 32/16 WG12_1	Validated. No cal required.	Validated. No cal required.
Liquid transition	MVG	SN 32/16 WGLIQ_5G000_1	Validated. No cal required.	Validated. No cal required.
Wa∨eguide	MVG	SN 32/16 WG14_1	Validated. No cal required.	Validated. No cal required.
Liquid transition	MVG	SN 32/16 WGLIQ_7G000_1	Validated. No cal required.	Validated. No cal required.
Temperature / Humidity Sensor	Testo 184 H1	44235403	02/2024	02/2027

# **DIPOLE CALIBRATION DATA**



# **SAR Reference Dipole Calibration Report**

Ref: ACR.118.19.22.BES.A

# ATTESTATION OF GLOBAL COMPLIANCE CO. LTD.

1-2/F, BUILDING 19, JUNFENG INDUSTRIAL PARK, CHONGQING ROAD, HEPING COMMUNITY, FUHAI STREET

BAO 'AN DISTRICT, SHENZHEN, GUANGDONG, CHINA MVG COMOSAR REFERENCE DIPOLE

FREQUENCY: 1900 MHZ

SERIAL NO.: SN 29/15 DIP1G900-389

Calibrated at MVG
Z.I. de la pointe du diable
Technopôle Brest Iroise – 295 avenue Alexis de Rochon
29280 PLOUZANE - FRANCE

Calibration date: 04/28/2022



ETALONNAGE

Accreditations #2-6789 and #2-6814 Scope available on www.cofrac.fr

The use of the Cofrac brand and the accreditation references is prohibited from any reproduction

#### Summary:

This document presents the method and results from an accredited SAR reference dipole calibration performed in MVG using the COMOSAR test bench. All calibration results are traceable to national metrology institutions.



	Name	Function	Date	Signature
Prepared by:	Jérôme Luc	Technical Manager	4/28/2022	JES
Checked by :	Jérôme Luc	Technical Manager	4/28/2022	JE
Approved by:	Yann Toutain	Laboratory Director	4/28/2022	Gann TOUTAAN

<u>Gann TOUTAIN</u> 2022.04.28 17:02:05 +02'00'

	Customer Name
Distribution :	ATTESTATION OF GLOBAL COMPLIANCE CO. LTD.

Issue	Name	Date	Modifications	
A	Jérôme Luc 4/28/2022		Initial release	





# TABLE OF CONTENTS

1	Intro	duction4	
2	Devi	ce Under Test	
3	Prod	uct Description	
	3.1	General Information	4
4	Mea	surement Method5	
	4.1	Return Loss Requirements	5
	4.2	Mechanical Requirements	5
5	Mea	surement Uncertainty5	
	5.1	Return Loss	5
	5.2	Dimension Measurement	
	5.3	Validation Measurement	5
6	Calil	oration Measurement Results6	
	6.1	Return Loss and Impedance In Head Liquid	6
	6.2	Return Loss and Impedance In Body Liquid	6
	6.3	Mechanical Dimensions	7
7	Vali	dation measurement	
	7.1	Head Liquid Measurement	8
	7.2	SAR Measurement Result With Head Liquid	8
	7.3	Body Liquid Measurement	11
	7.4	SAR Measurement Result With Body Liquid	12
8	List	of Equipment13	



#### INTRODUCTION

This document contains a summary of the requirements set forth by the IEC/IEEE 62209-1528 and FCC KDB865664 D01 standards for reference dipoles used for SAR measurement system validations and the measurements that were performed to verify that the product complies with the fore mentioned standards.

#### 2 DEVICE UNDER TEST

Device Under Test				
Device Type	COMOSAR 1900 MHz REFERENCE DIPOLE			
Manufacturer	MVG			
Model	SID1900			
Serial Number	SN 29/15 DIP1G900-389			
Product Condition (new / used)	Used			

#### 3 PRODUCT DESCRIPTION

#### 3.1 **GENERAL INFORMATION**

MVG's COMOSAR Validation Dipoles are built in accordance to the IEC/IEEE 62209-1528 and FCC KDB865664 D01 standards. The product is designed for use with the COMOSAR test bench only.



Figure 1 – MVG COMOSAR Validation Dipole



#### 4 MEASUREMENT METHOD

The IEC/IEEE 62209-1528 and FCC KDB865664 D01 standards provide requirements for reference dipoles used for system validation measurements. The following measurements were performed to verify that the product complies with the fore mentioned standards.

#### 4.1 RETURN LOSS REQUIREMENTS

The dipole used for SAR system validation measurements and checks must have a return loss of -20 dB or better. The return loss measurement shall be performed against a liquid filled flat phantom, with the phantom constructed as outlined in the fore mentioned standards. A direct method is used with a network analyser and its calibration kit, both with a valid ISO17025 calibration.

#### 4.2 <u>MECHANICAL REQUIREMENTS</u>

The IEC/IEEE 62209-1528 and FCC KDB865664 D01 standards specify the mechanical components and dimensions of the validation dipoles, with the dimension's frequency and phantom shell thickness dependent. The COMOSAR test bench employs a 2 mm phantom shell thickness therefore the dipoles sold for use with the COMOSAR test bench comply with the requirements set forth for a 2 mm phantom shell thickness. A direct method is used with a ISO17025 calibrated caliper.

#### 5 MEASUREMENT UNCERTAINTY

All uncertainties listed below represent an expanded uncertainty expressed at approximately the 95% confidence level using a coverage factor of k=2, traceable to the Internationally Accepted Guides to Measurement Uncertainty.

#### 5.1 RETURN LOSS

The following uncertainties apply to the return loss measurement:

Frequency band	<b>Expanded Uncertainty on Return Loss</b>		
400-6000MHz	0.08 LIN		

#### 5.2 <u>DIMENSION MEASUREMENT</u>

The following uncertainties apply to the dimension measurements:

Length (mm)	Expanded Uncertainty on Length
0 - 300	0.20 mm
300 - 450	0.44 mm


#### 5.3 VALIDATION MEASUREMENT

The guidelines outlined in the IEC/IEEE 62209-1528 and FCC KDB865664 D01 standards were followed to generate the measurement uncertainty for validation measurements.

Scan Volume	Expanded Uncertainty
1 g	19 % (SAR)
10 g	19 % (SAR)


#### 6 CALIBRATION MEASUREMENT RESULTS

# 6.1 <u>RETURN LOSS AND IMPEDANCE IN HEAD LIQUID</u>



Frequency (MHz)	Return Loss (dB)	Requirement (dB)	Impedance
1900	-23.76	-20	$52.2 \Omega + 6.1 j\Omega$

# 6.2 RETURN LOSS AND IMPEDANCE IN BODY LIQUID



Frequency (MHz)	Return Loss (dB)	Requirement (dB)	Impedance
1900	-21.20	-20	$45.5 \Omega + 7.4 i\Omega$

Page: 6/13





#### 6.3 MECHANICAL DIMENSIONS

Frequency MHz	Ln	nm	hm	m	d r	nm
	required	m easured	required	m easured	required	m easured
300	420.0 <b>±1 %</b> .		250.0 <b>±1 %.</b>		6.35 <b>±1 %.</b>	
450	290.0 <b>±1 %.</b>		166.7 <b>±1</b> %.		6.35 <b>±1 %</b> .	
750	176.0 ±1 %.		100.0 <b>±1 %.</b>		6.35 <b>±1 %</b> .	
835	161.0 <b>±1 %.</b>		89.8 <b>±1 %.</b>		3.6 <b>±1 %.</b>	
900	149.0 <b>±1 %.</b>		83.3 <b>±1 %.</b>		3.6 <b>±1 %.</b>	
1450	89.1 <b>±1 %.</b>		51.7 <b>±1 %.</b>		3.6 <b>±1 %.</b>	
1500	86.2 <b>±1 %.</b>		50.0 <b>±1 %.</b>		3.6 <b>±1 %.</b>	
1640	79.0 <b>±1 %.</b>		45.7 ±1 %.		3.6 <b>±1 %.</b>	
1750	75.2 <b>±1</b> %.		42.9 <b>±1 %.</b>		3.6 <b>±1 %.</b>	
1800	72.0 <b>±1 %.</b>		41.7 <b>±1 %.</b>		3.6 <b>±1 %.</b>	
1900	68.0 <b>±1 %.</b>	-	39.5 <b>±1 %.</b>	-	3.6 <b>±1 %.</b>	-
1950	66.3 <b>±</b> 1 %.		38.5 <b>±1 %.</b>		3.6 <b>±1 %.</b>	
2000	64.5 <b>±1 %.</b>		37.5 <b>±1 %.</b>		3.6 <b>±1 %.</b>	
2100	61.0 <b>±1 %</b> .		35.7 <b>±1 %</b> .		3.6 <b>±1 %</b> .	
2300	55.5 <b>±1 %.</b>		32.6 <b>±1</b> %.		3.6 <b>±1 %.</b>	
2450	51.5 <b>±1 %.</b>		30.4 <b>±1 %</b> .		3.6 <b>±1 %</b> .	
2600	48.5 <b>±1 %.</b>		28.8 <b>±1 %.</b>		3.6 <b>±1 %.</b>	
3000	41.5 <b>±1 %.</b>		25.0 <b>±1 %.</b>		3.6 <b>±1 %.</b>	
3300	-		-		-	
3500	37.0 <b>±1 %.</b>		26.4 <b>±1 %.</b>		3.6 <b>±1 %.</b>	
3700	34.7 <b>±1 %</b> .		26.4 ±1 %.		3.6 <b>±1</b> %.	
3900	-		-		-	
4200	-		-		-	
4600	-		-		-	
4900	-				-	

#### 7 VALIDATION MEASUREMENT

The IEC/IEEE 62209-1528 and FCC KDB865664 D01 standards state that the system validation measurements must be performed using a reference dipole meeting the fore mentioned return loss and mechanical dimension requirements. The validation measurement must be performed against a liquid filled flat phantom, with the phantom constructed as outlined in the fore mentioned standards. Per the standards, the dipole shall be positioned below the bottom of the phantom, with the dipole length centered and parallel to the longest dimension of the flat phantom, with the top surface of the dipole at the described distance from the bottom surface of the phantom.



#### 7.1 HEAD LIQUID MEASUREMENT

Frequency MHz	Relative permittivity ( $\mathbf{\epsilon}_{\mathbf{r}}$ ')		Conductiv	ity (σ) S/m
	required measured		required	measured
300	45.3 <b>±10</b> %		0.87 <b>±</b> 10 %	
450	43.5 <b>±</b> 10 %		0.87 <b>±</b> 10 %	
750	41.9 <b>±</b> 10 %		0.89 <b>±</b> 10 %	
835	41.5 <b>±</b> 10 %		0.90 <b>±</b> 10 %	
900	41.5 <b>±</b> 10 %		0.97 <b>±</b> 10 %	
1450	40.5 <b>±</b> 10 %		1.20 <b>±</b> 10 %	
1500	40.4 <b>±</b> 10 %		1.23 <b>±</b> 10 %	
1640	40.2 <b>±1</b> 0 %		1.31 <b>±</b> 10 %	
1750	40.1 <b>±</b> 10 %		1.37 <b>±</b> 10 %	
1800	40.0 <b>±</b> 10 %		1.40 <b>±</b> 10 %	
1900	40.0 <b>±</b> 10 %	37.9	1.40 <b>±</b> 10 %	1.43
1950	40.0 <b>±</b> 10 %		1.40 <b>±</b> 10 %	
2000	40.0 ±10 %		1.40 ±10 %	
2100	39.8 <b>±</b> 10 %		1.49 <b>±</b> 10 %	
2300	39.5 <b>±1</b> 0 %		1.67 <b>±</b> 10 %	
2450	39.2 <b>±1</b> 0 %		1.80 <b>±</b> 10 %	
2600	39.0 ±10 %		1.96 <b>±</b> 10 %	
3000	38.5 <b>±10</b> %		2.40 <b>±</b> 10 %	
3300	38.2 <b>±1</b> 0 %		2.71 <b>±</b> 10 %	
3500	37.9 <b>±</b> 10 %		2.91 <b>±</b> 10 %	
3700	37.7 <b>±</b> 10 %		3.12 <b>±</b> 10 %	
3900	37.5 <b>±10</b> %		3.32 <b>±10</b> %	
4200	37.1 <b>±</b> 10 %		3.63 <b>±1</b> 0 %	
4600	36.7 <b>±</b> 10 %		4.04 <b>±</b> 10 %	
4900	36.3 <b>±</b> 10 %		4.35 <b>±</b> 10 %	

#### 7.2 SAR MEASUREMENT RESULT WITH HEAD LIQUID


The IEC/IEEE 62209-1528 and FCC KDB865664 D01 standards state that the system validation measurements should produce the SAR values shown below (for phantom thickness of 2 mm), within the uncertainty for the system validation. All SAR values are normalized to 1 W forward power. In bracket, the measured SAR is given with the used input power.



Software	OPENSAR V5
Phantom	SN 13/09 SAM68
Probe	SN 41/18 EPGO333
Liquid	Head Liquid Values: eps': 37.9 sigma: 1.43
Distance between dipole center and liquid	10.0 mm
Area scan resolution	dx=8mm/dy=8mm
Zoon Scan Resolution	dx=8mm/dy=8mm/dz=5mm
Frequency	1900 MHz
Input power	20 dBm
Liquid Temperature	20 +/- 1 °C
Lab Temperature	20 +/- 1 °C
Lab Humidity	30-70 %

Frequency MHz	1 g SAR (W/kg/W)		10 g SAR	(W/kg/W)
	required	m easured	required	measured
300	2.85		1.94	
450	4.58		3.06	
750	8.49		5.55	
835	9.56		6.22	
900	10.9		6.99	
1450	29		16	
1500	30.5		16.8	
1640	34.2		18.4	
1750	36.4		19.3	
1800	38.4		20.1	
1900	39.7	41.26 (4.13)	20.5	20.86 (2.09
1950	40.5		20.9	
2000	41.1		21.1	
2100	43.6		21.9	
2300	48.7		23.3	
2450	52.4		24	
2600	55.3		24.6	
3000	63.8		25.7	
3300	-		-	
3500	67.1		25	
3700	67.4		24.2	
3900	-		-	
4200	-		-	
4600	-		-	
4900	-		-	









#### 7.3 BODY LIQUID MEASUREMENT

Frequency MHz	Relative per	Relative permittivity (s <sub>r</sub> ')		ity (σ) S/m
	required	required measured		measured
150	61.9 <b>±</b> 10 %		0.80 <b>±</b> 10 %	
300	58.2 <b>±10</b> %		0.92 <b>±</b> 10 %	
450	56.7 <b>±1</b> 0 %		0.94 <b>±</b> 10 %	
750	55.5 <b>±10</b> %		0.96 <b>±</b> 10 %	
835	55.2 <b>±1</b> 0 %		0.97 <b>±</b> 10 %	
900	55.0 <b>±1</b> 0 %		1.05 <b>±</b> 10 %	
915	55.0 <b>±1</b> 0 %		1.06 <b>±</b> 10 %	
1450	54.0 <b>±1</b> 0 %		1.30 <b>±</b> 10 %	
1610	53.8 <b>±10</b> %		1.40 <b>±</b> 10 %	
1800	53.3 <b>±1</b> 0 %		1.52 <b>±</b> 10 %	
1900	53.3 <b>±10</b> %	55.0	1.52 <b>±</b> 10 %	1.57
2000	53.3 <b>±10</b> %		1.52 <b>±</b> 10 %	
2100	53.2 <b>±10</b> %		1.62 ±10 %	
2300	52.9 <b>±</b> 10 %		1.81 <b>±</b> 10 %	
2450	52.7 <b>±10</b> %		1.95 <b>±</b> 10 %	
2600	52.5 <b>±10</b> %		2.16 <b>±</b> 10 %	
3000	52.0 <b>±1</b> 0 %		2.73 <b>±10</b> %	
3300	51.6 <b>±</b> 10 %		3.08 <b>±</b> 10 %	
3500	51.3 <b>±</b> 10 %		3.31 <b>±</b> 10 %	
3700	51.0 <b>±</b> 10 %		3.55 <b>±10</b> %	
3900	50.8 <b>±1</b> 0 %		3.78 <b>±</b> 10 %	
4200	50.4 <b>±1</b> 0 %		4.13 <b>±</b> 10 %	
4600	49.8 <b>±</b> 10 %		4.60 <b>±</b> 10 %	
4900	49.4 <b>±</b> 10 %		4.95 <b>±</b> 10 %	
5200	49.0 <b>±10</b> %		5.30 <b>±10</b> %	
5300	48.9 <b>±10</b> %		5.42 <b>±10</b> %	
5400	48.7 <b>±10</b> %		5.53 <b>±10</b> %	
5500	48.6 <b>±10</b> %		5.65 <b>±10</b> %	
5600	48.5 <b>±10</b> %		5.77 <b>±10</b> %	
5800	48.2 <b>±10</b> %		6.00 <b>±10</b> %	




# mvg

# 7.4 SAR MEASUREMENT RESULT WITH BODY LIQUID

Software	OPENSAR V5
Phantom	SN 13/09 SAM68
Probe	SN 41/18 EPGO333
Liquid	Body Liquid Values: eps': 55.0 sigma: 1.57
Distance between dipole center and liquid	10.0 mm
Area scan resolution	dx=8mm/dy=8mm
Zoon Scan Resolution	dx=8mm/dy=8mm/dz=5mm
Frequency	1900 MHz
Input power	20 dBm
Liquid Temperature	20 +/- 1 °C
Lab Temperature	20 +/- 1 °C
Lab Humidity	30-70 %

Frequency MHz	1 g SAR (W/kg/W)	10 g SAR (W/kg/W)
	measured	m easured
1900	39.55 (3.96)	20.51 (2.05)



Page: 12/13



# 8 LIST OF EQUIPMENT

	Equipment Summary Sheet					
Equipment Description	Manufacturer / Model			Next Calibration Date		
SAM Phantom	MVG	SN 13/09 SAM68	Validated. No cal required.	Validated. No cal required.		
COMOSAR Test Bench	Version 3	NA	Validated. No cal required.	Validated. No cal required.		
Network Analyzer	Rohde & Schwarz ZVM	100203	08/2021	08/2024		
Network Analyzer	Agilent 8753ES	MY40003210	10/2019	10/2022		
Network Analyzer – Calibration kit	Rohde & Schwarz ZV-Z235	101223	05/2019	05/2022		
Network Analyzer – Calibration kit	HP 85033D	3423A08186	06/2021	06/2027		
Calipers	Mitutoyo	SN 0009732	10/2019	10/2022		
Reference Probe	MVG	SN 41/18 EPGO333	10/2021	10/2022		
Multimeter	Keithley 2000	1160271	02/2020	02/2023		
Signal Generator	Rohde & Schwarz SMB	106589	03/2022	03/2025		
Amplifier	MVG	MODU-023-C-0002	Characterized prior to test. No cal required.	Characterized prior to test. No cal required.		
Power Meter	NI-USB 5680	170100013	06/2021	06/2024		
Power Meter	Rohde & Schwarz NRVD	832839-056	11/2019	11/2022		
Directional Coupler	Krytar 158020	131467	Characterized prior to test. No cal required.	Characterized prior to test. No cal required.		
Temperature / Humidity Sensor	Testo 184 H1	44225320	06/2021	06/2024		



# **SAR Reference Dipole Calibration Report**

Ref: ACR.139.13.25.BES.A

# ATTESTATION OF GLOBAL COMPLIANCE CO. LTD.

1-2/F, BUILDING 19, JUNFENG INDUSTRIAL PARK, CHONGQING ROAD, HEPING COMMUNITY, FUHAI STREET

BAO 'AN DISTRICT, SHENZHEN, GUANGDONG, CHINA MVG COMOSAR REFERENCE DIPOLE

FREQUENCY: 1900 MHZ SERIAL NO.: 2915-DIP1G900-389

Calibrated at MVG
Z.I. de la pointe du diable
Technopôle Brest Iroise – 295 avenue Alexis de Rochon
29280 PLOUZANE - FRANCE

Calibration date: 05/15/2025



Accreditations #2-6789 and #2-6814 Scope available on www.cofrac.fr

The use of the Cofrac brand and the accreditation references is prohibited from any reproduction

#### Summary:

This document presents the method and results from an accredited SAR reference dipole calibration performed in MVG using the COMOSAR test bench. All calibration results are traceable to national metrology institutions.



Ref: ACR.139.13.25.BES.A

	Name	Function	Date	Signature
Prepared by:	Pedro Ruiz	Technical Manager	5/19/2025	fedurpain
Checked & approved by:	Pedro Ruiz	Technical Manager	5/19/2025	Jacobson Jacobson
Authorized by:	Kim Rutkowski	Quality Manager	5/19/2025	Kinberley ROTKOWSKI

Customer Nan	ne
Distribution: ATTESTATIO OF GLOBAI COMPLIANC CO. LTD.	L

Issue	Name	Date	Modifications
A	Pedro Ruiz	5/19/2025	Initial release



#### TABLE OF CONTENTS

1	Intro	oduction4	
2	Dev	ice Under Test4	
3	Proc	luct Description4	
	3.1	General Information	4
4	Mea	surement Method5	
	4.1	Mechanical Requirements	5
	4.2	S11 parameter Requirements	
	4.3	SAR Requirements	5
5	Mea	surement Uncertainty5	
	5.1	Mechanical dimensions_	5
	5.2	S11 Parameter	
	5.3	SAR	5
6	Cali	bration Results6	
	6.1	Mechanical Dimensions	6
	6.2	S11 parameter	
	6.3	SAR	6
7	List	of Equipment8	

#### INTRODUCTION

This document contains a summary of the requirements set forth by the IEC/IEEE 62209-1528 and FCC KDB865664 D01 standards for reference dipoles used for SAR measurement system validations and the measurements that were performed to verify that the product complies with the fore mentioned standards.

#### 2 DEVICE UNDER TEST

Device Under Test			
Device Type	COMOSAR 1900 MHz REFERENCE DIPOLE		
Manufacturer	MVG		
Model	SID1900		
Serial Number	2915-DIP1G900-389		
Product Condition (new / used)	Used		

#### PRODUCT DESCRIPTION

#### 3.1 GENERAL INFORMATION

MVG's COMOSAR Validation Dipoles are built in accordance to the IEC/IEEE 62209-1528 and FCC KDB865664 D01 standards. The product is designed for use with the COMOSAR test bench only, however, being built in accordance to relevant standards, it can be used in others SAR test benches as long as the final user take care that the prescribed S11 and SAR target value are met.



Figure 1 – MVG COMOSAR Validation Dipole



# 4 MEASUREMENT METHOD

#### 4.1 MECHANICAL REQUIREMENTS

The IEC/IEEE 62209-1528 and FCC KDB865664 D01 standards specify the mechanical components and dimensions of the validation dipoles, with the dimension's frequency and phantom shell thickness dependent. The COMOSAR test bench employs a 2 mm phantom shell thickness therefore the dipoles sold for use with the COMOSAR test bench comply with the requirements set forth for a 2 mm phantom shell thickness. A direct method is used with a ISO17025 calibrated caliper.

#### 4.2 <u>S11 PARAMETER REQUIREMENTS</u>

The dipole used for SAR system validation measurements and checks must have a S11 of -20 dB or better. The S11 measurement shall be performed against a liquid filled flat phantom and using a prescribed spacer, with the phantom constructed as outlined in the fore mentioned standards. A direct method is used with a network analyser and its calibration kit, both with a valid ISO17025 calibration.

#### 4.3 SAR REQUIREMENTS

The IEC/IEEE 62209-1528 and FCC KDB865664 D01 standards provide requirements for reference dipoles used for system validation measurements. The following measurements were performed to verify that the product complies with the fore-mentioned standards.

#### 5 MEASUREMENT UNCERTAINTY

#### 5.1 MECHANICAL DIMENSIONS

For the measurement in the range 0-300mm, the estimated expanded uncertainty (k=2) in calibration for the dimension measurement in mm is  $\pm -0.20$  mm with respect to measurement conditions.

For the measurement in the range 300-450mm, the estimated expanded uncertainty (k=2) in calibration for the dimension measurement in mm is  $\pm -0.44$  mm with respect to measurement conditions.

#### 5.2 <u>S11 PARAMETER</u>

The estimated expanded uncertainty (k=2) in calibration for the S11 parameter in linear is  $\pm -0.08$  with respect to measurement conditions.

#### 5.3 SAR

The guidelines outlined in the IEC/IEEE 62209-1528 and FCC KDB865664 D01 standards were followed to generate the measurement uncertainty for validation measurements.

The estimated expanded uncertainty (k=2) in calibration for the 1g and 10g SAR measurement in W/kg is  $\pm$ 1.19% with respect to measurement conditions.

Page: 5/8




#### CALIBRATION RESULTS

#### MECHANICAL DIMENSIONS

L mm		h mm		d mm	
Measured	Required	Measured	Required	Measured	Required
-	68.00 +/- 2%	-	39.50 +/- 2%	-	3.60 +/- 2%

#### 6.2 S11 PARAMETER

#### 6.2.1 S11 parameter in Head Liquid



Frequency (MHz)	S11 parameter (dB)	Requirement (dB)	Impedance
1900	-24.01	-20	$47.8\Omega + 5.6j\Omega$

#### 6.3 SAR

The IEC/IEEE 62209-1528 and FCC KDB865664 D01 standards state that the system validation measurements must be performed using a reference dipole meeting the fore mentioned return loss and mechanical dimension requirements. The validation measurement must be performed against a liquid filled flat phantom, with the phantom constructed as outlined in the fore mentioned standards. Per the standards, the dipole shall be positioned below the bottom of the phantom, with the dipole length centered and parallel to the longest dimension of the flat phantom, with the top surface of the dipole at the described distance from the bottom surface of the phantom by using a prescribed spacer.

#### 6.3.1 SAR with Head Liquid


The IEC/IEEE 62209-1528 and FCC KDB865664 D01 standards state that the system validation measurements should produce the SAR values shown below (for phantom thickness of 2 mm), within the uncertainty for the system validation. All SAR values are normalized to 1 W forward power. In bracket, the measured SAR is given with the used input power.

#### Page: 6/8



Software	OPENSAR V5
Phantom	SN 13/09 SAM68
Probe	4424-EPGO-443
Liquid	Head Liquid Values: eps': 42.4 sigma: 1.39
Distance between dipole center and liquid	10.0 mm
Area scan resolution	dx=8mm/dy=8mm
Zoon Scan Resolution	dx=8mm/dy=8mm/dz=5mm
Frequency	1900 MHz
Input power	20 dBm
Liquid Temperature	20 +/- 1 °C
Lab Temperature	20 +/- 1 °C
Lab Humidity	30-70 %

Frequency	1g SAR (W/kg)		10g SAR (W/kg)			
	Measured	Measured	Target	Measured	Measured	Target
		normalized	normalized		normalized	normalized
		to 1W	to 1W		to 1W	to 1W
1900 MHz	3.98	39.83	39.70	2.06	20.59	20.50





# 7 LIST OF EQUIPMENT

Equipment Summary Sheet							
Equipment Description	I HAENTINGANAN NA I		Next Calibration Date				
SAM Phantom	MVG	SN 13/09 SAM68	Validated. No cal required.	Validated. No cal required.			
COMOSAR Test Bench	Version 3	NA	Validated. No cal required.	Validated. No cal required.			
Network Analyzer	Rohde & Schwarz ZVM	100203	08/2021	08/2026			
Network Analyzer – Calibration kit	Rohde & Schwarz ZV-Z235	101223	07/2022	07/2027			
Calipers	Mitutoyo	SN 0009732	11/2022	11/2025			
Reference Probe	MVG	4424-EPGO-443	05/2025	05/2026			
Multimeter	Keithley 2000	4013982	02/2023	02/2026			
Signal Generator	Rohde & Schwarz SMB	183277	05/2022	05/2026			
Amplifier	MVG	MODU-023-C-0002	Characterized prior to test. No cal required.	Characterized prior to test. No cal required.			
Power Meter	NI-USB 5680	170100013	06/2021	06/2026			
Power Meter	Keysight U2000A	SN: MY62340002	10/2024	10/2027			
Directional Coupler	Krytar 158020	131467	Characterized prior to test. No cal required.	Characterized prior to test. No cal required.			
Temperature / Humidity Sensor	Testo 184 H1	44235403	10/2024	10/2027			