



EPILADY 2000 L.L.C

Kibbutz Hagoshrim D.N. Upper Galilee 12225 ISRAEL
Tel. 972-6-6956242 Fax. 972-6-6956222
E-mail: epilady@epilady.com Web site: www.epilady.com



Date: 6 February, 2000

Our Ref: RND 000206

To: Hermon Laboratories
Att: Mischelle
Fax.: 6288277

Pages: 2

Re: **A brief description of the circuit functions of the device along with a statement describing how the device operates.**

The electrical system is separated in two circuits. One circuit creates by a crystal of 27.12 MHz a transmitting of radio waves that are tuned by a shielded wire to a mechanical tweezer. When the Tweezer closes on a hair it operates the second circuit, the timer circuit that provides a vocal indication after 28-30 seconds. All that time the tweezer transmits radio waves into the hair and causes the root to loosen itself from the skin.

Sincerely,

Moshe Fish
Q.A. Manager

c.c. Aharon Nechushtan – Q.A. Dept.

