

TrakBelt



Figure 4-14 TrakBelt

Figure 4-14 illustrates the TrakBelt and the positioning of the StarPak and battery. For the user's convenience, the Belt is shipped pre-assembled. If the Belt is disassembled please note the positioning and routing of the cables to aid in re-assembly.

NOTE:

In order to comply with FCC RF Exposure requirements, when this device is used with the TrakBelt (i.e., in the body worn configuration), a minimum separation distance of 3.25 inches must be maintained between the antenna and the user's body. This is accomplished by the design of the Star Pak brackets and mounting straps on the Trak Belt. When the Star Pak is attached as shown in figure 4-14, the minimum separation distance is assured. For added comfort and to increase separation distance, a foam cushion is recommended between the Trak Belt and body.