

Operation Guide

Bluetooth headphone

Model: BH-30

Brand: MiracleAudio™

FCC ID: S7DBH-30



- Thank you for using our product BH-30.

Battery charge

- Before using, please fully charge the battery by the USB cable.
- When the battery power is weak, the red LED will flash and there are 'dee..dee..' sound to remind.
- The red LED will light on in charging.
- When the battery is fully charged, the red LED will turn off.

Power on/off

Long press power button for about 3 seconds to power on and ready to pair or power off the unit.

Pairing

Long press power button for about 3 seconds, the blue LED will flash fast. Then the unit is in pairing mode. Enter the pairing mode of the other Bluetooth device and find 'BH-30' to pair. The pairing can be done automatically or by inputting '0000' to pair. After pairing, the blue LED will flash slowly. Then unit enters the standby mode.

Music Playing

- Play the music from the paired device.
- Short slide '-' or '+' wheel to go the last or next song.

- Long slide ‘-’ or ‘+’ wheel to adjust the volume.
- Press MBF button to change the mode.

Hands-free for calling

- Short press power button to pick up or stop a call.

TF playing

- Insert the TF card for stereo music.

Note: After you make or pick up, then stop a call, the unit will play music automatically though the unit is not in playing mode before. If you don’t want to enjoy the music, please stop playing.

LED indicator

LED Indicator	Status of the Headphone
Blue LED flash fast	No connection and Pairing mode
Blue LED flash slowly	In connection, playing or calling
Red LED light on in charging	Battery is not full
Red LED light off in charging	Battery is full

Specifications

Bluetooth Version	V3.0
Bluetooth profiles	HSP, HFP, A2DP, AVRCP
Operation range	Up to 10 meters
Music playing time	Up to 8 hours
Talking time	Up to 10 hours
Charging time	About 2 hours
Input power	DC, 5V/320mA
Dimensions	195*170*80mm
Weight	190g

Accessories:

- USB cable
- AUX cable
- Instruction manual

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.