

**Rabbit Tanaka Corporation Limited**

18 Ka Yip Street,  
MP Industrial Centre,  
Block A, 7/F,  
Siu Sai Wan, Hong Kong.

Telephone : (852)2562 5299  
Fax Line : (852)2561 1108  
e-mail: [info@rabbit-tanaka.com](mailto:info@rabbit-tanaka.com)  
Website: [www.rabbit-tanaka.com](http://www.rabbit-tanaka.com)

## 72060 Aquaclean Operational Description

When the Aquaclean Switch “ON”, the Power Indicator Light ( formed by Resistor R16 and LED D5 ) will be lit up.

The Transistors Q9, Q10 and Transformer T5 constituted a high frequency high voltage's Oscillator to drive the UV Fluorescent Tube lit.

If the UV Fluorescent Tube is working. The UV Fluorescent Tube Indicator Light ( formed by Diodes D2, D3, Capacitor C2 and LED D4 ) will also be lit up.