

CoolFire

BLUETOOTH VIBRATING MOUSE ALARM CLOCK




IM.:BTVB-06

www.TimeChant.com

Customer service:
Support@timechant.com

POWER YOUR VIBRATOR

Connect the Coolfire Bluetooth Vibrating Shaker to a USB power Adapter.



White light turns ON
When the vibrator is
powered up.



1

INSTALL THE APP

What you need ?

Any smartphone device with iOS / Android 5.0 or above



Scan the below QR code to install.

Or, search "CoolFire Vibrator Alarm" on App Store to download and install the APP.



Scan the below QR code to install.

Or, search "CoolFire Vibrator Alarm" on Google Play to download and install the APP.



2

HOW TO PAIR THE VIBRATOR WITH YOUR SMARTPHONE?


STEP 1

Close the App and remove it from the background
(Make sure that the Bluetooth of your smartphone is turned ON)

STEP 2

Hold the big button for more than 10 seconds until you hear a beep sound then release the button.

HOLD THIS BUTTON



STEP 3

Open the CoolFire App

Pair the device when the pairing request pops up

Select "Not allowed" when it asks for notification

The App shows the time of the vibrator when the pairing is successful.



Close the App and reopen it if there is any pairing problems.

Contact support@timechant.com if you need help!

3

USING THE APP


- + Add** Tap the plus button to add a new alarm.
- ↻ Edit** Tap the button to edit an alarm.
- ✉ E-mail** Tap the HELP button to contact us
- 🏠 Home** Tap the button back to HOME page



4

THE VIBRATOR

THE VIBRATOR



A) VIBRATION STRENGTH SETTING

Set the vibration strength to L=Low, H=High

B) WAKE YOU UP SETTING

- | OPTIONS | |
|----------------------|--|
| 1. VIBRATION ONLY | |
| 2. SOUND ONLY | |
| 3. VIBRATION + SOUND | |

5

HOW TO TURN OFF THE VIBRATION



Set the Alarm to **Snooze**

Press the **BIG BUTTON** once to set the alarm to snooze

Set the Alarm to **off**

Press and hold the **BIG BUTTON** until the vibration stops.

This sets the alarm to off

6

CHARGE YOUR SMARTPHONE

CHARGE YOUR SMARTPHONE



CONVENIENT CHARGING

Use the USB charging port of the vibrator to charge your phone while you sleep.

7

TROUBLESHOOTINGS and FAQ

Why the vibrator doesn't work after I set the alarm?

Check the "Time of the Vibrator" to see if it is the same as your smartphone
(1 minute tolerance is acceptable).

If it is not then close the App first and then hold the big button of the vibrator for 10 seconds until you hear a beep sound.

After that open the App to make a connection with your vibrator.

The time of the vibrator will sync with the smartphone and the vibrator should work with your alarm time settings.

Why the time of the vibrator is different from my smartphone?

Refer to the above question.

Can I use the vibrator without the smartphone?

Yes. The vibrator saves all your alarm settings that comes from the smartphone app and then it can work without the presence of your smartphone.

How can I use the vibrator with my second smartphone?

Follow the "HOW TO PAIR THE VIBRATOR WITH YOUR SMARTPHONE?" to switch the vibrator to work with your second smartphone. You need to do the same when you switch it back to work with your primary phone.

8

FCC Warning:
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. The device has been evaluated to meet general RF exposure requirement.