


# WIRELESS SPEAKER

## USER MANUAL

### BT528



Please read user guide carefully before use.

## **PRODUCT SPECIFICATIONS:**

- Model: BT528
- Bluetooth Version: 5.1
- Support: L2CAP / A2DP / AVRCP, receive AUDIO signal and control the AUDIO device.
- Supports HSP / HFP (hands-free), built in microphone for hands-free calls
- Connection Distance: 10M approx
- SNR:  $\geq 90$ dB
- Battery: 2400mAh 3.7V 8.88Wh
- Play Time (100% volume): 4H
- Charging Time: 4-5H
- Speaker Size:  $\Phi 45$ mm\*2
- Power:  $4\Omega/5W*2$
- Frequency: 120HZ-20KHZ
- Input: 5V=2A
- Size:  $\Phi 73 \times 156$ mm
- Weight: 480g


## **PRODUCT FEATURES:**

1. Advanced bluetooth chip and circuit design techniques, compatible with all wireless devices.
2. With HI-FI speaker, to ensure clear and bright sound.
3. Support TF card and USB card, play audio with MP3 mode.
4. The distance range is about 10 meters.

5. With built-in AUX line, you can directly connect the external devices, such as, tablet PC/TV/cell phone.

6. It will turn off automatically if you disconnect Bluetooth for 5 minutes.

## KEY AND SLOT FUNCTIONS:



- ①. DC 5V Slot: Use the standard Type C charging cable for charging.
- ②. USB Slot: When inserting the U disk into the slot, it can decode and play audio in MP3/WAV format.

- ③. TF Slot: When inserting a TF card into the slot, it can decode and play audio in MP3/WAV format.
- ④. AUX Line in Slot: Use 3.5mm AUX line input through external equipment.
- ⑤. Power Switch: Long press for "on/off ". When play music ( U disk /TF card / Bluetooth), short press to switch U disk /TF/Bluetooth.(Switch to "Line In" if connected to an audio device via an AUX cable)
- ⑥. Play Button
  - 1) Press once: Play or pause.
  - 2) Long press: Turn off or turn on the light.
- ⑦. During music playback, press the "+" button once to increase the volume, long press the "+" button to skip to the next song.
- ⑧. During music playback, press the "-" button once to decrease the volume, long press the "-" button to return to the previous song.

⑨Light mode switch: When the music starts to play, the certain pattern of the lights will follow the rhythm of the music; to change the light pattern you need to press the button to get the "breathing light";To turn off the light you need to press button again.

**RESET:** Long press ON/OFF for 10 seconds to reset.

### **WARRANTY STATEMENT:**

The warranty period for this product is 3 months after purchase.

If you have any questions, please contact a customer service representative for assistance.

## FCC Warning

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and  
(2) this device must accept any interference received,  
including interference that may cause undesired operation.  
Any Changes or modifications not expressly approved by  
the party responsible for compliance could void the user's  
authority to operate the equipment.

This equipment has been tested and found to comply with  
the limits for a Class B digital device, pursuant to part 15  
of the FCC Rules. These limits are designed to provide  
reasonable protection against harmful interference in a  
residential installation. This equipment generates uses  
and can radiate radio frequency energy and, if not installed  
and used in accordance with the instructions, may cause  
harmful interference to radio communications. However,  
there is no guarantee that interference will not occur in a  
particular installation. If this equipment does cause harmful  
interference to radio or television reception, which can be  
determined by turning the equipment off and on, the user is  
encouraged to try to correct the interference by one or  
more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment  
and receiver.
- Connect the equipment into an outlet on a circuit  
different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV  
technician for help.

The device has been evaluated to meet general RF  
exposure requirement. The device can be used in portable  
exposure condition without restriction.