WARRANTY TERMS & CONDITIONS

For Additional Information Online: https://thesteakager.com/return-policy

For Warranty Information Online:

https://www.thesteakager.com/about/warranty

PRIVACY POLICY

We never share you information. For Additional Information Online: https://thesteakager.com/privacy-policy

STEAKAGER

PRO15 USER GUIDE

Now that you have purchased a SteakAger product, you can be confident knowing that as well as our 1-year parts and labor warranty, you have the added peace of mind of a dedicated helpline and web support.

Please retain proof of purchase in order to obtain warranty services.

Warranty begins from original date of purchase.



READ ALL INSTRUCTIONS BEFORE USE

For your safety and continued enjoyment of this product, always read the instruction manual before using.

CONTENTS

- 1 Introduction
- 2 Safety Instructions
- Operating Instructions
- 4 Cleaning and Maintenance
- Warranty Terms and Conditions

CLEANING AND MAINTENANCE

BEFORE FIRST USE

- Place the SteakAger on a level flat surface that is clean and dry.
- Wash all surfaces of the appliance with a soft damp cloth and warm, sudsy water.
- Wash drying rack with a soft damp cloth and warm, sudsy water or dishwasher.
- Dry thoroughly with paper towel or soft cloth.
- DO NOT immerse appliance in water.

BETWEEN AGING CYCLES

- Unplug the Steakager and place on a level flat surface that is clean and dry.
- Wash all surfaces of the appliance with a soft damp cloth and warm, sudsy water.
- Wash drying rack with a soft damp cloth and warm, sudsy water or dishwasher.
- Dry thoroughly with paper towel or soft cloth.
- DO NOT immerse appliance in water.
- Truss Rack can go in the dishwasher.

These instructions, additional information, FAQ's and assembly videos can be found online at www.thesteakager.com.

OPERATING INSTRUCTIONS

Connecting to your SteakAger

- Download the SteakAger App from the App Store or Google Play for free.
- Make sure your appliance is plugged in and running.
- Follow the below App instructions for either iOS, Android.

•

WiFi Connection :

** NOTE: If connecting through WiFi you will need to set up and account. Make sure to confirm the account with the confirmation email before trying to sign in.

After opening the app press "Connect to SteakAger". You will then be prompted to select "Wifi Connection" or "Bluetooth Connection". Press "Wifi Connection" and enter your credentials. If you have already created an account, enter your credentials and press login. If you have not created an account press create account and enter your information.

- After signing in through WiFi you will need to go into the Settings (Gear lcon) and go into WiFi configuration to select the network and enter your password.
- If you receive an error message "Please wait 4 minutes for data to load", you may have entered the incorrect information or your ager is not connecting to your network properly.

•

Bluetooth Connection :

 When connecting through bluetooth you do not need a login to access your SteakAger. This is the easiest and quickest way to setup and view your SteakAger data.

After opening the App press "Connect to SteakAger" you will then be prompted to select "Wifi Connection" or "Bluetooth Connection". Press "Bluetooth Connection" and you will be immediately redirected to your home screen.

• If you receive any error messagers once connected, "Please wait 4 minutes for data to load". Your unit may not be plugged in or connecting properly. If you are unable to resolve the issue with the troubleshooting guide, contact us at www.TheSteakAger.com

INTRODUCTION

Congratulations!

You have made an excellent choice with the purchase of this SteakAger product. You can be confident this SteakAger product has been manufactured to the highest standards of performance and safety, and is supported by the team at SteakAger.

We want you to be completely satisfied with your purchase of this SteakAger product, which is backed by a comprehensive manufacturer's 1 year warranty and ongoing support through our After Sale Support Team.

If you require technical support or in the unlikely event your product was received damaged, please email us at info@ thesteakager.com. Product claims made within the 1 year warranty period will be repaired and/ or replaced free of charge provided you have satisfactory proof of purchase (keep your receipt). This limited warranty does not apply in cases of damage caused by accident, improper use, abuse or force majeure.

This limited warranty will be invalidated if the appliance is tampered with in any way whatsoever. In case of questions or technical problems please contact us at info@thesteakager.com

If the appliance is returned, it must be packed correctly, as we cannot accept responsibility for damage caused in transit. We recommend using a traceable, insured delivery service.

SAFETY INSTRUCTIONS

THIS APPLIANCE IS FOR HOUSEHOLD USE ONLY



WARNING: When using electrical appliances especially when children are present, basic safety precautions should always be followed to reduce the risk of fire, shock, and/or injury to persons, including the following:

- Read all Instructions.
- AVOID ELECTRICAL SHOCK. DO NOT immerse cord, plug or the SteakAger in water or other liquid.
- UNPLUG the SteakAger from outlet when not in use or before cleaning. DO NOT add or remove parts while running.
- Never touch or obstruct the rear vent during operation, ensure minimum clearance is 1" at back of SteakAger
- Children should not use the SteakAger unsupervised; close supervision is required when appliance is used near or with children
- Never touch any moving parts in the product.
- Operation of the SteakAger requires it to be placed on a level surface in the refrigerator.
- Never operate the SteakAger with a damaged cord or plug that has been damaged in any way. Immediately contact Customer Service for analysis and resolution.
- DO NOT add unauthorized attachments.
- Use only with factory cord supplied; NEVER add extension cords. Unplug when not in use.
- Do not use product for any purpose outside its intended use.
- WARNING: This product contains a chemical known to the State of California to cause cancer.
- **WARNING:** This product contains a chemical known to the State of California to cause birth defects or other reproductive harm.

OPERATING INSTRUCTIONS

GETTING READY TO USE YOUR STEAKAGER


- Set your refrigerator thermostat to maintain 34-38*F/1.1-3.3*C
- Purchase a cut of beef of your preference:
 - o T-bone
 - o Ribeye
 - o NY Strip
- Use the rack as a cutting guide for sizing length of cut
- Thoroughly pat dry the beef before placing in the SteakAger
- When placing beef in the SteakAger be careful that beef DOES NOT TOUCH ANY SURFACE INSIDE THE APPLIANCE.
- Place the window on the SteakAger and note it is NOT a sealed door.

ATTENTION PLEASE NOTE

- You can only dry age whole cuts of beef not individual steaks 8lb MIN
- The SteakAger is designed to dry age beef only.
- The SteakAger is NOT designed to age fish, chicken, pork, lamb or game meat.
- To reduce risk of cross contamination, do not cut just a few steaks off and place the rest back in the The SteakAger.

NOTES ON GETTING STARTED

- The Truss Rack will slide in and out of the unit with the guides on the top and bottom.
- Use butchers twine to truss the meat in the Truss Rack.
- When inserting the meat into the unit make sure that the meat isn't touching any side of the unit.
- The PRO15 can be used in either the vertical or horizontal orientation.



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.