

98mm
210mm

FCC warning:
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Relocate or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

This device has been evaluated to meet general RF exposure requirement.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

WaterHr. All rights reserved.
Designed in Canada. Manufactured in China.
Headquarters in Toronto, Ontario.

How to Maintain?

Do NOT:

- Wash the WaterHr Smart Bottle in a dishwasher (Bottle lid is dishwasher safe).
- Submerge the WaterHr Smart Bottle under water for over 30 minutes.
- Unassemble the bottle.
- Use the bottle with liquid over 140°F (60°C).
- Clean bottle with strong acid or alkali such as cleaning powder, bleach, chemical or solvent.

WaterHr warranty excludes damages caused by negligence, accident, abuse, alteration or modification.

Warnings & Cautions

The WaterHr Smart Bottle may cause injury if improperly used. Prior to using the WaterHr Smart Bottle, please read the following safety and precautions. Please do not use the WaterHr Smart Bottle in any manner other than that specified on the product packaging or in the user manual.

IMPORTANT:

This product is not suitable or intended for use by children under 3 years old. Children may otherwise be hazardous to small children, especially children under 3 years old. Keep product and any dangerous equipment, including those using batteries, out of the reach of small children!

WaterHr. All rights reserved.
Designed in Canada. Manufactured in China.
Headquarters in Toronto, Ontario.

Hydrate to Help Others

WaterHr is committed to helping people worldwide hydrate easier and safer. That is why a portion of our proceeds will go directly to our water charity partner - Water.org

When you support WaterHr, you help those in need gain access to safe drinking water.

Tell the World!

We're proud of our product and to be part of your journey towards achieving hydration wellness! Tag or mention us on Instagram and we'll post it! @enjoywaterh #DrinkConfidently

Customer Service

Have a specific question? Reach out to us directly at service@waterh.com

FAQ

Got questions? We have answers. Visit our FAQ at www.waterh.com/faq

www.waterh.com



WaterHr
User Manual
Model: WH-8021

98mm
210mm

Conquer Hydration

Auto Accurate Tracking

No need to guess or log manual entries. The sensor inside WaterHr automatically tracks your exact level of hydration.

360° LED Hydration Reminder

Subtle reminder so you stay hydrated all day. Customize reminder preference and frequency in the WaterHr app.

Smart Scan Safety Sensor

WaterHr is equipped with a water quality sensor that measures the TDS (Total Dissolved Solids) in your drinking water.

Wireless Charging

No more fuss with charging cables. Experience WaterHr convenience by charging your smart bottle on any wireless charging station. Each full charge lasts up to 15 days* of un-interrupted use.

* Days may vary depending on your drinking habits.

1. Getting Started

In Your Package



WaterHr Smart Bottle
Lid
Wireless charging station
Charging cable

Step 1 - Create Account

In the WaterHr app, register for an account.

Step 2 - Bring Your Phone Near Your WaterHr Bottle

Click "Search" in the WaterHr app.

Step 3 - Pair Device

Click "Connect" in the WaterHr app to begin pairing. WaterHr bottle will display a solid blue LED light.

Step 4 - Complete Setup

Tap "Complete" in the WaterHr app for a display message "Connect Successful".

* To achieve optimal hydration tracking accuracy, place bottle upright on a flat surface for 2-3 seconds after drinking.

2. The Mobile APP

Hydration intake is precisely tracked for you in the app.

- No more manually log water consumption or make your own calculations.
- No more kicking yourself for forgetting to log an entry and lose track.
- No more guessing whether you've had enough water.

For a full WaterHr experience, scan the QR code and download the WaterHr app via the App Store or Google Play Store.



Light Modes

Low Battery	Breathing red light
Your Bottle is Charging!	Breathing green light
Your Bottle is Ready to Go!	Steady green light
Hydration Reminder	Breathing blue light
Ready to be Paired	Steady blue light

3. Enjoy & Grow

You're officially all set!

Light Modes

Low Battery	Breathing red light
Your Bottle is Charging!	Breathing green light
Your Bottle is Ready to Go!	Steady green light
Hydration Reminder	Breathing blue light
Ready to be Paired	Steady blue light

封面

封面

介绍

step 1

step 2

step 3