

BODY CAMERA
USER'S QUICK GUIDE

Model: S3

I.Warning 1

II.Product introduction 2

III.Operation 2


IV.Indicator 4

V.Customer service 4

I.Warning










- Please keep the device from high temperature.
- When smoke, smell or noise comes out from the device, shut down the power immediately, and contact your supplier in time.
- Please contact your supplier if the device is not working properly.
No warranty will be covered if the damage caused by unauthorized disassembly or repair.
- Please do NOT charge the device at high temperature over 45 degrees Celsius, it could possibly cause the explosion of the battery. Please use the certificated battery from the original factory ONLY.
- Please read this manual carefully before using the device, and follow the instructions when using the device.
- Please do NOT kick or hit the product to avoid device damage and data missing.
- Keep the device away from high temperature and high humidity environment.
- Keep the device away strong interference source.
- Please backup the data recorded by the device in time.
- Please keep the lens clean for good image quality.
- Please keep your user name and password safe.


II.Product introduction



III.Operation

| Buttom | Icon | Action | Function |
|-----------|------|-------------|--|
| Power | | Short Press | When device is ON, short press to turn on/off the screen. |
| | | Long press | 1.When device is OFF, power on device when holding for over3 seconds. 2.When device is ON, poweroff device when holding for over 3 seconds. |
| Talk back | PTT | Short Press | Start talking back. (Need to connect to interphone or server through internet★) |

| | | | |
|--------------|---|--------------|--|
| Record |  | Short Press | Start recording when device is ON, Stop recording after pressing it again. |
| | | Long press | Power ON and start recording when device is OFF. |
| Snap |  | Short Press | 1.Start to snap. 2.Snap when device is recording and store the picture. |
| | | Long press | Holding for 3 seconds will turn on the flash light when device is ON. |
| Audio Record |  | Short Press | 1.Start recording audio when device is ON. 2.Switch to record audio when device is recording video. |
| Laser |  | Short Press | Turnon the laser when device is ON (only when laser is enabled in menu) |
| | | Long press | Holding for 3 seconds will turn on the IR (when IR is in manual mode) |
| SOS | SOS | Long press | Holding for 3 seconds to starts an alarm and recording, send the alarm to server at the same time★ |
| SIM |  | Insert/Eject | Insert a SIM card into the slot and use 4G service to connect internet★ |
| USB |  | Connect | For charging, data transmission, external camera, headset and interphone ect. |
| Menu/ OK |  | Short Press | 1.Display the main menu on the screen when device is in preview mode. 2.Confirm thesetting changed. |
| | | Long press | Switch 1080P, 720P or other REC resolution in preview mode. |
| Up |  | Short Press | Scroll up the menu or zoom out the view in preview mode. |
| Down |  | Short Press | Scroll down the menu or zoom in the view in preview mode. |

| | | | |
|---------------|---|-------------|---|
| Return / Play |  | Short Press | 1. When menu is displayed,press to return to the upper level menu; 2. When device is idle, pressto play back recorded video, audio and pictures. 3. When recording, press the button will mark the recording video as IMP file. |
| | | Long press | Disable/Enable menu operaton when recording. |

★ Only for 4G product with

IV.Indicator

| LED Indicator | Colour | Description |
|---------------|--------|--|
| Window 1 | Blue | ON:Charging complete Twinkling:Charging OFF:Not charging |
| Window 2 | Green | Twinkling slowly:Idle Twinkling faster:Face recognition is working ON:Live streaming or menu operating |
| | Red | Video recording in progress |
| | Yellow | Audio recording in progress |

V.Customer service

User Notice

A.Warranty

1. This product is warranted for one year;
2. Warranty are not covered in any case of unauthorized modification, repair or damage (such as water, moisture, drop, improper use, etc.)
- 3.In order to extend the life of the battery, it is recommended to

charge once every three months when devices are not used for a long time.

B. Technical support service

If you have any operation or technology problems when you are using product, you can refer to the user manual to find solutions. If that still can't help,try the ways below to find help:

1. Contact your supplier for technical support
2. Regardless of the method of seeking technical services, please be sure to provide the model number, device ID and detailed malfunction of the failed unit, so that our engineers can be more quickly and accurately to help or repair.

C. Precautions before maintenance

- 1.Do simple troubleshooting before you send device back, if that still can't help you solve problems, please confirm the basic information of the product and contact the supplier for repair.
- 2.If the product is out of warranty, make a preliminary quotation for the product repair, and we will provide repair service after receiving your consent.

Note:The service mentioned in this warranty is a standard service. If you have an extra agreement with the company on the service at the time of purchase, the extra service agreement signed will prevail.

Warranty card

User Profile

D M Y (Date)

| | | | |
|---------------|---------------|-------------------|--|
| Name | | Company | |
| Telephone No. | | Address | |
| Dev. Model | | Device ID | |
| Data of sale | | Sales Department | |
| Repair Date | Repair Record | Repair Department | |
| | | | |
| | | | |

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used

in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure

requirement. The device can be used in portable exposure condition without restriction.