







Instruction Manual

Main Features & Technical Parameters

- Power supply: Input AC100-240V 50/60Hz, Output DC12V/2A
- Rated working current: 1.7A
- Rated power of product: 22W
- Rated power of lamp: 5.5W
- Dimming type: Capacitive touch button/stepless dimming
- Power Timer: Smart timing lights (on/off auto-control)
- Light source: 36pcs High photosynthetic efficiency semiconductor LED
- Three types of Light effects to switch: Natural—White—yellow light
- Color temperature: 2700-6500K
- Color rendering index (CRI): Ra ≥90
- Max illuminance: ≥ 1000LUX(The Intensity of Illumination measured from the lamp perpendicular to the table top 31cm distance)
- Wireless charging output: 10W (MAX)

Operating Instruction

1. Usage method of Lamp: Put the lamp on the table and connect power at first. And press  button, short press  button to switch on, The default light is the natural light, press  again to switch off. Short press light switch “M” button, the lamp light changing circularly (Natural—White—Yellow light).
2. Brightness adjustment: In lighted state, Long press  button to change brightness of lamp.

3. Timer function: In lighted state, long press  to start timer off function. Then, the light flashes 2 times it means countdown function starting, and the light will be off automatically in 40 minutes (About one class time). If you Press  again during this period, it will be restart 40 minutes countdown light off function, until end of the countdown function, the lights automatically turned off.

Wireless Charging Instruction


1. Wireless charging function: Please connect power at first, then, please put your mobile phone (which one with wireless charging receiving function) near by the product, and see the reminder show your mobile phone. If show, means be charging, and the status light is green of the time.
2. To be the best using effects and charge efficiency, pleas ensure your mobile phone wireless receiving position is in right way with product receiving, range. When the status light both green and red, means fully charged.

Cautions

1. Please ensure using the power supply matching DC12/2A, If the power adapter or flexible wire is damaged, It only can be replaced by the manufacturer or agent, or by similarly qualified person.
2. For indoor use only.
3. Please pay attention to eyes hurting while using the lamp, the distance should not closely.
4. Please make sure the product without strong electromagnetic interference, otherwise may be lights on or turn off.
5. The hosepipe part of lamp pole can not bent in continuously, otherwise lead to the lamp pole damage easily.

6. Please change a new one, when the light source is use up, cause of this light source is can not be alternative.
7. Please pay attention when used on countertops with a tilt greater than 6 degrees. might be dumping.
8. When using the lamp at night, Please adjust the color temperature (light effect) under 4000K (like natural light, warm white light) is better.

Product Illustration



Packing Accessories

1. Power Adapter * 1
2. Instruction manual * 1

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received,

HSD9027E-10 英文说明书(过 QI-10W 无线充电 DC12V/2A)/

including interference that may cause undesired operation.

RF Exposure Warning Statements:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment shall be installed and operated with minimum distance 20cm between the radiator & body.