

Cocoon manual

Main features of CO smart speaker

Internal MaxAudio3.0 digital audio IC

accurately restore compressed audio file and play original music.

Play music with perfect sound and volume

Built-in two channel stereo amplifying audio circuit

New developing high performance NdFeB mixed magnetic systems, 50mm speaker

Very sensitive touch key, it makes very easy for your operation.

Very long playing time

Built-in 1200 mAh lithium battery

Up to 7 hours playing time

It can be connected with most of audio device

via Bluetooth or 3.5mm input audio jack

CO's hands free function is very helpful for your chat with your friend on mobile or tablet PC, can free your hands.

Overview of CO smart speaker

- 1、 Volume+ / Next
- 2、 Answer / Hung up (Play / Pause)
- 3、 Volume- / Previous
- 4、 USB charging port
- 5、 3.5mm audio input jack
- 6、 Power on /off
- 7、 Indicated light
- 8、 Mic

Turn on CO smart speaker

Slide the power switch to left (refer to diagram No.6) to turn on the speaker.

Charging for CO smart speaker

Please connect it with computer or other charging device via cable line, plug the cable into available USB port on your computer and charging for it. The indicated light is red while charging (refer to diagram No.7) . It will be turn off after charging finished. Charging time is about 2 to 3 hours.

Connection

Two connecting ways

One is wireless Bluetooth connection, another is wired connection via 3.5mm audio line.

1、 Please connect CO smart speaker with any audio device via the 3.5mm audio line be supplied by vendor.

Notice: When a device is connected to the 3.5 mm jack port, Bluetooth stop and CO speaker will not be able to play music in wireless.

2、 Bluetooth wireless connection

- ①It will be in Bluetooth status automatically when turning on the speaker.
- ②On the status of pairing Bluetooth, the speaker will have guidance voice, and the indicated light will rapidly flash in blue.
- ③Turn on the Bluetooth in your mobile phone, then search and find the device named “CO-B” , please click it and wait for connection. The indicated light will turn on in blue after connected.
- ④May be asked to key a password for some lower version of Bluetooth device, please key in “0000” and confirm it.

Play music and answer telephone

1、 Play music in Bluetooth

The music will be automatically transfer to the CO smart speaker and being play after connected with the speaker via Bluetooth. If you can not hear audio, please check it again and ensure the Bluetooth has connected, or turn up the volume.

2、 Play music from external audio source

Connect with external audio device via 3.5mm audio jack, the indicated light will be on in green.

3、 Playing operation

Please press touch-key “+” or “—”for about 3 seconds to choose different songs ; Press the call key (refer to diagram No.2) to pause playing, and press it again to continue to play.

4、 Adjust volume

Please short press “+” or “-” to adjust volume.

Hold on the key of “+” & “-” in same time, it will stop the function of MaxAudio3.0

5、 Answer telephone

When CO smart speaker connected with your mobile via Bluetooth, your all call will be transfer to it, so it is a hands free phone in this time.

When you have a incoming call, the indicated light will rapidly flash in blue, please press the phone key to answer it (refer to diagram 2th)

Notice: The music will be automatically paused during a call , then will replay when the call is ended.

Support

1、 Frequently Asked Questions

Question	Answer
No voice	1、 Please turn up volume 2、 Ensure the speaker paired or connected with the audio device are playing music.
Can not answer and hung up call	It depends on your mobile whether support hands free, because some device are not support it. Please refer to your user manual of device.
Can not connect with CO speaker in wireless	Please ensure the Bluetooth on your mobile phone has been turn on and connected, please refer to the guidance of “ wireless Bluetooth connection”
crackling noise	Bluetooth is a wireless transmission technology, which it is sensitive to objects between the CO speaker and the connected device. The CO speaker is designed to be used within 33feet (10 meters) from the connected device, and without major objects in between both. (such as walls, etc.)

2、 How to care for your CO smart speaker

Please turn off CO smart speaker when do not use it, and far away from dusty.

Avoid to store in environment of extreme temperatures as it will may shorten battery life and affect its function.. Moreover, high temperatures may also degrade performance.

Please try to put it on ventilated place,and put it on the place children can not touch.

Technical Specifications

Weight: 505g

Dimension:171mm*61mm*61mm

Omnidirectional speaker

USB 5V power supply

Power: 5Watt*2

Speaker unit: New developing high performance NdFeB mixed magnetic systems,

Dual 50mm speaker

Very big passive low-frequency radiator

3.5mm audio jack

1200mAh polymer lithium battery

Up to 10 meters (33 feet) working distance

Version 3.0 Bluetooth

Bluetooth profile: HPF V1.5, HSP V1.2, A2DP V1.2, AVRCP

Up to 7 hours playing time, it depends on volume and music type

About 2 or 3 hours charging time

Stored temperature: -10° C to 55° C

Pairing passkey or PIN: 0000

Accessories: User manual, Warranty card, USB charging line, Audio cable

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

All information contained herein is true and correct at the time of print. Any further update can be directed through our website. Thank you.