



Bluetooth Musical LED Makeup Mirror

USER MANUAL



Please read all instructions thoroughly before use.

Units Introduction & Button Function:



Specification:

Model : M1517 (M104A)
Magnification: 1X Magnification
Mirror size: 26*30 CM
Material: Iron + Glass+PP+MDF
Input voltage: AC 100-240V
Output voltage: DC 5V
Version: Bluetooth 5.0

3 Steps for Bluetooth Connection:

1. Long press the bluetooth power button on.
2. Search the mirror via bluetooth on your mobile phone.
3. Select 'music mirror' and finish matching.

Safety introductions:

1. Mirror is made of glass, therefore handle with care.
2. Adult use only. Not intended for use by children.
3. Do not expose mirror to direct sunlight while unattended. Reflected sunlight may cause fire.
4. Gently press the switch, do not press hard.
5. Use soft cloth to clean the mirror surface when needed.
6. Avoid heat, humidity and damp areas.
7. Stop using the mirror immediately if it malfunctions or is damaged in any way.
8. Use care when using LED lights. Extended use/prolonged exposure directly into eyes may cause damage.

Included in box:

LED mirror(1X)
1 AC adaptor (TYPE C)
1 User manual

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body.