





For Android users

Connecting Note
The App need to be installed in a mobile communication device with built-in Bluetooth function, please make sure that your communication equipment has Bluetooth function, this device supports all Bluetooth versions.


Main Interface Partition



Registration Information
Registered user (as shown in Figure) log in after registration, then fill in your personal information.



Friend Interaction
After successfully adding friend, you can interact with your friends; control vibration mode of your friend, and you can chat with your friends in voices and in texts.



Function modes
Voice mode, multimedia mode, smart mode, shake mode, scene mode.




Shenzhen Huahai Technology Co., Ltd.
Shenzhen Huahai Technology Co., Ltd., all right reserved. Duang is a registered trademark or service mark which has been registered by Shenzhen Huahai Technology Co., Ltd. in China and other countries and regions. Other company's and products names mentioned here may be trademarks of other companies.

FCC Statement
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.

Shenzhen Huahai Technology Co., Ltd.
Address: Room 602, Level 6, Plaza A, Shengchanli Building, No.2 Gaoxinzhong Road, Nanshan District, Shenzhen City, China PR
Designed and produced by Shenzhen Huahai Technology Co., Ltd.
Service and support: 400-070-5152

Smart Vibrat Product Manu




Contents

Overview	1
Button Function Description	1
Charging Note	2
Indicator Status	3
UsingSafety and Cleaning	3
Interaction and Environment	4
UsingFlow Chart	4
Downloading Client	5
Connecting Bluetooth	5
Registration Information	7
Adding Friend	7
Friend Interaction	8
Function Modes	8

Overview
Welcome to choose our adult entertainment products. In order to make you have a better experience with the product, we have more experience on the function of intelligent interaction, we prepare this manual which describes the functions and operations of vibrating rod products. Please read it before your usage to ensure your interests and rights. Thank you again for your support.

Main Parts of Vibrating Rod



Button Function Description



Turn on:
Function 1: start after pressing for 3 seconds;
Function 2: vibration intensity enhances when pressing it in starting mode;
Description: after starting the defaulted intensity is the weakest, vibration intensity has 10 levels.

Temperature Control Button:
Press the button once- start heating function, press the button again: turn off heating function;
Description: heating function is off in defaulted mode after starting.

Mode Control Button:
Press once, switching mode
Mode Switching: There are 8 modes can change.

Turn off:
Function 1: press for 3 seconds to turn it off;
Function 2: press the button in starting mode to adjust the vibrating intensity;
Functional combination description:
Press both the on and off buttons seconds at the same time in starting mode, it will make the device locked in the current work. Forunlocking, also need press both the on and off buttons seconds at the same time.

UsingSafety and Cleaning:
Cleaning is needed if the vibrator touches any pollutants, such as stain and grease, ink, cosmetics, or detergent. Please do as follows when cleaning:
 - Confirm that the vibrating rod is not connected to any cables and it's in off state.
 - Use neutral detergent (not containing gasoline or acetone) or high-quality antibacterial soap dab and rinse with clean warm water.
 - Please use a soft dry cloth or towel for patting until it is dry.
 - The vibrating rod is coated with medical silicone, please do not use sharp object when cleaning to avoid piercing and scratching its surface.
 - When using the plug, port or button, do not force the plug into the charging port and do not press button too strongly it will lead to the damage of the charging port and button.


If a plug can not be easily inserted into a charging port, it indicates that they are not well matched. Please check if there is any obstructions and make sure that they are well matched.

Indicator Status
Starting or switching of any state and function can be indicated on the status of the light and vibration.
1. Starting, both lights flashes slowly.
2. When it's successfully connected with the Bluetooth, the light will go out.
3. When the battery capacity is below to 20%, both lights flash quickly, in this case the heating function can not be used.
4. In charging mode, both lights are on for a long time.
5. When it is fully charged, the both lights will go out.
6. Lock/unlock, press both the on and off buttons for 3 seconds, then restart after the motor is paused for a while.

Interaction and Environment
Huahai Technology Company is committed to reducing the influence of its products and its operation to the environment and offering better life experience and smart products to more users. For more information, please visit our official website.

APP Use Instruction

Use flow chart



Vibration Rod Firmware Upgrade
When you are reminded to upgrade, the proposed power capacity of the vibration rod should keep more than 50%, do not turn off the vibration rod during the process of upgrading, it will automatically turn off after the completion of upgrading. However, sometimes it cannot upgrade successfully, and you may be reminded to upgrade again, this is a normal situation.

Connecting Bluetooth
Bluetooth device
You need to install the App in a mobile communication device with Bluetooth module. After installing the App, you can have the vibration rod with wireless connection then use it, detailed operation procedures are shown as follows:

