



**PAUBA**  
THROW OUT LOUD  
Darts Performance Monitor + Activity Tracker

**USER MENU**



3. Wear PAUBA on your dominant wrist where the home button pointing towards your fingers.

**Table of Contents**

Hardware Overview	1
Quick Start	2
How to install mobile app – PAUBA	4
How to pair PAUBA with your Smartphone / Tablet	5
Function Setting Procedure	6
Basic Specifications	7
Important Information:	
FCC Statement	8
FAQ	10

**How to install mobile app**

The data of your activities can be synchronized from the device to your smartphone/tablet via Bluetooth. Simply download the mobile app named "PAUBA" in your smartphone/tablet on App Store or Google Play.

**App Requirement:**  
iOS 8.0 or above  
Android 4.4 or above  
Bluetooth 4.0 or above

For more info please visit: [TheDartsFactory.com/page/PAUBA](http://TheDartsFactory.com/page/PAUBA)

**Important Information: FCC Statement**

**Caution:** changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
- Increase the separation between the equipment and receiver.  
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
- Consult the dealer or an experienced radio/TV technician for help.

**Basic Specifications**

Module Dimension:	46mm x 20.5mm x 12.5mm
Wristband Dimension:	235mm x 21mm x 9.5mm
Module Weight:	7g
Wristband Weight:	40g
LCD Dimensions:	11.2mm x 5.6mm
LCD Resolution:	64dpi x 32dpf
Module Material:	PC (Cover) and ABS (Case)
Wristband Material:	Silica gel
USB Socket:	5V 500mA
Battery Capacity:	60mAH (Li-ion)

**Note:** This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference; and  
(2) this device must accept any interference received, including interference that may cause undesired operation.

**Hardware Overview**

1. Silicone wristband
2. Function key cover
3. Function key of PAUBA
4. Module
5. Micro USB
6. USB cable



**Quick Start**

1. Connect to power supply for up to 6 hours for the first time use. Simply plug one end of the USB cable into the charger and another end of the cable into the Micro USB port of PAUBA.
2. Assembly – Insert module into the silicone wristband properly in such a way that function key of PAUBA matches function key cover as shown below:



**Function Setting Procedure**

**Dart mode function procedure**

1. Go to app settings and select "Darts" in order to enter darts mode.
2. Go to the darts page, touch the green arrow to draw out button tray.
3. Press "Start" button to start and press "Next" to perform next throw.

**Smart Watch Mode:**

1. Go to app settings and select "Activities" to resume smart watch functions.

**Wristband reset function procedure**

1. Press function key of PAUBA 10 seconds.
2. Display will show the Reset.
3. Released the function key, wristband will be factory reset.

**FAQ**

**Q: Can't find device when pairing device?**

**A:** 1. Make sure PAUBA is charged and turned ON.  
2. Make sure smartphone/tablet Bluetooth function is turned ON and the operating system meets minimum requirement.  
3. Make sure the icon of Bluetooth is displayed on the module.  
4. Make sure the distance between the phone and device is within 6 meters.

**Q: How to clean the device?**

**A:** For the module, it is not waterproof; hence, just gently clean with a soft dry cloth. For wristband, use pure water and avoid the use of cleaner, detergent, or bleach.

**Q: When does PAUBA vibrate?**

**A:** The vibration function notifies you of alarms, find your devices, and when it successfully pairs up with your Smartphone / Tablet.

**Q: How do I turn off PAUBA?**

**A:** PAUBA does not have any turn off mode. However, it automatically turns off its screen when it is not used for a period of time.

**Q: How can I register the product warranty?**

**A:** Please complete the online warranty registration <http://thedartsfactory.com/PAUBA>

**TheDartsFactory.com**

For support enquiry, please email to:  
[Hello@thedartsfactory.com](mailto:Hello@thedartsfactory.com)