



DPVR E3 Basic Getting Started Guide

www.dpvr.cn




-1-



Head Strap Face Foam Cushioning Range sensor
Optical Lens

-2-



3. Security Guide Please read the following security guide before using the device, to ensure the safety and proper use. Follow the warnings below, to prevent accidents such as fire or Do avoid an physical collision or damaging to the device.
Use the charger and accessories approved by the manufacturer.
Do not touch the device by wet hands. Do not use the device in humid environment, such as bathroom or swimming pool.


Read the following warnings, to prevent personal injury or device damage. - Do not store the device in hot or cold environment. Temperature is suggested to be between 0 degree and 40 degree.

- Keep the device dry, do not use it outdoor in thunderstorm weather.

- To avoid the possibility of hearing impairment, do not use the earphone or headphone at high volume for long time.

- Not recommended for children under 13 years old. The guardian should limit the using time and ensure frequent breaks for users under 18 and over 65 years old.

-3-




4.Usage Instructions



-4-


4.2 Recommended System Spec




4.3 Download and Install DPVR Assistant Assistant. - Install DPVR Assistant following the prompts after download.

-5-

Windows 10 64bit Home/Professional (Recommended) Windows 8.1 64bit Standard/Professional Windows 7 SP1 64bit Home/Professional/Ultimate



- Go to DPVR official website www.dpvr.cn to download DPVR



-6-

For users without glasses, please directly wear helmet and adjust to a comfortable state. For users wearing glasses, please wear the product as follows:





Figure 2: Make the foam cover the glasses, loosen the headband, and adjust to a comfortable state

-7-

4.6 Replace the facial foam After long time using, the foam cushion might be worn out, replace it when necessary.



4.7 Adjust the straps The headband of this product can be automatically adjusted by the built-in resilient structure according to the user's head circumference. For those with large head circumference, please take off the Back Foam


-8-



4.8 Replace the 3-in-1 Cable If you need to replace the 3-in-1 cable or audio cable, please use a small screwdriver to open the cable cover, pull out the


Figure 2

-9-



Market and business Cooperation: mkt@dpvr.cn 7 Warning Changes or modifications to this unit not expressly approved by the party

5 Firmware Upgrade



responsible for compliance will void the user's authority to operate the

Please refer to function prompts of DPVR Assistant to complete



Official WeChat Account Official Service Account

- Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help.

-11-

-10-