





Bluetooth Musical Traveling Pillow

Output Power : 1W*2
Speaker : 8Ω1W
Charging Power : DC5v 500mA
Working Volt : 3.7v
Power Capacity : 900mAh
Charging Time : 2 hours
Playback Time : 6 hours
Connection : Bluetooth or TF card
BT operative distance : 10m



How to pair: Turn on the unit, turn on the Bluetooth function on the mobile phone, search for the name "BT-0750", press it, finish the pairing after the voice.

Power On: Press the power on bottom for 4s, powered on after the voice.

Power Down: Press the power down bottom for 2s, powered down after the voice.

Pause: Press the pause bottom while playing.

Resume: Press the pause bottom again while the music in pause.

Function: Play music on the phone wirelessly, soft and comfortable touch, good for baby's brain development, comfort baby's neck in their position of lay down or lean on.

Shenzhen Joyren Maternal and Baby Products Co., Ltd
Manufactured by: Address: Floor 3, No. 61, Pingxin Bei Road, Pinghu, Shenzhen
Tel: 86-755-89630932
Fax: 86-755-89630951

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.