





User Manual for LED Mirror



Parameters

Rated Voltage:	110-250V
Wattage/LED Bulb:	1.2W*12PCS
Voltage/LED Bulb:	12V
Color Temperature:	6500K(White)/3000K(Yellow)
Working Wattage:	23.5W
USB Power Output:	DC5.2V $\pm$ 0.2V 1.5A
Bluetooth Name:	A3
AC Input(MAX):	AC100-240V 0.45-0.2A 50-60Hz
Battery Parameters:	Li-ion 7.4V 2000mAh 14.8Wh

User Guide For LED And Bluetooth

1. Connect the power socket on the back of the mirror with the power cord. Turn on the power switch, then you will hear a voice "Bluetooth Mode".
2. Press the light switch to turn on the led lights. The lights can be 3 colors ---- yellow, warm white, white. Quickly press the light switch twice to change the color. Keep pressing the light switch to adjust the brightness.
3. Keep pressing the time switch to set the hour time and minute time. Quick press the time switch to change the number.
4. Turn on the Bluetooth on your phone, then search 'A3' and connect it. If successfully, you will hear a clear voice. Turn on the music player on your phone to play music. Music volume can be adjusted with your phone.
5. A USB port on the bottom of the mirror can be used for charging your phone. An extra socket on the back of the mirror can be used for connecting electrical tools, such as hair dryer.
6. After use, please turn off the power switch.

Caution

1. This product is applicable to rated voltage 110-250V, maximum wattage is 500W.
2. Please unplug hair dryer or other high-power electrical appliance immediately after use so that possible accident as a result of overheat and long time working caused by forgotten carelessness can be avoided.
3. In case of smoke or fire, please don't pull the plug with hand if the cause of smoke or fire is unidentified. Power supply must be cut off by using insulator to unplug the product and then ask professional technician for help.

Please contact vendor in time if you have any questions regarding the use of the product. Thanks for your cooperation!

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.