

Tracker 3.0 Instructions

1.1 Appearance diagram



Key Description:

- 1. On /Off key: in the off state, press this key to start the machine normally; in the on state, short press to enter or exit the sleep mode, long press this key will give a prompt whether to shut down or not, if long press the power key for more than 10 seconds, the machine will shut down automatically.
- 2. Volume adjustment key: press left to decrease the volume and right to increase the volume.

1. 2 Interface diagram




Interface specification:


- (1) COM:Can be connected toCOM peripherals.
- (2) HDMI OUT:HD signal transmission to peripherals.
- (3) USB *4 :Can be connected to USB peripherals, such as USB mouse, USB scanner and other peripherals with USB.
- (4) Micro SD:Can be plugged in the micro SD card and play

- the content stored in it.
- (5) LAN:Can connect to the Internet.
- (6) DC:Input power supply.

1.3 Connection of Electronic balance and Tracker (as shown in the figure below)



COM Cable: as follows



Can be connected the Tracker and the Electronic balance by the COM cable, and then the Electronic balance will transfer the weight data to Tracker. At this time, the Tracker will calculate through the corresponding app application software, and display in the corresponding form in the Tracker.

Through the application and calculation of the Tracker app, the wasted food can be classified, summarized and displayed.



1.4 Product Specification

Product Specification Table	
Product name	Track 3.0
LCM	13.3inch, 1920×1080 IPS
Architecture	Dual Core Cortex-A72+Quad Core Cortex-A53
System	Android 9.0
DDR	2GB
Main frequency	Up to 2GHz
EMMC	8GB
Wifi/BT	WiFi,2.4G+5G
TouchScreen	10Point G+G
USB2.0	Support external mouse, USB flash disk, etc
Input	12V/3A
Temperature	Operation Temperature: 0~50°C; Storage Temperature: -10~50C°
Size	217.5mm×327mm×26mm
Others	Support multiple audio and video formats

1.5 Standard list

Please check whether the main engine and accessories are complete after purchasing the product.

Number	Name	Quantity	Unit	Remarks
1	Tracker	1	Set	
2	Instructions	1	PCS	
3	Power Input	1	PCS	
4	Product certificate	1	Sheet	
5	Warranty card	1	Sheet	

Note: if consumers use power adapter for power supply, they should purchase a power adapter that meets the requirements of corresponding safety standards or a

power adapter that has obtained CE / FCC certification
The accessories are subject to the real object, and are
subject to change without notice.

Matters needing attention

In order to use and store the machine safely and correctly,
please read the precautions carefully first.

1. Users are not allowed to disassemble by themselves.
2. Do not use or store the machine in the environment of
high temperature, high pressure, humidity, strong static
electricity and strong magnetic field.
3. Avoid the machine falling from a high place or being
under too much pressure. Do not use pen, ball point pen,
pencil and other sharp objects to contact the LCD screen,
so as to avoid damage to the screen.
4. When the screen display is blurry and the sound playing
is abnormal, using the machine can not guarantee the
normal use of all functions.
5. The machine has some water-proof functions. In case
of rain or falling into the water accidentally, please do not
start the machine. After drying the machine, attach the
description of the occurrence, and send it to the after-sales
service point in the area for maintenance as soon as
possible.
6. Please do not use the machine in dusty place or throw
or shake it to avoid damaging the parts of the machine.
7. Do not use any highly corrosive liquid to clean the
components of the machine; use soft cleaning cloth and
neutral detergent when cleaning.
8. Please back up all important data separately. Our
company will not be responsible for the loss or damage of
internal data caused by improper operation, unauthorized
maintenance, and inability to use.
9. When upgrading the system, please make sure that the
machine is powered on to avoid the upgrade failure or even
system crash due to low power failure during the upgrade
process.

FCC Caution:

Any Changes or modifications not expressly approved by
the party responsible for compliance could void the user's
authority to operate the equipment.

This device complies with part 15 of the FCC Rules.
Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received,
including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply
with the limits for a Class B digital device, pursuant to part
15 of the FCC Rules. These limits are designed to provide
reasonable protection against harmful interference in a
residential installation. This equipment generates, uses
and can radiate radio frequency energy and, if not installed
and used in accordance with the instructions, may cause
harmful interference to radio communications. However,
there is no guarantee that interference will not occur in a
particular installation. If this equipment does cause harmful
interference to radio or television reception, which can be
determined by turning the equipment off and on, the user
is encouraged to try to correct the interference by one or
more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and
receiver.
- Connect the equipment into an outlet on a circuit different
from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician
for help.

FCC RF Radiation Exposure Statement:

1. This Transmitter must not be co-located or operating
in conjunction with any other antenna or transmitter.
2. This equipment complies with RF radiation exposure
limits set forth for an uncontrolled environment.
This equipment should be installed and operated with a
minimum distance of 0cm between the radiator and your
body.

CE:

- 1.Risk of explosion if battery is replaced by an incorrect type.
Dispose of used batteries according to the instructions.
- 2.Adapter shall be installed near the equipment and shall be
easily accessible.
- 3.The plug considered as disconnect device of adapter.
- 4.The device complies with RF specifications when the
device used at 0m form your body.
- 5.The product shall be connected to a USB interface of
version USB2.0 or higher.
- Hereby, Leanpath,Inc. declares that this product is in
compliance with essential requirements and other relevant
provisions of Directive 2014/53/EU. This product is allowed
to be used in all EU member states.

Frepuency bands	Maximum output power
BT(EIRP)2402-2480 MHz	7.20dBm
BLE(EIRP)2402-2480 MHz	3.04 dBm
2.4G WiFi (EIRP) 2412MHz-2472MHz	17.06dBm
5G WiFi(EIRP) :5150-5250MHz ,5725MHz-5875MHz	18.36dBm

Address:8305 SW Creekside Place, Suite A, Beaverton OR 97008