


# Self-heating bottle

Quick start guide

07.16.20

Model: X-888805500

# Self-heating bottle



# Self-heating bottle

Set up



1) Screw control module into bottom of module firmly but do not overtighten.



2) Fill bottle with liquid and attach drink cap.



3) Place on top of desk charger to keep desired temperature

# Self-heating bottle

## Operating instructions



Long press the C/F Selector for 2 seconds to switch the temperature unit.



Selected temperature unit will illuminate



Use up and down arrows to set the temperature. Press once to increase or decrease by 1 degree, long press to scroll.



If overheating occurs due to lack of liquid, the no water light will illuminate.



When Bluetooth is connected, the Bluetooth icon illuminates.



Short press the brightness button to change the brightness of the display.

**FCC STATEMENT :**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

**Warning:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**RF warning statement:**

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.