

# Camera Remote Shutter

## User Manual

### 1. How to pair the shutter with your device?

Step 1: Turn on switch on the right side and the blue light will flash.

Step 2: Click phone settings and enter into Bluetooth.

Step 3: Start to search devices by Bluetooth until "AB shutter" or "Dayleer" is founded.

Step 4: Connect to AB shutter or Dayleer until it is connected successfully.

Step :Open the camera on your phone and press the button on the Remote to take photos.

### 2. Compatibility

Work with devices with IOS 6.0 and above, Android 4.2 and above.

Such as iPhone 12/12 pro/12 pro max/11/11 pro/11 pro max/X/XR/XS MAX/8/7/6 plus

Samsung Galaxy S20/S10/S9/S8 plus ultra, Note 20 ultra/10/9/8.

HUAWEI Mate or P series and most other Android Phones.

### 3. FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.