

220.00 mm

115.00 mm



## QUICK START GUIDE

Model:G11  
Read this manual carefully before  
operating the Rebeosoi Tablet

### Technical Parameters

Product Name:Tablet PC  
Model:G11  
System:Android™13.0  
Android is a trademark of Google LLC;  
Dimension:W207mm × H122mm × D9.0mm  
Weight:Approximately 528g  
BatteryCapacity:5000mAh


### Packagecontent:

Device  
USB Cable  
USB poweradaptor  
Temperglass(LCDProtector)

### Type-C USB connector

Connect the Type-C USB connector  
to charge the battery with a Type-C USB cable  
Do not plug a Type-C USB cable into your  
device multipurpose jack.Doing so may  
damage the device

### ABOUT THE TABLET



- |   |                  |
|---|------------------|
| 1. front camera                             | 7. flash         |
| 2. USB Type-C<br>(charging & data transfer) | 8.volume+        |
| 3. micro SD                                 | 9. volume-       |
| 4.3.5mm audio jack                          | 10.on/off button |
| 5. touch screen                             | 11.reset         |
| 6. back camera                              | 12. speaker      |
|   | 13. microphone   |


### TURNING ON

Press and hold the power button for a couple of seconds to turn on your tablet.  
You might need to charge the tablet first.



### EXPANDING STORAGE

You can expand your storage space for saving files and installing programs by  
adding microSD card (microSD, microSDHC or microSDXC). The maximum  
supported capacity is 64 GB.



### Accessing more information

To view the full user manual on your device  
launch the Setting app and tap User Manual.  
Visit [www.rebeosoi.com](http://www.rebeosoi.com) to view device  
information, the manual and more.

### Maintaining water and dust resistance

The device may be damaged if water or dust  
enters the device.  
Follow these tips carefully to prevent damage  
to the device and to maintain the water and  
dust resistant performance of the device.  
Do not immerse the device in water deeper  
than 1.5m or keep it submerged for more than  
3 minutes.

Do not expose the device to water moving  
with force.  
Perhaps the device exposed to clean water,  
dry it thoroughly with a clean soft cloth. If the  
device is exposed to other liquid such as  
salt water, ionized water, or alcoholic beverage,  
rinse it with clean water and dry it thoroughly  
with a clean soft cloth. If you do not follow  
these instructions, the device performance and  
appearance may be affected.  
If the device has been immersed in water or  
microphone or speaker is wet, sound may not  
be heard clearly during a call.  
After wiping the device with a dry cloth, dry it  
thoroughly before using it.

Made in PRC

55 mm

220.00 mm

115.00 mm

#### ଠଠଠଠ ଠଠଠଠ

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

The FCC Statement of Exposure to RF and the SAR limit for the United States (FCC) is 1.6 W/kg average for each gram of tissue. This device was tested for typical operations of use on the body. This device was tested for typical operations 0mm from the body.

55 mm