


MAYTON





AutoPro X

오토프로 X 패키지와 통일성을 위해 X 로고를 중앙에 배치하였으며, 심플한 오토프로 브랜드의 이미지를 담았습니다. 제품의 설명, 연결 방법 및 쉬운 기능 이해를 돕기 위해 가독성이 높은 일러스트 요소를 활용하였습니다.

project	건명	오토프로 X 영문 설명서
category	종류	설명서
size	규격	660×114mm
colors	색도	Black 1도
page	면수	12면
paper	지질	스노우지 100g 백색
bind	제본	-
post-processing	후가공	코너라운드 5mm / 접지
file	파일명	240328_AutoProX_Menual(En).ai
담당자	크리에이티브 본부 - 양혜선 디자이너	

※ 임의로 판단하여 수정 및 적용하는 것을 절대 금지합니다.
※ 파일에 이상이 있거나 적용이 어려운 부분이 있을 경우,
디자인 담당자에게 문의 부탁드립니다.

About product



Online detailed manual

This user guide was published to provide instructions on connecting to the AutoPro X and performing basic operations. For more details, please refer to the online manual.


Some of the devices and functions contained in this user guide may vary depending on the type and manufacturer's policies of the vehicle and mobile operating system policies.

Warning

- 1 Do not operate the product when driving for safety.
- 2 No warranty can be granted for the product if it is damaged after it is arbitrarily disassembled.
- 3 Please use the product when the voltage of the port is stable.
- 4 This product works normally within the temperature range of -20°C to 70°C. Do not expose the product to excessively high or low temperatures for safety.
- 5 Please thoroughly read and comply with the precautions in the user guide.


How to connect Android Auto mode

- 1 Connect the Mayton AutoPro X to the communication port in the car(USB or C-Type).




- 2 Select the Android Auto mode on the left when AutoPro X displays the initial screen.

1 If you have moved to the initial screen during use, you can re-enter when selecting Android Auto.



- 3 Activate Wi-Fi and Bluetooth on your smartphone, and connect AutoProX_0000 in Bluetooth settings.


1 When the Bluetooth connection is completed, Wi-Fi will be connected automatically. Do not disable Wi-Fi.



How to connect AutoPro X mode


Connect to Android Auto mode first when you first connect for your smooth use.

- 1 Connect the Mayton AutoPro X to the communication port in the car(USB or C-Type).



- 2 Select the AutoPro X mode on the right when AutoPro X displays the initial screen.

1 If you select AutoPro X mode, the connection to Android Auto will be terminated.



- 3 Run Samsung DeX on your smartphone.


Settings → Connected devices → Samsung DeX

2. How to run on the notification panel


Swipe down notification panel
→ Select the DeX icon in the quick panel

3. How to run with Bixby

Call Bixby → Say "Run DeX"



- 4 Please select and connect AutoProX_0000 in the 'Connect wirelessly' list.



Frequently asked questions


- 1 Press OK when you confirm the message when AutoPro X mode is running. It is a message related to screen proportion and does not affect your product usage.
- 2 AutoPro X mode does not connect automatically. It needs to run DeX on the smartphone to connect. (Please refer to various methods to run DeX / No.3 from 'How to connect AutoPro X mode')
- 3 The Bluetooth in the car is disconnected after calling in AutoPro X mode. Please connect the Android Auto Mode once.
- 4 If you use any app that are not compatible with AutoPro X mode, your normal operation may be restricted. If you have installed any app that conflicts with the vehicle's function to cast to the screen or installed the app with unknown APK source files, your normal operation may be restricted.
- 5 I cannot use Samsung Pay function when using AutoPro X mode. Please turn off AutoPro X mode to use Samsung Pay.

NOTE
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

AutoPro X

Model name AutoPro-X
Bluetooth 5.2
Dimension 70.3 × 70.3 × 11.5mm
Material ABS, Silicon, Aluminium
Manufacturer SUZ-HOU MEYITE AUTO PARTS CO., LTD
Import sales MAYTON

Wi-Fi 5Ghz
Color White
Weight 51.9g
Power input 5V/1A



MAYTON


4F, 404, Annam-ro, Bupyeong-gu, Incheon, Republic of Korea

How to operate Android Auto mode

- 1 Use the touchscreen

You can control Android Auto using the touchscreen of the navigation device.

1 If the vehicle does not support a touchscreen, it can be controlled with a jog dial.




- 2 How to set up the app to display

You can select and modify the apps for your vehicle Android Auto in the Customize launcher.

Settings → Connected devices
→ Android Auto → Customize launcher

1 Apps that are not supported by Android Auto do not appear. For more information, please refer to the Android Auto webpage.



- 3 Voice support service

Google assistant voice support is available with the "OK, google" voice call or the steering wheel remote controller button.

Call my friend How's the weather today?




How to operate AutoPro X mode

- 1 Use the touchscreen

You can use the navigation device as your touchscreen, like a tablet PC. If the app is displayed too small, you can adjust it using the following methods.

Settings → Samsung DeX settings
→ Font size and screen zoom


1 You can control it via the smartphone touchpad if the vehicle does not support touchscreens.



- 2 Smartphone touchpad

You can move and click bigger than your laptop and type text when you choose the touchpad icon on your smartphone screen. If you select the navigation device's search box and message window, the keyboard will appear on your smartphone.

1 If the keyboard is not displayed, pressing the keyboard icon in the Quick Toolbar will show the keyboard.




- 3 Connect external devices via Bluetooth

You can connect external devices via Bluetooth, such as a keyboard and a joystick.

You can use external devices in the navigation device if you switch to Touchpad mode after connecting external devices via your smartphone's Bluetooth connection.


1 Please note that the device will work on the smartphone screen if the touchpad mode is not turned on.



- 4 Voice support service


You can get voice support from Bixby by calling "Hey, Bixby."

Send a txt to my friend Play Netflix



- 5 How to adjust AutoProX screen size


You can choose the default or full-screen modes on the AutoPro X screen.




- 6 How to set up a 5:5 split-screen

You can use the screen split button to divide two app screens into split screens quickly.


- 1 Run the two apps you want to split.
- 2 Activate(touch) the app you want to place on the left and then press the device's shortcut button.
- 3 The split screen setting is completed when you select the other app in addition to the app you place during 2 on the left side to the right.




About product



AutoPro X



C to C cable




A to C cable



Online detailed manual

This user guide was published to provide instructions on connecting to the AutoPro X and performing basic operations. For more details, please refer to the online manual.

Some of the devices and functions contained in this user guide may vary depending on the type and manufacturer's policies of the vehicle and mobile operating system policies.




Warning

- ① **Do not operate the product when driving for safety.**
- ② No warranty can be granted for the product if it is damaged after it is arbitrarily disassembled.
- ③ Please use the product when the voltage of the port is stable.
- ④ This product works normally within the temperature range of -20°C to 70°C .
Do not expose the product to excessively high or low temperatures for safety.
- ⑤ Please thoroughly read and comply with the precautions in the user guide.


How to connect Android Auto mode

- 1 Connect the Mayton AutoPro X to the communication port in the car(USB or C-Type).




- 2 Select the Android Auto mode on the left when AutoPro X displays the initial screen.

! If you have moved to the initial screen during use, you can re-enter when selecting Android Auto.



- 3 Activate Wi-Fi and Bluetooth on your smartphone, and connect AutoProX_0000 in Bluetooth settings.


! When the Bluetooth connection is completed, Wi-Fi will be connected automatically. Do not disable Wi-Fi.



How to connect AutoPro X mode

Connect to Android Auto mode first when you first connect for your smooth use.

- 1 Connect the Mayton AutoPro X to the communication port in the car(USB or C-Type).



Comm port




Charging port

- 2 Select the AutoPro X mode on the right when AutoPro X displays the initial screen.



If you select AutoPro X mode, the connection to Android Auto will be terminated.



3 Run Samsung DeX on your smartphone.

1. How to run in Settings


Settings → Connected devices → Samsung DeX

2. How to run on the notification panel

Swipe down notification panel
→ Select the DeX icon in the quick panel

3. How to run with Bixby

Call Bixby → Say "Run DeX"



4 Please select and connect AutoProX_0000 in the 'Connect wirelessly' list.

Connect wirelessly

Select the device you want to connect to from list.

 **AutoProX_0000**



Frequently asked questions

- ① Press OK when you confirm the message when AutoPro X mode is running.**
It is a message related to screen proportion and does not affect your product usage.
- ② AutoPro X mode does not connect automatically.**
It needs to run DeX on the smartphone to connect.
(Please refer to various methods to run DeX / No.3 from 'How to connect AuroPro X mode')
- ③ The Bluetooth in the car is disconnected after calling in AutoPro X mode.**
Please connect the Android Auto Mode once.
- ④ If you use any app that are not compatible with AutoPro X mode, your normal operation may be restricted.**
If you have installed any app that conflicts with the vehicle's function to cast to the screen or installed the app with unknown APK source files, your normal operation may be restricted.
- ⑤ I cannot use Samsung Pay function when using AutoPro X mode.**
Please turn off AutoPro X mode to use Samsung Pay.

NOTE

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

AutoPro X

Model name AutoPro-X

Bluetooth 5.2

Dimension 70.3 × 70.3 × 11.5mm

Material ABS, Silicon, Aluminium

Manufacturer SUZHOU MEIYITE AUTO PARTS CO., LTD

Import sales MAYTON

Wi-Fi 5Ghz

Color White

Weight 51.9g

Power input 5V/1A



KC Certificat
R-R-m3t-AUTOPROX



FCC Certificat
2BAG8-AUTOPROX

MAYTON


4F, 404, Annam-ro, Bupyeong-gu,
Incheon, Republic of Korea

How to operate Android Auto mode

1 Use the touchscreen

You can control Android Auto using the touchscreen of the navigation device.

! If the vehicle does not support a touchscreen, it can be controlled with a jog dial.




2 How to set up the app to display

You can select and modify the apps for your vehicle Android Auto in the Customize launcher.

Settings → Connected devices
→ Android Auto → Customize launcher

! Apps that are not supported by Android Auto do not appear.
For more information, please refer to the Android Auto webpage.



3 Voice support service

Google assistant voice support is available with the "OK, google" voice call or the steering wheel remote controller button.

Call my friend

How's the weather today?



How to operate AutoPro X mode


1 Use the touchscreen

You can use the navigation device as your touchscreen, like a tablet PC.


If the app is displayed too small, you can adjust it using the following methods.

Settings → Samsung DeX settings
→ Font size and screen zoom

! You can control it via the smartphone touchpad if the vehicle does not support touchscreens.




2 Smartphone touchpad

You can move and click bigger than your laptop and type text when you choose the touchpad icon  on your smartphone screen.

If you select the navigation device's search box and message window, the keyboard will appear on your smartphone.

! If the keyboard is not displayed, pressing the keyboard icon  in the Quick Toolbar will show the keyboard.



3 Connect external devices via Bluetooth

You can connect external devices via Bluetooth, such as a keyboard and a joystick.

You can use external devices in the navigation device if you switch to Touchpad mode after connecting external devices via your smartphone's Bluetooth connection.

! Please note that the device will work on the smart phone screen if the touchpad mode is not turned on.




4 Voice support service

You can get voice support from Bixby by calling "Hey, Bixby."


Send a txt to my friend

Play Netflix



5 How to adjust AutoProX screen size


You can choose the default or full-screen modes on the AutoPro X screen.



6 How to set up a 5:5 split-screen

You can use the screen split button to divide two app screens into split screens quickly.

- ① Run the two apps you want to split.
- ② Activate(touch) the app you want to place on the left and then press the device's shortcut button.
- ③ The split screen setting is completed when you select the other app in addition to the app you place during ② on the left side to the right.





AutoPro X

User manual