



HOW TO USE

- 1. Start: long press switch (1) 2s, go to standby mode.
- 2. Shut down: Long button (1) 2s shutdown.
- 3.Standby Mode: Click on the button to enter inhalation mode, Click on the frequency switching again, a total of 4 frequency adjustable.

USING WITH REMOTE CONTROL

- 1.Standby Mode: Click on the button to enter vibration mode, Click on the frequency switching again, a total of 10 frequency adjustable, Long Press 2 seconds to stop work.
- 2.Standby Mode: Click on the 1 button to enter inhalation mode, Click on the frequency switching again, a total of 4 frequency adjustable, Long Press 2 seconds to stop work.

SPECIFICATION

Product Material: Silicone+ABS Waterproof property: IPX5

Functional Pattern 10 Frequency vibration / 4 Frequency sucking

Power Supply Mode: USB Charging

Battery capacity: 260amh

Charging Time: About 90 minutes

Battery Discharge Time: About 60 minutes

Product Size: 3.41" x 1.74" x 1.74" / 86.50 x 44 x 44.20mm

ATTENTION

- 1. The product is charged with USB cable.
- 2. Please charge it with matching charger.
- 3. When charging switch button LED lights start flashing, massager charging began.
- 4. When fully charged, The on-off button LED is on constantly.
- 5. The massager is fully charged for approximately 60 minutesof pleasure.

ATTENTION 1

- Before using this product, please charge the product and do a good job of hygienic cleaning.
- 2. When charging this product, it is forbidden to use the product.

BEFORE USING

- 1.Please kindly read the manual before using this product.
- 2.Fully charged before the first use, Wash with body wash or soap.
- 3.Please keep the product in a clean place.Don't use any corrosive detergent.
- 4.Please keep the product out of the reach of children.
- 5. This product is prohibited for minors under the age of 18.
- Check the equipment for damage before or after use and do not use the equipment if damage is found.
- If you experience some discomfort while using the device, please stop using the device immediately.

PACKING LIST

Massager * 1, User's Manual * 1, Charging Cable * 1,Remote Control * 1.

ATTENTION **(**

- This product has a built-in polymer lithium battery, which cannot be disassembled by itself to avoid damage to the product.
- 2. After the use of this product, it should be placed in a dry and ventilated place to avoid direct sunlight.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Regrient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.