



Bluetooth key: Long press the Bluetooth key to switch on and off Bluetooth function. Short press to pause/play during Bluetooth playback

Bulb button: Short press to turn on the light, default to white. During work, short press to change color, white → warmColor → natural color; Long press to adjust brightness.

Magnifier: equipped with 5X magnifying glass

Bracket: Adjustable bracket, wall mounted

LED MAKEUP MIRROR WITH BLUETOOTH

High Quality Cosmetic Mirror



LONG-LASTING
DAYLIGHT LED
LIGHTING

BLUETOOTH
SPEAKERS

USB RECHARGEABLE

CATCHALL
STORAGE

5X MAGNIFYING
MIRROR

Charging the mirror before receiving it
will have a better effect!

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.