

Caregiver Pager User Manuals

How To Register SHORT RING

The ring will stop automatically after two consecutive reminders.

1. After selecting the ring tone what you need by   key, hold down the  volume key for about 3 secs until red light quickly flash.
2. Then press a transmitter to register, a ding-dong sound that means the registration is successful, then automatically exit to standby. Or no action within 6 secs after registering, it will automatically exit to standby.

Provided that the transmitter is registered :

-In standby, you can adjust the ring tone by pressing the   key;

-If you press the   key, the current ring tone will be overwritten and updated to the new one, regardless of whether the transmitter is pressed or not.

How To Register LONG RING

The ring will keep cycling unless the call is cancelled manually.

1. After selecting the ring tone what you need by   key, hold down the  volume key for about 3 secs until red light quickly flash. Continue to press and hold until the red light turns into a slow flashing state.
2. Then press a transmitter to register, a ding-dong sound that means the registration is successful, then automatically exit to standby. Or no action within 6 secs after registering, it will automatically exit to standby.

Note: You can press   and  volume key to stop the call. In standby, you can adjust the volume but can not select the ring tone.

4 levels adjustable volume, no mute mode.

Restore Factory Settings

Hold down the  volume key for about 10 secs until the red light is long, indicating that the factory settings have been successfully restored.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.