



Tik Tok Video & Music Remote Controller Scrolling Ring

User's Manual Model: D02

1

Packing List



Charging Case Scrolling Ring



Charging Cable User's Manual

2

Power on / off




power button

Power on :
Press and hold on the power button for 1 second the red and blue lights flash alternately

Power off :
Press and hold on the power button for 5 second The red light keep on for 2 second and then goes off when the ring power on

3


Connect the cell phone



First Connection
The ring automatically enters the pairing state when it is power on. At the same time please turn on the Bluetooth switch of your phone, then search for **D02** in the Bluetooth list and click to connect
If you can't find the BT name Please turn off the BT switch and turn on again to reserach Automatic Connection
The ring automatically connect the last connected device after Power on

4


iPhone / iPad Settings



iPhone and iPad need to turn on Assistive touch button before it can be used normally
Please see the below picture

5

iPhone / iPad Settings




Once you're done a dot appears on the screen

Notes:
1. Make sure the IOS software of your device is above 14.8
2. If you still can't control the Tik Tok video after the touch button is turned on Please restart your device

6

Function (video Mode)



Single click : Pause
Double click : Like
Triple click : Continuous like on / off
Press and hold for 1 second to release: Lock / Open screen

Single click : Previous video
Double click : Swipe right
Press and hold :Volume -

Single click : Next video
Double click : Swipe light
Press and hold :Volume +

7

Take Picture / Record Video



In photo or video recording mode on your phone, Press any up or down button for 2seconds to take a photo or recording video and end recording video
Single click the left big button to focus

Notes:
1. just support the original camera and various beauty cameras to take photos and record videos
2. When working Tiktok, long press is the function of volume increase and decrease

8

Switch mode



Press and hold on the two buttons for 1 second at the same time the red and blue lights flash 3times

Notes:
1. The initial mode is Tiktok mode
2. When the ring is turned off , the last mode is saved
3. Page 7 shows how to operate in video mode
4. Page 10 shows how to operate in music mode

9

Function (Music Mode)




Single click : Play / Pause / Answer / hang up call
Double click : Call the last call
Press and hold for 1 second: Refuse the call
Wake up / Undo Siri

Single click : Previous song
Double click : Return to last page
Press and hold :Volume -

Single click : Next song
Double click : Lock or Open screen
Press and hold :Volume +

10

Charging Diagram



Case Charging

Red light flashing Slowly Keep the red light on

Ring Charging (In Case)

Keep the red light on The red light goes out

11

Automatic Shutdown


1.The ring automatically shuts down if it is not paired or if it is not paired again after 5 minutes of disconnection
2. The ring was connected to the phone for 30 minutes without any operation then the ring automatic shutdown

Question Guide

1. **It doesn't work on iPhone and iPad?**
iPhone and iPad need to turn on Assistive touch button before it can be used normally.
2. **How to reset factory Settings?**
Press the power button five times quickly.
3. **It cannot be used with beauty cameras?**
It only work the original camera and some beauty cameras to taking photos and recording videos.

12

Question Guide



4. **iPhone and iPad can't swip up and down normally or can only pause the video after turning on the touch button and reset**

Option 1
Click that the cursor point to in the result of the answer after the ring is connected. If not the result, the solution is to adjust the ring the following figure in the left of right, Press the power button of the ring to confirm every adjustment until the cursor point reaches the middle, then press the power button and make sure that the "Portion Screen Gesture" in the left figure is turned on, and you can begin the video up and down

Option 2
At the following operations in sequence
1. Place of the ring and reset your phone
2. Turn on Assistive touch and appears
3. Turn on the screen
4. Turn on the Bluetooth and connect the ring

13

Specification

The Ring	
Bluetooth Version	V 5.0
Bluetooth Name	D02
Password	0000
Distance	33 feet
Battery Capacity	45 mAh
Input	5V / 40 mA
Charging time	About 1 hour
Charging Case	
Battery Capacity	400 mAh
Input	5V / 300 mA
Charging time	About 2 hours

Email to support
1301547734@qq.com
(we will reply within 24 hours)



14

FCC Safety Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general ID equipment requirement. The device can be used in portable exposure condition without restriction.

15