



Petca R1

Bri-St01





Scan the QR code with your mobile phone and
download the Ebo App






Device Connection


1

Register on Ebo App and click '+' to connect.





2

Select device card for Ebo SE.



3

Place the robot on the charging dock.



* Updates are ongoing and subject to the actual interface of the App






English

4

Choose the Wi-Fi network and put in the Wi-Fi password and click NEXT.





5

Scan the QR code with the robot camera.






6

Connection is successful.
Enjoy your Ebo.



About 15cm apart




Scan the QR code with Ebo's camera until  and  are off, and the pairing is successful.






Interface Instructions



Left/Right

Forward/
Backward



Forward/Backward/
Left/Right



Battery



Exit



Operation
Setting



Take
Photo



Shoot
Video



Mic.



Volumn
On/Off



Run
Forward



Rotating



Shaking




* Updates are ongoing and subject to the actual interface of the App







General instructions



Indicator light
Camera



Mic.
Card slot
SD card
Speaker



Charging contact point
Reset button
Detachablescrew



*Top part of the pin

Power on/off and RESET of Ebo:
Use the top of the pin to press RESET

POWER ON: Press RESET for 2 seconds
(or place the robot on the charging dock)

POWER OFF: Click RESET twice


REBOOT: Click RESET 1 time when Ebo is on

RESET: Press RESET for 5 seconds until you hear 'ebo'


*Lower part of the pin

How to clean the wheels?

Dismount the screws at the bottom with the lower part of the pin to disassemble the wheel set for cleaning




Power socket



Adapter



USB connector



Indicator light
● Red light: Charging
● Green light: Full

Note for charging Ebo:

Place the back side of the charging dock along the wall and free from any obstacles 0.6 meters on right/left and 2 meters in front.





FCC compliance statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This device must operate with a minimum distance of 20 cm between the radiator and user body.

ISED compliance statement

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) L'appareil ne doit pas produire de brouillage;
- (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The device is restricted to indoor use only when operating in the 5150 to 5250MHz frequency range.

L'appareil est limité à une utilisation en intérieur uniquement lorsqu'il fonctionne dans la plage de fréquences de 5 150 à 5 250 MHz.

ISED Radiation Exposure statement

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the radiator and your body.

Cet équipement est conforme aux limites d'exposition aux radiations IC CNR-102 établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec une distance minimale de 20 cm entre le radiateur et votre corps.

