

Musical boxing pro

YXB008



Please read the instruction before using

Technical Data:

Input: DC 5V Power: 5W Working Voltage: 5V


Size: 45*45*4.5 cm N.W./G.W.: 2.0 kg/2.5kg

Battery: 2000mA


Bluetooth Name: HOMEASY-006

Charging:

Use the mobile phone charger (5V/1A-2A) to charge via the attached cable link. Mounting Boxing Pro should be considered close to the wall socket position



Three ways of installation




A. Peel off the white film behind the black adhesive tape and stick to the wall.


Operation:



1. -----Long press the "On/Off" button for 2 seconds to switch the machine on and off. After no key operation or strike for one minute, the boxing light switches to the music flashlight mode, the key operation or strike automatically exits, if the Bluetooth is not connected, it will automatically shut down after three minutes.
2. Background Audio: Double-click the "On/Off" button, and the display shows "ON" to turn the audio on, and the display shows "OFF" to turn the audio off.
3. The Bluetooth is in standby mode for Bluetooth connection when the machine is powered on. Bluetooth Name: HOMEASY-006
4. -----Press the "Mode" key to switch modes, P01-P09 cycle switch. P01 is random mode, and P02-P09 is preset sequence.
Long press the "Mode" key to increase the volume.
5. -----Speed & Sensitivity: Press the "Speed" key to switch between the preset fixed speeds (H01-H06) or the variable speed sensitivity (HA1-HA3). Long press the "Speed" key to decrease the volume.
6. Count: Display 000-999.



B. Peel off the rectangle area on back white film and stick the short Velcro hook, and stick the long Velcro loop on the wall. Stick the hook and loop together.



C. Fix it with the screw and the stator.

Caution:

1. Don't use it within 30 minutes after a meal.
2. It should not be used during pregnancy or menstruation.
3. It is forbidden to wash, but can be wiped with a rag.
4. It should be charged when it powers off automatically. It should be charged every 15 days.



FCC Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC RF Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.