

AirBell
Safe and sound.
www.airbell.se
Närskommunikation
för barn och vuxna
i skolor och
hemma.
Designad i Sverige.
Made in China.

AirBell® Pro

3V Lithium Battery

CE FCC RoHS

Works with
Apple Find My



Scannen mich für die Anleitung!
Scann mich für instructions!

DE Scannen Sie das QR Code, um zu Betriebsanleitung auf der Seite www.artbot.de/pages/guides zu gelangen.

EN Scan the QR code to access the instructions on www.artbot.de/pages/guides

Inhaltsangabe		Seitenzahl
1	Inhaltsabnahme	S. 6
2	Baustelleneinrichtung	S. 17
3	Funktionen der Arbeit	S. 13
4	Gerätemanager einrichten	S. 13
5	Verpackungen	S. 15
6	Eingangsdaten	S. 15
7	Technische Spezifikationen	S. 16
8	Kompatibilität	S. 17
9	Prozessplan	S. 17
10	Umwelt	S. 18
11	Werkzeuge	S. 18
12	Rechtliches	S. 19
13	Glossar	S. 19
14	Konformitätsklärung	S. 20
15	Kontakt	S. 21

[illegible]

4 Montage

Zur Montage der Aflöser an Ihrem Fahrradlenker benötigen Sie einen **Neuenschäutlenkerbolzen**.



Um die Aflöser in Ihrem Lenker zu befestigen, bringen Sie sie in die **gewünschte Position** und ziehen Sie die **Schraube** fest.

5 Klöppel ausrichten

Um **höheren Komfort** zu gewährleisten, sollten Sie die **Mittellinie**, die **Ausrichtung** des Klöppels **individuell** anpassen.



Etwas **helfen** Sie zunächst die **Schritte** zum **Einbauverfahren** in der **Kapitel 4** auf Seite 11 zur **Anleitung** und **erweitern** Sie die **Grundlage der Aflöser**. Danach können Sie **nach Belieben**, an dem die **Klöppel** **befestigt** ist, **abwärtend** und **nach hinten** **Bachschrauben** ziehen. Sie müssen die **Aflöser** **dazu** nicht vom **Lenker** entfernen.



Der Klöppel kann um **360°** gedreht werden.

Die Befestigung des Klappbretts erfolgt über einen kleinen Haken, der im Unterteil der Arbell erscheint.

Halten Sie beim Zusammenbau das Klappbrett fest und drücken Sie ihn nach unten, bis das Haken eingeklinkt ist (2).

Anschließend schrauben Sie die Arbell wieder zusammen.

Um die Arbell sicher zu verstellen, klicken Sie den Klappgriff während der ersten vollen Umdrehung des Handrads nach unten, bis das Oberteil fest sitzt.

2. Batteriewechsel

Die Arbell wird aus dem CH2023 Klapptable betrieben, die sich unter dem Klappgriff befindet.

Der Mechanismus zum Öffnen der Arbell (bzw. dem Sicherheitsverschluss von Fräsech und Mechaniewerkzeugen).



Drücken Sie den Klingelgriff nach unten und drücken Sie ihn langsam entgegen des Uhrzeigersinns zurück, bis er in die Position der Klingel zurückfällt.

Halten Sie den Klingelgriff fest und drücken Sie den Klingelgriff nach unten und drücken Sie ihn langsam entgegen des Uhrzeigersinns zurück, bis er in die Position der Klingel zurückfällt.

Legen Sie das Oberblech zur Seite. Die Batterie kann problemlos durch das Drücken oder der Schraube aus der Oberfl. entfernt werden. Beachten Sie beim Einsetzen der neuen Batterie, dass die Polung richtig ist. Die Batterie sollte nicht mehr verwendet werden, wenn das Symbol für eine schwache Batterie erscheint. Wenn das Symbol für eine schwache Batterie erscheint, sollten die Klingelgriffe und angeschlossenen Klingelgeräte nicht angeschlossen werden.



3. Funktionen der AirBell

Die AirBell ist auf drei Geräten über das First-Mat Netzwerk von Aqua verbunden und bietet dabei folgende Funktionen:

- Positionierungsmöglichkeit via Karten in der Find My App
- Wasserleak-Timer
- Status der Position der AirBell
- Verriegeln von Türen
- Anzeige der Sensoren

4. Seriennummern einsehen

Die Seriennummer der AirBell können Sie sich am Drop unter der Batterie ablesen. Bitte beachten Sie, dass die Seriennummer der AirBell nicht mit der Seriennummer der Aqua-Druckpumpe übereinstimmt. Die Seriennummer der Aqua-Druckpumpe ist auf dem Gehäuse der Aqua-Druckpumpe angegeben. Die Seriennummer der Aqua-Druckpumpe ist auf dem Gehäuse der Aqua-Druckpumpe angegeben. Die Seriennummer der Aqua-Druckpumpe ist auf dem Gehäuse der Aqua-Druckpumpe angegeben.



5. Auf Werkseinstellungen zurücksetzen

Um die Arbeit auf Werkseinstellungen zurückzusetzen, zirkulieren Sie bitte diese Schritte:

1. Trennen Sie zunächst die Antenne von Ihrem Cloud-Controller, indem Sie die Antenne eingeschachtelt ist. Drücken Sie auf die Taste **1** (Antenne) zweimal hintereinander. Während die Antenne dreimal aufleuchtet, stoppen Sie sofort nach dem ersten auf den Knopf und halten Sie ihn drei Sekunden gedrückt.
2. Nach etwa 5 Sekunden hören Sie ein charakteristisches Piepen. Halten Sie den Knopf weiterhin gedrückt.
3. Nach weiteren 5 Sekunden spricht die Antenne eine Melodie. Halten Sie den Knopf los.

Die Antenne ist jetzt auf Werkseinstellungen zurückgesetzt.

6. Eingabeoptionen

#	Funktion	Knopfdruck	Ton
1	Einsetzen	5 Sekunden gedrückt	3 aufeinanderfolgende Piepen
2	Auswählen	5 mal hintereinander drücken	3 absteigende Piepen
3	Status Antenne	2 mal hintereinander drücken	3 kurze Piepen, wenn die Antenne eingeschachtelt ist, oder einen Piep, wenn die Antenne ausgeschachtelt ist
4	Antenne	3 Sekunden gedrückt	3 kurze Piepen
5	Zurücksetzen	Siehe Kapitel 4	

7. Technische Spezifikationen	8. Kompatibilität
Batterie Lithium-Ionen-Chemie CR2032 Kapazität 225 mAh	Die Airtel Pro funktioniert ausschließlich mit dem First My Netzwerk von Airtel.
Dimensionen (L x B x T) 49,5 x 35,2 x 10,5 mm	Um die Airtel Pro mit der First My App zu steuern, ist eine Internet-Verbindung erforderlich.
Kommunikation Bluetooth	Die Airtel Pro ist kompatibel mit allen Android- und iOS-Smartphones.
Antenne 2400 MHz	Die Airtel Pro wird von der First My App gesteuert.
Leistung 2400 MHz bis 2483,5 MHz	9. Privatsphäre Die Airtel Pro nutzt das Airtel First My Netzwerk mit
Anforderungen < 2,5 mW	Bluetooth-Technologie. Ihr Smartphone muss Airtel®-Konten und die Funktion Ihrer Airtel Pro unterstützen.
Lautsprecher Ergonomisches Design 140 dB	10. Umwelt Die Airtel Pro enthält eine Batterie und elektrische
Sensor Beschleunigungssensor	Komponenten und sollte nicht im Hausabfall oder in
Temperaturbereich 0°C bis +40°C	einem Recycling-Container entsorgt werden. Bitte entsorgen Sie die Airtel Pro
Größe/Gewicht 140 x 65 x 10 mm 22,5 g	nach den dafür vorgesehenen Anweisungen.

[illegible]

14. Konfliktlöseklärung

Dieses Produkt entspricht den CE und FCC-Richtlinien. Es erfüllt die CE und FCC-Richtlinien des Industriestandard-Zustands für handelsübliche Röhren (Richtlinie für das Prozessdesign). Die Verwendung ist unterhalb des folgenden Zeit-Bedingungs:

- Diese Geräte auf keine elektrische Interferenzen verursachen.
- Diese Geräte muss jegliche organisierten Interferenz ausschließen, einschließlich solcher, die unvorsichtige Funktion verursachen kann.

Die entsprechende Konfliktlöseklärung ist verfügbar unter: www.artel.de/press/inquiry

15. Kontakt

Sollten Sie Fragen oder Probleme mit Ihrer Artikel haben, können Sie weitere Informationen auf unserer Website unter:

www.artel.de/press/faq finden oder unsere Artikelnummer:

www.artel.de/pages/contact

FAQ

	Contents	
1	AirBell Setup	p. 14
2	Changing the Battery	p. 19
2	AirBell Features	p. 31
4	Serial Number Lookup	p. 31
5	Factory Reset	p. 32
6	Button Functions	p. 33
7	Technical Specifications	p. 34
8	Compatibility	p. 35
9	Privacy	p. 35
10	Environment	p. 35
11	Legal	p. 36
12	Warranty	p. 36
13	Warnings	p. 37
14	Declaration of Conformity	p. 38
15	Contact	p. 39

1. **AirBell Setup**
 - ➊ Remove the plastic strip by pulling it in the direction indicated by the arrow.
2. **Locate the buttons on the bottom of the AirBell.**
Press the button for at least 3 seconds.
(When the AirBell emits a sound [recording melody] it is turned on.)
3. **Connect to Find My**
To use the AirBell to add location on, double-click the button for a status app. The AirBell emits three ascending beeps, it indicates that it is turned on.
 - ➊ Open the Find My App on your Apple device.
 - ➋ In the bottom right corner, tap on the blue "+" symbol.
 - ➌ From the menu, select "Add Other Item."
 - ➍ Once the AirBell appears on the screen, tap on "Connect."


You can now customize the name of your AirBell and tap "Confirm." Follow the on-screen instructions to proceed.

If you double click once to check the status, you should hear a sounding sound. This indicates that the AirBell is connected to the Find My network and is operational.

- 4 Mounting the AirBell on your Bike**



To mount the AirBell on your handlebar, you need a screw that fits snugly. Simply insert the screw and slide the AirBell onto your handlebar.
- 5 Trigger Positioning**



For optimal comfort, you can adjust the trigger position. Please refer to the instructions outlined in the second chapter on page 28 to detach the top of the AirBell. Once the top is removed, you can adjust the position of the ring against the trigger in manual according to your preference. Please refer to the instructions to determine the ideal position for the AirBell on your bike's handlebar before adjusting the trigger accordingly. The trigger can be rotated 360°.

The ring on which the trigger is attached, located in the middle of the handle, must be pulled out to hold it in place.


For a secure attachment, press the ring onto the AxiAir with the protrusion's side first (1), then push the ring down (2). The protrusion must be inserted in the same manner it was disassembled.

To ensure a proper fit, engage the crown's mechanism and press it down firmly for the final quarter turn to lock it in security.

2. Changing the Battery

The AxiAir contains a CR2032 coin cell battery which is located in a compartment between the handle and the trigger.

The opening mechanism is similar to that of a security bottle cap.



28

To open the AirFit, press down on the dome and slowly turn it counter-clockwise until the dome catches, and then the dome catches, continue to turn the dome counter-clockwise until the top completely separates from the bottom.

To effectively remove and replace the battery, simply press on the battery just above the screen. Ensure that the terminal is connected properly before insertion.

After the battery is inserted, the device will power on. If you disconnected it, the same will happen. To power off, simply press down on the dome for the best gesture turn.



3. AirFit Features

The AirFit leverages Apple's Find My network, offering the following benefits:

- Map and Location via the Find My App
- Sound playback
- Location sharing for your AirFit
- "Lost Mode"
- Serial Number Lookup

4. Serial Number Lookup

The serial number of the AirFit is located on the PCB.

Alternatively, you can also access the serial number of the AirFit by using the Find My app. To do this, open the app on the AirFit, press the button on the bottom of the device (the one with a lock icon) and then click on "Serial". Once activated, you can view the serial number in the Find My app.



30

31

5. Factory Reset

To reset the AirTel to its factory settings, please follow the steps below:

- 1 First delete the AirTel from your Cloud Account using the **Remove Air Tel** button.
- 2 Then press the power button on the start of the AirTel to power on the button while the AirTel is powered on. Upon successful power on, you will see the AirTel logo on the screen and continue pressing it.
- 3 After about 1 second, you will hear a series of three beeps. Continue pressing the button.
- 4 After about 1 second, you will hear a series of three beeps. Release the button and the AirTel will be successfully reset.

6. Function Buttons

#	Function	Button Action	Sound
1	Power On	Press for 5 seconds	Ascending Buzzer
2	Power Off	Press 5 times in succession	Descending Buzzer
3	Request Status	Double-click	3 short beeps
4	Request Setup	Long Press	1 beep sound for 4 sec and 4 beeps connected
5	Request Lockup Mode	Power for 2 seconds	3 short beeps
6	Reset	See Chapter 4	

7. Technical Specifications	
Battery	user-replaceable CR2032 coin cell
Dimensions (inches)	4.9x3.5x0.5
Weight (g)	22mm maximum
Connectivity	
Proximity Finding	Bluetooth
Antenna Frequency	2400 to 2483.5 MHz
Frequency	< 2.5 mW
Power	BAU (in Power > 60 dB)
Speaker	Accelerometer
Sensor	GPS
Temperature Range	-10°C to +60°C (-14°F to 147°F)
Humidity Range	10% to 90% RH
Ball volume	> 85 cc

[illegible]

14. Declaration of Compliance (DoC)

This product conforms to CE and FCC regulations. It complies with Part 15 of the FCC Rules and with Industry Canada's license-exempt RSS (standards). Operation is subject to the following conditions:

- This device must not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

The relevant DoC is available at:
www.arbnet.de/pages/regulatory

15. Contact

For any inquiries or claims regarding this product, please refer to our website for detailed information:

www.arbnet.de/pages/faq or
email: info@arbnet.de

www.arbnet.de/pages/contact

31

32

33

34

35

37

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.