

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction


## Wireless Microphone S10 User Manual




### Introduction

Thanks for choosing our product. This product is a smart wireless microphone that provides professional audio recording output. Plug and play, no app required. Multiple uses, it can be used in online live broadcast, video Vlog shooting, program interview, recording, video teaching and other occasions.

This product consists of three parts: charging box, microphone transmitter and receiver (as shown in the figure below, some models have no charging box, based on the actual object)




### ID Diagram



### How to use

Step 1: Long press the power button on the microphone, and the connection indicator light will flash, indicating successful power on.  
 Step 2: Connect one end of the receiving end to the phone interface.  
 Step 3: The indicator light for the connection between the receiver and transmitter remains on, indicating a successful connection. Open the camera live streaming app on your phone and use the microphone to listen.



### About UI

#### Microphone Transmitter

Function	Button	LED
Power on	Long press 2s the power button	The connection light flashes slowly, and the blue indicator light on the microphone is on.
Shut down	Long press 2s the power button	All lights off
Noise reduction	Click function key	On the noise reduction light is always on.
Mute	Double click function key	On the mute light is always on.
Reverberation	Triple-click the function key	On the noise reduction light flashes slowly.
Photograph	Double click the power button	On the noise reduction light is always on.
Charge		The charge light is always on, and the light indicator light is always on.
Low battery		Charging light flashes

#### Receiver

Function	Operate	LED
Power on		Blue light flashing
Search pairing		Unpaired: slow flashing; Paired: light always on

### Packing List

Content of packing
(1) Microphone transmitter
(2) Receiver
(3) Charging box
(4) Charging cable
(5) User manual