


蓝牙音乐枕
使用说明书

蓝牙规格参数

蓝牙名称	miniBand
蓝牙版本	5.3及以上
充电电源	DC5V/0.5A
充电接口	Type-C
电 池	3.7V/250mAh
电池类型	聚合物锂离子电池
充电时间	约2小时
连续播放	>10小时

嘉兴市佳宏电源科技有限公司
地址：浙江省嘉兴市秀洲区加创路1238号
电话：0573-82790789

控制面板说明




使用方法

蓝 牙 配 对：打开设备蓝牙，连接“miniBand”蓝牙。
配对成功有提示音，蓝灯亮一秒后熄灭，若无连接，蓝灯8分钟后关闭。
充 电 方 法：将USB充电线接口插入蓝牙接口。
充电时，红灯常亮，充电完毕，蓝灯常亮。

- ① 开 机 & 关 机：长按开关机。持续语音“power ON”或“power OFF”。
- 音乐播放&暂停：单击播放或暂停。
- 接听&挂断电话：单击接听或挂断。
- 接通时伴提示音“incoming call”。
- 拒 接 电 话：长按两秒拒接。
- 未 号 重 拨：双击重拨。
- + 音 量 增 大：单击增大。
- 播放下一曲：长按播放下一曲。
- 音 量 减 小：单击减小。
- 播放上一曲：长按播放上一曲。

1.取出蓝牙模块


左手抓住U型枕，右手上下抓住蓝牙模块，利用大拇指**顺时针斜向上方**顶出蓝牙模块。



- ① 清洗产品时，需用**暖手**先将蓝牙模块拆除。

2.拆除蓝牙模块


用**暖手**插入红黑端口，外扳使蓝牙模块脱离红黑连接线。拉开拉链，将内胆翻起，外枕套正常洗涤晾晒即可。



- ① 内胆清洗条件：可晾晒 不可水洗

3.安装蓝牙模块

将接线端（胶水颜色），以**红对红，黑对黑**插入蓝牙模块接口。



- ① 外枕套清洗条件：可晾晒 手洗


Bluetooth Music Pillow
User Manual

Bluetooth
Specification Parameters

Bluetooth Name	miniBand
Edition	5.3 and above
Charging supply	DC5V/0.5A
Charging Interface	Type-C
Cell	3.7V/250mAh
Cell Type	Polymer lithium ion
Charging Time	About 2 hours
Endurance	≥10 hours

Made in China

Control Panel Description



Usage Method


Bluetooth Pairing: Turn on device Bluetooth. Connecting “mini-band”. Bluetooth. There is a prompt sound for successful pairing, and the blue light will light up for one second before it goes out. If there is no connection, Bluetooth will turn off after eight minutes.

Charging Method: Insert the USB charging cable port into the Bluetooth interface. When charging, the red light is constantly on. After charging, the blue light remains on.

- ① Power ON & Power OFF: Long press on/off. Accompanied by a prompt sound of “power ON” or “power OFF”.
- Music Playback & Pause: Click on music playback or pause.
- Answer & End calls: Click to answer and end the call. When connected, accompanied by a prompt tone “incoming call”.
- Reject Calls: Long press for two seconds to reject.
- Last redial: Double click redial.
- + Volume up: Click to increase the volume.
- Play Next Song: Long press to play the next song.
- Volume down: Click to decrease the volume.
- Play Previous Song: Long press to play the previous song.

1.Remove The Bluetooth Module


Grasp the U-shaped pillow with the left hand and the Bluetooth module up and down with the right hand. Use your thumb to lift the Bluetooth module **clockwise and diagonally upwards**.



- ① When cleaning the product, it is necessary to use a **wrench** to remove the Bluetooth module.

2.Detaching Bluetooth Module


Insert a wrench into the red and black port, and pull the external wrench to separate the Bluetooth module from the red and black connection cable



- ① Tank Cleaning Conditions: Air Not Washable

3.Installing Bluetooth Module

Insert the terminal (glue color) into the Bluetooth module port in **red to red and black to black**



- ① Pillowcase Cleaning Conditions: Air Hand washing

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.