


RY-1350

ALARON®

HANDS FREE HEADSET WALKIE TALKIE SYSTEM






**Model: RY-1350
OWNER'S MANUAL**

ANOTHER QUALITY PRODUCT BY ALARON

WINATION TECHNOLOGY MFG
FCC ID : N57RY-1350
JOB # : 196AH0
EXHIBIT # : *3A*

DUPLEX HEADSET WALKIE TALKIES



INTRODUCTION

This Duplex Headset Walkie Talkie system is like a cordless telephone. It enables both parties to talk at the same time. Its headset style allows your hands to be free for other activities.

INSTALLATION OF BATTERY

- Open the battery compartment cover by using a small screwdriver as indicated at fig.1.
- Insert a 6F22 (9-Volt) battery.
- Replace the cover.

BATTERY PRECAUTIONS

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
- When not in use, remove battery to prevent possible leakage.
- Avoid short circuit of battery.
- Do not bury or burn them.

HOW TO OPERATE


1. Open the battery compartment and insert one 9-Volt battery for each unit.
2. Adjust desired volume level by using Rotary Volume Control situated at the side of your Walkie Talkie system.
3. When transmitting, speaking clearly in a normal voice.
4. Adjust headset comfortably on your head. See fig.2 for example.
5. In the event of interference caused by other radio signals in the vicinity, move to a different location.

CAUTION

1. Your Duplex Headset has been fully adjusted prior to shipment from the factory. Be sure not to touch internal components other than replacing batteries.
2. When the sound becomes weak, it is time to change the batteries.
3. After use, always turn the selector switch to off position.
4. Keep your headset in a dry and clean place.

Operating performance may be affected by surrounding structures and equipment.

WARNING: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USERS AUTHORITY TO OPERATE THE EQUIPMENT.



ALARON® LIMITED WARRANTY

This ALARON product is guaranteed for six (6) months against manufacturing defects in material and workmanship. During this period, repairs or replacement required as a result of such defects will be made free of charge.

If service is required, pack products securely with adequate protection against damage during transportation and mail it prepaid to: ALARON INC., 1026 DORIS ROAD, AUBURN HILLS, MI 48326. Please enclose your sales slip showing the date of purchase to prove that your warranty period has not expired. Also enclose a letter explaining the nature of the difficulty together with \$5.00 to cover handling and return transportation. Repairs not covered by our warranty will be made at a nominal service charge.

This warranty does not cover accessories. Nor does it cover broken cabinets or any damages caused by misuse or negligent handling.

This guarantee excludes any claims for indirect or consequential damage due to defect(s) in the product. This guarantee is in lieu of any other warranty either expressed or implied. Any and all warranties of merchantability and fitness for a particular purpose are expressly disclaimed and excluded by Alaron Inc.

In no event shall Alaron Inc. be liable to you or any other person for indirect or consequential damages arising from but not limited to the following: The use or inability to use this product; Incompatibility of this product with any other product; breach by Alaron Inc. of the limited warranty contained herein.

Some states do not allow limitations on how long an implied warranty lasts, so the limitation may not apply to you. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the limitations above or the exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which may vary from state to state.

MADE IN CHINA FOR
ALARON INC.
AUBURN HILLS, MI 48326

WINATION TECHNOLOGY MFG
FCC ID : N57RY-1350
JOB # : 196AH0
EXHIBIT # : *3B*