

Functions

- Hands-free communication available on the move
- Highly sensitive microphone and speaker for direct communication without ear-microphone or headset
- Automatic scanning function of 40 channels to avoid a call interference
- Dual hook switch on handset and headset
- Last number redial
- Hold button (Pressing hold button during a call plays music to the party on hold
- Flash button to transfer a call
- Paging the handset when the handset is away from the base station
- Voice Volume adjustable
- Channel Selection against a call interference
- Pressing any key on handset enables you to receive a call

Installation

(Setup)

- Attaching the battery to the handset -

- 1) Open the battery cover
- 2) Insert the battery with connecting battery jack to inner socket. Melody will be played to indicate that it was properly located
- 3) Replace the cover : To avoid possible damage, it was made not to easily open)

- Connecting to the power and telephone line -

- 1) Put a plug of DC 9V adapter into the outlet and connect the AC round jack to the 'power' in base station. (Then, green light is turned on after one second)
- 2) Connect the phone line to telephone outlet and then the end of the line to 'Phone/Line' in the base station. (Another phone or Modem can be connected to the phone jack, but no communication security guaranteed in this case since voice can

be heard in another connected phone during a call)

Operation

(Placing a call)

- Decide whether to use ear-microphone or not.
- ✓ Connect Ear-microphone to earphone jack in handset for a hands-free communication
- ✓ Remove an ear-microphone for a direct communication using built-in speaker and microphone in handset.
- Press the hook button of handset or ear-microphone. (After green light is blinking in handset and dial tone is heard in green light)
- Listen for a dial tone and dial the desired number
- Ending a call pressing hook button on handset or ear-microphone
(Green light on handset is turned off accordingly)

(Receiving a call)

- Green light is blinking with playing a melody.
- Pressing any button of handset or hook button of ear-microphone and start your conversation with the caller
- Green light indicates that you are connected
- Ending a call pressing hook button on handset or ear-microphone

INFORMATION

*** Note**

- Make sure to press the hook button of the ear-microphone adequately (for about one second)
- Red light of handset indicates the battery needs to be charged
- An irregular noise is heard when over-discharged (recharge)