

PROTAG

User Manual

FCC ID : OLKG1

MODEL : PROTAG G1



INNOVATM
TECHNOLOGY


aL Quick Start Guide

for Android and Blackberry users



Getting Started Guide

Button Basics



Power On/Off

Hold **Button A** for 4 Seconds to turn on/off.

Discovery

Hold **Button A** for 8 Seconds to on discoverable.

Distance Setting

Hold **Button B** for 4 Seconds to set distance.

Press **Button B** twice to confirm distance.

Table of Contents

1. Welcome
2. How aL Helps
3. aL Parts and Functions
4. Installing aL Software
5. Setting Up
6. Alarm Functions
7. GPS Functions
8. GPS Settings
9. Alarm Settings
10. Losing Your Valuables
11. Losing Your Mobile Phone
12. Troubleshooting & FAQ
13. Terms and Conditions
14. One Year Limited Warranty

Welcome

Welcome to aL User Manual by Innova Technology.

If you have further questions after reading this manual, you may contact us at:

<http://innovatechnology.com.sg/contact-us>

In the **aL retail pack**, you will find one **aL card** and **two accessories**:



aL



**USB Wall
Charger & Cable**

How aL Helps

aL is specially designed for travellers to prevent the hassle of losing belongings overseas. Losing a passport or wallet would spoil your entire trip's experience which can be prevented with **aL**.

aL helps you protect your belongings in many scenarios. For example:

In a restaurant after your meal.

In the bus or other public transports.



aL Parts and Functions

LED lighting

Blue LED blinks every 8s when connected.

Red LED blinks every 8s when disconnected.

Red LED blinks 4 times when battery is low.

Red LED remains constant when charging.

Blue LED remains constant when setting distance.

Charging

You can charge aL directly by plugging in the USB into a computer USB port or by using our charging device.

Red LED remains constant when charging.

Upon full charge, RED LED will be turned off.

Take note that as a safety feature, aL will automatically switched off when charging.

Installing aL Software

In 3 Simple Steps, aL can be installed into your phone.



You can download directly from your Android or Blackberry store by searching “aL”.



If you are downloading using your PC, go to www.innovatechnology.com.sg/downloads to get your software for Android. Connect the USB cable from your mobile to the laptop. Transfer aL’s software to the root folder of your android. Find your device manager (e.g. ASTRO), find **aL apk** and select **install aL**.



The application launcher icon should appear on the phone’s menu page.

Run the aL application now.

If your aL does not work, contact aL’s helpdesk for assistance.

Setting Up


With 3 Simple Steps, the basic setup can be done.

Add Device



To pair aL with Mobile phone (aL) - Hold **Button 'A'** (Discovery) for about 8 seconds till Red and Blue LED flashes (Timeout after 1 minute).

Select 'Add Devices' on aL application home screen, it will take you to the default Bluetooth Menu.



Scan for new devices and select aL on the device list. Upon successful pairing, Press the back button to the add aL into the application.

To **change device name**, select aL's Device Name in the details button.

Setting Up

Set Distance



Hold 'B' (Distance) Button for about 4 seconds till constant Blue LED is lighted (Timeout after one minute).

Walk to a comfortable distance that you wish to set with aL. This distance (3-10m) will act as a safe zone. To confirm the distance, click on **Button 'B'** twice. Upon leaving the safe zone, an alarm will ring.

*Recommended distance should be above 3 metres.

If distance setting is successful, Blue LED will blink twice. If unsuccessful, Red LED will blink twice.

Test aL application



Test the application - Walk away from your set distance. If your set-up is complete, you will hear the alarm. Press reconnect to start using.

Your valuables are ready to be protected.

***Click the home button to run the aL application on the background.**

Alarm Functions

Upon exiting the safe zone, an alarm with 3 main functions will pop-up.




Snooze alarm - The snooze alarm feature comes with a pre-set timing of 5 minutes. You can snooze for your toilet or lunch breaks. It will reconnect itself after the set snooze timing.



Stop monitoring - When you are at home or in your hotel, you can easily stop monitoring aL by selecting stop monitor.



Reconnect – The reconnect function works upon leaving your valuables behind. Upon retrieving your valuables, press reconnect to continue protecting your valuables.



IMPORTANT REGULATORY INFORMATION

This device complies with Part 15 of the FCC Rules: Operation is subject to the following two conditions:

1. This device may not cause harmful interference and
2. This device must accept any interference that is received, including any interference that may cause undesired operation.

WARNING:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.