

User Manual for models CL3, CS-CL3& BT-CL3

USER'S MANUAL



Warning

Note: This equipment has been tested and found to comply with limit for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used according with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- reorient or relocate the receiving antenna
- Increase the separation of between the separation and receiver.
- Connect the equipment into an a circuit different from that to which the receiver is connected.
- Consult the dealer or an experience radio/TV technician for help.



Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device compliance with Part 15 of the rules. Operation is subject to following two conditions : (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CONNECTING


Adapter (DC 12V)with main cable
(plug types vary according to different countries)

Telephone jack with telephone cable
(type varies depending on country)





You can conveniently carry the
emergency alert control and
make a emergency alert if necessary.

FEATURES



1. Emergency Alert Control

If an emergency happens, press the  button to activate the alert function.
If you want to deactivate the function, just press the  button.

2. Alert Time Select Switch

The switch is located on the back of the unit. Move it to proper position (1~3) to select the emergency alert time.

3. Power and Alert Button (Indicator)

When the DC adapter is connected, the indicator will be bright in green.
But if the emergency alert function is activated, the indicator will be bright in red, also you can press the button to deactivate the emergency alert function.

4. Turning Off Functions

Set the switch to this position, all the functions of the unit will be turned off.
But when the emergency alert function is activated, the unit will sound the alert tone.

5. Flash and Ring

Set the switch to this position, when a call is received **or** the emergency alert function is activated, the unit will flash and ring.
But when a call is received, the emergency alert function is activated, the unit will sound the alert tone.

6. Flash and Shake

Set the switch to this position, when a call is received **or** the emergency alert function is activated, the unit will flash and the additional shaker will shake.

7. Ring and Shake

Set the switch to this position, when a call is received **or** the emergency alert function is activated, the unit will ring and the additional shaker will shake.
But when a call is received, the emergency alert function is activated, the unit will sound the alert tone.

8. Volume Control

Move it upwards or downwards to control the volume.



9. Ringer Tone Select Switch

Set the switch to proper position to select the ringer tone (1~3).

10. Alert Tone Select Switch

Set the switch to proper position to select the alert tone (1~3).

11. LED Indicator

Each time the  or  button is pressed, the red LED on the emergency alert control will flash.

Note:

1. You must connect the adapter (DC 12V, 1A) for using the unit.
2. It is optional to connect a shaker.

CONSUMER INFORMATION

This equipment complies with Part 68 of the FCC rules and the requirement by the ACTA. On the **bottom** of this equipment is a label that contains, among other information, a product identifier in the format **US:AAAEQ##TXXXX**. if requested, this number must be provided to the telephone company.

An applicable certification jacks Universal Service Order Codes (USOC) for the equipment is provided (i.e., **RJ11C**) in the packaging with each piece of approved terminal equipment.

A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connect to a compatible modular jack that is also compliant. See installation instructions for details.

The REN is used to determine the number of devices that may be connected to telephone line. Excessive RENs on a telephone line may result in the devices not ring in response to an incoming call. In most but not all areas, the sum of RENs should not exceed five (5.0). To be certain of the number of devices that may be connected to a line, as determined by the total RENs, contact the local telephone company. [For products approved after July 23, 2001, the REN for this product is part of the product identifier that has the format US:AAAEQ##TXXXX. The digits represented by ## are the REN without a decimal point (e.g., 03 is a REN of 0.3). For earlier products, the REN is separately shown on the label.]

If this equipment causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. But if advance notice isn't practical, the telephone company will notify the customer as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary.

The telephone company may make changes in its facilities, equipment, operations or procedures that could affect the operation of the equipment. If this happens, the telephone company will provide advance notice in order for you to make necessary modifications to maintain uninterrupted service.

Please follow instructions for repairing if any (e.g. battery replacement section); otherwise do not alternate or repair any parts of device except specified.

Connection to party line service is subject to state tariffs. Contact the state public utility commission, public service commission or corporation commission for information.

This equipment is hearing aid compatible.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

SAFETY PRECAUTIONS

To reduce the risk of the electrical shock and injury, please follow these basic safety precautions before using the phone.

1. Carefully read and observe the instructions in this manual. Heed the warnings marked on the unit.
2. When cleaning, unplug the phone. Use a damp cloth. Do not use liquid or aerosol cleaners.
3. Do not use this unit in wet surroundings and environments where there is a risk of explosion.
4. Avoid spilling any liquid on the unit.
5. **Only use the power supply unit supplied (DC 12V, 1000mA)**, identified by the symbol on the underside of the device. The adapter must pass the authorized approval.
6. Children don't recognise the risks of electrical appliances. Therefore use or keep the unit only under supervision of adults or out of the reach from children.
7. Use the unit only in the described manner. Do not use or stop the use if the unit is damaged.
8. The phone is designed for working with a temperature range from 5℃ to 45℃.