

4

3

2


1

NOTES:

1. INTERPRET DRAWING PER ASME Y14.100-2000.
2. SEE CONFIGURATION TABLE TO SELECT PROPER ASSEMBLY PART NUMBERS AND SELECTION OF BUTTON.
3. SEE PAGE TWO FOR ASSEMBLY INSTRUCTIONS.
4. INCLUDE BELT CLIP AND KEYCHAIN LOOP ACESSORIES WHEN SHIPPING, SEE PAGE 1 FOR IDENTIFICATION.

REVISIONS				
REV	ZONE	DESCRIPTION	NAME	DATE
01	ALL	ENGINEERING RELEASE	BRS	22 JUNE 06
02		ADD FCC LABEL, SN LABEL REMOVE MIL SPEC FROM NOTES UPDATE ASSEMBLY INSTRUCTIONS CNG COLOR FROM BROWN TO ORANGE ADD REAR VIEW WITH LABEL LOCATION	BRS	13 JULY 06

ITEMS ON THIS PAGE NOT TO SCALE



SEE NOTE 4

RSI II CONFIGURATION TABLE			
ASSEMBLY PART NUMBER	BUTTON PART NUMBER	ASSEMBLY DESCRIPTION	BUTTON COLOR
RSIII-03-00584-XX	RSIII-03-00545-XX	RSI II ASSEMBLY	ORANGE
RSIII-03-00586-XX	RSIII-03-00587-XX	RSI II, ASSEMBLY, MASTER	GREEN

12	1	RSIII-03-00604	01	RSI II , FCC LABEL
11	1	RSIII-03-00603	01	SERIAL NUMBER LABEL
10	2	RSIII-03-00585	01	#2-56 FILSTER HD, SS, 5/16"LG MCMASTER PN 91794078
9	2	RSIII-03-00553	02	RSIII, BATTERY PAD
8	1	RSIII-03-00552	02	KEYCHAIN LOOP, RSI II
7	1	RSIII-03-00551	02	BELT CLIP, REAR MNT, RSI II
6	1	RSIII-03-00550	03	LED WINDOW, RSI II
5	1	RSIII-03-00546	01	RSI II, BATTERY ASSEMBLY
4	1	RSIII-03-005XX	02	BUTTON, SEE CONFIGURATION TABLE
3	1	RSIII-03-00544	01	BTM SHELL, RSI II
2	1	RSIII-03-00543	02	TOPSHELL, RSIII
1	1	58-00016-PCA	04	RSI II, BOARD ASSEMBLY
ITEM	QTY	PART #	REV	DESCRIPTION

BILL OF MATERIALS

ALL DIMENSIONS ARE IN INCHES TOLERANCES .XXX ±.005 2 PLACES ±.02 ANGLES ±0° 30'		APPROVED	DATE	1225 Old Alpharetta Road Suite 210 Alpharetta, Ga 30005-2901 770-663-8844	
		DRAWN BRS	22 JUNE 06		
MATERIAL N/A		CHECK		RSI II, KEY REMOTE	
		ENGINEER			
FINISH N/A		MANUFACTURE		SIZE	DWG NO
		N/A		B	RSIII-03-0058X
		SCALE 0.750		SHEET	1 OF 2
				REV	02

THE CONTENT OF THIS DOCUMENT IS "TERAHOP NETWORKS INCORPORATED INTELLECTUAL PROPERTY" AND IS THE PROPERTY OF TERAHOP NETWORKS INCORPORATED. IT IS TO BE TREATED AS STRICTLY CONFIDENTIAL AND IS NOT TO BE DISCLOSED, REPRODUCED, OR USED, EXCEPT AS AUTHORIZED IN WRITING BY TERAHOP NWTWORKS INCORPORATED, IN CONNECTION WITH THE MANUFACTURE, MAINTENANCE, AND USE OF THE EQUIPMENT TO WHICH IT PERTAINS.

4





3

2

1

ASSEMBLY INSTRUCTIONS

- 1) REMOVE LINER FROM BATTERY PADS AND STICK INTO BATTERY WELL ON TOP AND BTM SHELLS.
- 2) REMOVE LINER AND APPLY LED WINDOW INTO TOP SHELL.
- 3) PLACE BUTTON IN TOP SHELL.
- 4) PLACE BOARD ON MOUNTS IN THE TOP SHELL.
- 5) PLACE BATTERY IN TOP SHELL WELL , INSURE TERMINALS ARE IN PROVIDE SLOT IN TOP SHELL. CONNECT BATTERY TO BOARD. BEND WIRE LEADS TO INSURE THEY WILL NOT INTERFERE WITH BOTTOM SHELL ASSEMBLY.
- 6) WITHOUT REVERSING ORIENTATION, SNAP BTM SHELL ON TO ASSEMBLY.
- 7) INSTALL SCREWS.
- 8) APPLY SERIAL NUMBER LABEL AND FCC LABEL IN LOCATION INDICATED



THE CONTENT OF THIS DOCUMENT IS "TERAHOP NETWORKS INCORPORATED INTELLECTUAL PROPERTY" AND IS THE PROPERTY OF TERAHOP NETWORKS INCORPORATED. IT IS TO BE TREATED AS STRICTLY CONFIDENTIAL AND IS NOT TO BE DISCLOSED, REPRODUCED, OR USED, EXCEPT AS AUTHORIZED IN WRITING BY TERAHOP INCORPORATED, IN CONNECTION WITH THE MANUFACTURE, MAINTENANCE, AND USE OF THE EQUIPMENT TO WHICH IT PERTAINS.

1225 Old Alpharetta Road Suite 210 Alpharetta, Ga 30005-2901 678-455-8844			
RSI II, KEY REMOTE			
SIZE B	DWG NO RSIII-03-0058X	REV 02	
SCALE 0.750		SHEET	2 OF 2