

# FM Hi-Fi Wireless Headphone User's Manual

## Technical Specifications

### Emitter

Asian frequency:  $86 \pm 0.5\text{MHz}$   
Modulation mode: FM  
Emission distance: 30m (with no interference)  
Reception from any audio and visual equipment with audio out socket, such as TV set, audio device, DVD/VCD player, multimedia ,PC, MP3, walkman, etc.  
Power supply: 2 × AAA batteries or 4.5V DC

### Receiver

Frequency range: 84–108MHz  
Reception Mode: FM  
Distortion:  $\leq 2\%$   
Power Supply: 2 × AAA batteries

## Notes

- To achieve best reception spread out emitter audio cable of the emitter(the emitter audio cable can also be used as antenna).
- If the sound is distorted or too strong, adjust the volume of the signal source (TV set, VCD player, DVD player, PC, MP3, walkman etc.) to a lower level, and reception performance may be improve.
- Replace the batteries if you are having the following problems.
  - The emitter indicator becomes dim.
  - The receiver reception is poor.
  - The volume becomes weak and the sound is distorted.

Note:  
This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and  
(2) This device must accept any interference received, including interference that may cause undesired operation.  
Caution:  
The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment.


## Appearance and Function Illustrations

### A Receiver

- Battery compartment cover
- Volume control and power button (ON/OFF)
- Scan key (SCAN)
- Reset key (RESET)
- Power indicator
- Audio socket

### B Emitter

- Power indicator (front)
- Power and function switch
- Microphone socket (MIC)
- Power socket (4.5V DC)
- Microphone (MIC)
- Audio cable of emitter
- Battery compartment cover (bottom)



## Parts

Package includes:	
● Emitter	1
● Receiver (Headphone)	1
● Instruction Manual	1
The following parts are optional (to be purchased additionally)	
● Audio cable	1
● Y adaptor cable	1
● Power adaptor	1

## Installation

### Installing the receiver:

Insert two AAA batteries into the battery compartment according to the + and -polarity.

### Installing the emitter:

Insert two AAA batteries into the battery compartment according to the + and - polarity, or insert the power adaptor (optional) into power socket of emitter (4.5V DC)  
Insert audio plug of the emitter into AUDIO-OUT socket of audio source (such as TV set, audio device, PC, DVD player, CD player, MP3 player, etc.). In case the audio out socket of the audio source is the headphone socket, The Y adaptor cable can be used for connection (see Fig.1). To achieve best reception spread out emitter audio cable which can be also used as antenna.

## Operation

### Wireless headphone

1.Insert the emitter audio cable into the AUDIO-OUT socket of the electrical device (see Fig.1) or earphone socket, and move the function switch of the emitter to the WIRELESS HEADPHONE position, and the power indicator of emitter will go on. (In case that TV set is used as the audio source, the TV set can be muted.)

2.Turn on the volume control and power button (ON/OFF) on receiver, the power indicator of receiver will go on. First press the RESET key, and press the SCAN key, the sound sent from emitter should be heard.

### Wireless net audio chat

- Connect the emitter audio cable to the adaptor cable (optional) (see Fig.2), and insert the other end of the adaptor cable into the audio out socket of the PC, then insert one end of the audio cable (optional) into the microphone socket (MIC) on the emitter, and insert the other end into the microphone in socket of the PC.
- Aim the microphone socket (MIC) of the emitter at you (see Fig.3), and move the power switch of the emitter to AUDIO CHAT position, and the power indicator will go on.
- Turn on the volume control and power button (ON/OFF) of the receiver, and the power indicator will go on. First press the RESET key, and the press the SCAN key, and then the sound sent out from the emitter can be heard.

### Wireless monitoring

Place the emitter near the people you want monitored (such as elderly people, children, etc.), and aim the microphone (MIC) the people. Move the function switch of the emitter to the MONITOR position, and the power indicator will go on. Turn on the volume control and power button (ON/OFF) of the receiver, and the power indicator of the receiver will go on. Press the RESET key, and press the SCAN key, the sound sent out from emitter can be heard with the headphone.

### Listening to the radio

The receiver can be used separately as an FM radio. Press SCAN key once, and the receiver will automatically search toward a higher range and lock one radio channel; when the highest range is reached, press RESET key, and the frequency returns to the lowest range. Press SCAN key again, and the receiver will search the radio channels from the low range again.

### Wired Headphone

Insert one end of the audio cable (optional)into the audio socket of the receiver (see Fig.4), and insert the other end into the headphone socket of the electrical devices, such as MP3 player, VCD player, DVD player, etc., and then the unit can be used as a wired headphone.

### Turing off the unit

When the unit is not used, move the function switch on the emitter to OFF position to turn off the emitter; and turn the volume control receiver to the OFF position, and the power indicator receiver will go out, and the receiver will turn off.  
Remove batteries when not using unit for a long time

