

# User manual

This device has only one button to operate.

And only thing user can operate on this device is press the button.

We make it super simple to use.

When press the button, it can make a phone call.

Short press the blue button to wake up the system, and long press for 4 seconds will make emergency call.

With a pin to press the pinhole can close the unit.

When unit is off, long press the blue button for 6 seconds to turn on the device.

User can press the button quickly to find the following information:

1. If the red light blinks 1 time, the device is powered on and in standby mode.
2. If the red light blinks 1 time and blue light blinks for 10 seconds, the device is on.
3. If no light blinks, the device is off

Put the device to the charger cradle, the device will be charged.

## **FCC Warning:**

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and

on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## **Specific Absorption Rate (SAR) information**

SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands. Before a new model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC. Tests for each phone are performed in positions and locations (e.g. at the ear and worn on the body) as required by the FCC. For body worn operation, this product has been tested and meets the FCC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that contains no metal and that positions the product a minimum of 0.5 cm from the body. Non compliance with the above restrictions may result in violation of RF exposure guidelines.