

Remote and nunchuck for wii operation guide

- 1. First connect power supply of wii game console including inductor and AV cable.**
- 2. Install 2*AA dru battery in the remote for wii.**
- 3. There is a red color code key SYNC on the back of the remote, the four indicators on the front of the remote will be blinking quickly by pressing it (sufficient battery power).**
- 4. Press the code key which is on the wii game console to connect the game console with the remote by pairing (after synchronization, the No. 1 indicator will be solid bright).**
- 5. Adjust the position of the sensor bar (position of cursor).**
- 6. You can play games by reading U-disk and DVD using the remote for wii (Nunchuck is required to be connected with remote when reading games).**

WII 左右手柄操作说明

- 1 先把主机的电源连接好，包括感应器、视频线。
- 2.将 WII 直柄手柄装好 2*AA 干电池。
- 3.WII 直柄背面有一个红色的对码键，按下对码键，WII 手柄四个指示灯会快闪(电池电量充足)
- 4.再按主机对码键让手柄与主机连上码(连上对码后 WII 直柄示灯 1 号灯常亮)
- 5.调整好感应条的位置(光标的位置)
- 6.用 WII 直柄读 U 盘或光盘进行玩游戏(读游戏时需配用弯柄使用)

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction