

Neurox R10 Remote Control Instruction Manual


1. Introduction

Thank you for using this remote control. This product uses 1 to 1 coding. When the battery is installed for the first time, it can be used directly if everything is normal without setting. If you need to perform code matching, please press and hold the "M" button on the main unit for three seconds, and then press the "M" button on the remote control. After successfully matching the code, you can use it.

*This remote control has a power-off memory function, and the battery needs to be changed without resetting.

2. Functions

- ① Indicator
- ② Sound on/off
- ③ Decreased pressure
- ④ Increased pressure
- ⑤ Heating on/off
- ⑥ Mode switch




3. Technical Parameters

Model:	R10	Working current:	8.5mA
Frequency:	433MHz (1to1)	stand-by current:	10nA~1uA
Protocol:	MCU learning code	Launch distance:	About 30M
Battery:	DC3V CR2032 Coin Cell		

(Open space, receiving sensitivity is -110dBm)

4. Replace or install the battery

Use a tool to open the battery cover and insert the battery according to the "+/-" symbol marked in the battery compartment (CR2032 or CR2025 is common.) If you do not plan to use the remote control for a long time, please remove the battery



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that

interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The device has been evaluated to meet general RF exposure requirement, the device can be used in portable exposure condition without restriction