


Memo to users


Thank you for purchasing our products.
To use the product properly, please read the manual carefully
before use and keep it for reference.

Parts Names & Installation

(Make sure that the power supply has been cut off to avoid electric shock)



Adjustable Range



The remote control of the LED lamp
can be fully rotated 360° clockwise
and counter-clockwise



Rotate the bottom cover of the LED lamp
to open the battery compartment to
insert or replace the batteries

Control Panel



Power Switch

Tap this button to turn the LED Lamp on/off, when the battery is low the red indicator will flash to remind you to replace the batteries.



Brightness Adjustment

Tap this button to wake up the Dimming Mode, turn the remote control clockwise to increase the brightness and counterclockwise to decrease the brightness.



Automatic Dimming

By tapping this button the LED lamp will adjust the brightness automatically according to the ambient light and the indicator is on.



Color Temperature Adjustment

Tap this button to wake up the Color Temperature Adjustment Mode and the indicator light is on, turn the remote control clockwise to increase the color temperature and counterclockwise to decrease the color temperature.



Favorite Mode

Long press this button for 2 seconds and the indicator light will flash 3 times and then is always on which means the Favorite Mode has been successfully saved; by tapping this button you can return to your favorite light setting saved in Favorite Mode immediately.



RGB Backlight

Tap this button to wake up the RGB Backlight Mode and the indicator light is on. The RGB backlight changes cyclically, long press for 1s to fix the color, long press for another 1s to change colors cyclically. By tapping the RGB Backlight Mode again, the indicator light is off.



Warm Backlight

Tap this button to wake up the Warm Backlight Mode and the indicator light is on. By tapping the Warm Backlight Mode again, the indicator light is off.

Tips: The effective distance of the remote control should be within 1.2 meters.

Method of pairing a newly purchased remote control when the original one is lost:

1. Power off the USB for 5 seconds and then power it on again.
2. Insert 3 AAA batteries into the remote control, the indicator light will flash to show that it is normally powered on.
3. Press the power button on the remote control to power on from a distance of max. 60cm and long-press the power button for 3 seconds, once your remote control is successfully paired, the LED lamp will flash 3 times and illuminate steadily to indicate completion of the process.

Model	Products	Rated Voltage	Rated Current	Power	Gross Power
MG-REMOTE	Control	4.5V	70mA	70mA	0.315W

Batteries of Remote Control: 3* 1.5V AAA / LR03 Batteries

Executive Standard: GB7000.1 GB7000.204

* Actual product appearance may be subject to change due to product enhancement.

* Product information is subject to such changes and adjustments without notice.

Made in China

CONTACT INFORMATION: service.us@mgleds.com

MANUFACTURER: Shenzhen Magelighting Co., Ltd.

ADDRESS: A 5/F, Building B, Chuangye Road 3, Fenghuang 3rd

Industrial Zone, Fuyong Street, BaoAn District, Shenzhen, 518103, China

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.