



Warning

1. The toy may have potentially sharp edges or sharp points or small parts prior to assembly, so it must be assembled by an adult.
2. Use The car properly under adult supervision or risk injury to yourself or a third party.
3. Do not drive or play in dangerous places such as public streets, roads, slopes, swimming pools, etc. Otherwise, it may cause traffic accident and drowning.
4. This toy car may have small parts falling off during use, so it is not suitable for children up to 36 months of age.
5. This product is only suitable for children aged 37–96 months. Please put on protective equipment before use, such as helmet, hand protective cover, KNEEPAD, etc.
6. The car can not be overloaded with a maximum load of 25KG.
7. chargers and batteries, wires, plugs and other components must be checked regularly for damage and should be stopped from being used until they are repaired.
8. Stay away from fire.
9. It is important to read the product instructions carefully before doing so and keep them for future reference.
10. The remote control uses two cells of No. 7 battery, which must be placed in the correct polarity position.

Certificate of conformity	
model:	_____
Inspector:	_____
Production date:	_____

Electric four-wheeler for children

Installation and operation manual

Applicable Age: 37–96 Months Child Use

- Front and rear shock absorbers,
- convenient pull rod,
- 2.4 g one-to-one Bluetooth function,
- hydraulic double door,
- swing function,
- LED light board,



Please take good care of the important information in it

Thank you for choosing our electric baby carriage

Please read the manual before using this product, it will tell you the correct operation method and installation steps. To avoid incorrect operation of the product and damage or injury to your baby. This manual shall be properly kept and kept in an accessible place.

Specifications


Storage battery	12V 4.5Ah
Motor	12V380(18000RPM)x2,
Applicable Age	For children aged 37–96 months
Maximum load	25kg
Dimensions	105x62x45CM
Speed	3.5km/h
Charger	output: 12V800mA
Usage time	Charge for 10–12 hours. Use for 1–2 hours

Charging points

1. When using an electric car for the first time, the battery must be fully charged for 16 hours! Otherwise the battery will be permanently damaged and beyond repair. The charging timeshould not exceed 18 hours.
2. When charging, first plug the charger DC into the charging socket, and then plug the charger into the power socket.
3. Each continuous use of 1 hour, you must be timely charging, normal charging time for 10–12 hours.
4. Charging process charger or battery heating phenomenon (below 600C) is normal.
5. When the electric baby'carriage is not in use for a long time, it must be recharged at least once a month.

Battery instruction for Remote Control


1. When installing the battery, first open the battery cover, then install the battery according to the polarity, lock the battery cover. In the same way, take out the battery.
2. The remote control uses 2 # 7 batteries.
3. The non-rechargeable battery can not be charged.
4. rechargeable batteries can only be charged under adult supervision.
5. The rechargeable battery should be removed from the toy before recharging.
6. Different types of batteries or old and new batteries should not be mixed. .
7. Batteries should be placed at the correct polarity.
8. The depleted battery should be removed from the toy.
9. The power terminal must not be short-circuited.



Trouble shooting

Fault type	Detection site	Method of elimination
The Motor won't run	1. Is the foot switch in good contact? 2. Is the welding wire on the motor terminal in good condition? 3. Is the connector of the motor lead plugged in well? 4. Will the motor plug-in disconnect, directly, connected to the battery rotation?	No, fix the foot switch; yes, next. No, weld the terminals to the wire; yes, next. No, plug the connector in; yes, next. Do not turn, change the motor; turn, Drive Circuit Board failure, send professional repair point repair.
To go only forward without going back, or to go only backward without going forward	1. Detect reverse switch, with a three-meter test, good contact? 2. Drive line to reverse switch wiring, is it good?	No, change the reversing switch; yes, next. No, the line connected; yes, Drive Circuit Board failure, send professional repair point repair.
It's slow	1. Check if the BATTERY VOLTAGE IS ABOVE 12V? 2. Will the motor (with gearbox) directly connected to the battery, speed up or not? 3. Unload the gear box, check the gear rotation, move well or not?	No, charge.–yes, next. No, next item; yes, Drive Circuit Board failure, send professional repair point repair. No, change the gear box; yes, change the motor.
It's not charging	1. Does the charger output terminal have 12V voltage? 2. Will charger input, output plug good, will the battery end two plug springs pull out, test has 12V voltage? 3. Check that the charging seat fastener is loose and the solder joint is free?	No, change the charger; yes, next. Yes, change the battery. No, next. Yeah, plug in the charger.

Instructions



1. Install wheels:

The wheel cover which distinguishes the front wheel from the rear wheel sets the gasket, the front wheel and the gasket in turn into the front axle and is fixed with a nut, and the wheel cover sets the rear wheel and the gasket in turn into the rear axle and is fixed with a nut and is fixed with a wheel cover, install the wheel on the other side in the same way.

2. Install the steering wheel:

First connect the steering wheel wiring, the steering wheel to the steering control rod alignment position with the screw insert fixed.

3. Install the front windshield:

The windshield is aligned with the card port on the body and is forced in.



4. Connect the power cord:
Connect the wiring to the battery and note the color of the circuit



5. Install the seat:
First remove the screws on the body, the seat at the body position of the card, with screws fixed.



6. Install the reflector and rear mount:
Distinguish the right and left rearview mirror, aiming at the body on both sides of the position of the card into the rear frame installed to the body of the corresponding position can be clamped

Instructions for use




Function Instructions:

1 forward stop back	8 USB port
2 Dashboard	9 power display
3 Power Switch	10 charging holes,
4 Light/Swing Switch	11 high speed,
5 on a song (long press to reduce sound)	12 low speed,
6 Music	13 Bluetooth,
7 next song (long press to add sound)	14 use keys

Remote control functions and instructions

- Do not switch the forward and backward buttons during vehicle movement to avoid damaging the gearbox and motor.
- The remote control needs a battery to work properly.
- The remote control requires the use of a guardian.
- Remote control is preferred.

★ Code method:
always press the code key (m) do not let go waiting for the signal lights flashing, flashing lights after the start of the car successfully release the Code Key




Precautions for use

1. Not in the streets, roads, slopes and other hazardous areas.
2. Please be on a well-level ground, please do not use on the smooth surface (such as marble, floor tiles) and other surfaces.
3. This product limited by one person, can not be overloaded, the maximum load 25KG.
4. Children must ride under adult guidance and caretakers must not leave during cycling.
5. Do not modify the vehicle wiring or additional charging device.
6. Do not use in water, do not pour water and other liquids in the car.
7. The car should not be blocked in the process of moving the car, so as to avoid damage to the device, such as blocked phenomenon, please immediately release Foot switch, remove the obstacles before riding,
8. The car should be timely charging slow cycling speed, cycling for too long will cause shortened battery life.
9. Do not use, please turn off the power switch, unplug the battery connector when not in use for a long time.
10. Do not drive in rainy weather.
11. The main use of PP car material, non-toxic, non-radiation, safe to use for a period of three years.

Packing Instruction

● Product specification	1	● The front wheel	2
● Car body	1	● The rear wheel	2
● The saddle	1	● The steering wheel	1
● The remote control	1	● Wheel cover	4
● The charger	1		
● Accessories package	1		
● mirror	2		

Schematic



FCC Statement

WARNING: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device must not be co-located or operating in conjunction with any other antenna or transmitter.