


# STUNT CAR MANUAL

Thank you for buying our stunt car, and enjoy yourself! In order to use this product more conveniently and safely, please read all contents of this manual carefully before using this product, and keep this manual for future reference.


## PACKING LIST



Stunt car




Remote control



USB charging cable



## REMOTE CONTROL INTRODUCTION



• Standard remote control function button

## PRODUCT BATTERY INSTALLATION

- Installation and charging of lithium ion battery for stunt car




Battery installation for stunt car: Insert the attached 3.7v/500mah battery (attached).

Battery charging method: plug one end of USB interface into battery, and the other end into USB port or compatible adapter of any computer.

Charging Tips: The Light Is On When Charging, And The Light Is Off When It Is Full.

- Battery installation method of standard remote control

Battery installation: Remove the battery cover and insert the 2 × 1.5V AA battery according to the polarity indicated (battery excluded). Low voltage prompt: When the battery of the control consumes power to the voltage limit setting value, the indicator light of the remote control will always flash slowly, and the low-voltage prompt will be cancelled after the new battery is replaced.



Precautions: 1. Battery installation can only be done under adult supervision!

2. When installing the battery, the positive and negative electrodes must be identified with the positive and negative electrodes of the battery box, and must not be installed in reverse.
3. Do not mix old and new batteries.
4. Do not mix different types of batteries.

## BATTERY PRECAUTIONS



- Keep batteries away from children.
- The battery must be replaced by an adult.
- The battery can only be charged under the supervision of an adult. Do not leave the rechargeable battery unattended.
- Do not cover the battery when charging. Do not expose the battery directly to sunlight.
- Do not connect a fully charged battery to a charger; overcharging may shorten battery life.
- Do not handle the battery in fire, as the battery may explode, and if the battery is damaged, it may also explode.
- Do not short circuit the battery. When the metal objects such as coins, clips or pens are directly connected to the positive (+) and negative (-) terminals, accidental short circuit of the battery may occur.

Disposal methods of waste electrical products:


1. Do not place the product as domestic waste.
2. Comply with local regulations and laws, and dispose of waste electronic products properly.
3. Thank you for participating in the electronic recycling program.

### ATTENTION:


\* The device consists of electronic components and batteries. For e-waste, please carry out special treatment according to the local waste disposal requirements.




## STANDARD REMOTE CONTROL OPERATION AND CONTROL




1. Push the left lever up and the stunt car will move forward.




2. Push the left lever down, and the stunt car moves backward.




3. Push the right lever to the left and the stunt will rotate to the left.



4. Push the right lever to the right and the stunt car rotates to the right.





5. Press the right lever to the left for a long time, and the stunt car starts to stand and rotate clockwise.



6. Long press the right lever to the right and the stunt car starts to stand as well rotate counterclockwise.

## AUTOMATIC PRODUCT DEMONSTRATION



Press the "auto display" button, and the stunt car will automatically play all skills.

## PRODUCT SAFETY MAINTENANCE

- Please remove the batteries from the stunt car and remote control if when not playing.
- When using the stunt vehicle, please keep away from heat sources and avoid exposing the stunt vehicle to direct sunlight for a long time.
- Keep hands, hair and loose clothes away from tires when the stunt car starts.
- Please don't pick up the stunt car when it's moving.
- Only use clean, dry soft cloth to clean the stunt car.
- To avoid irreparable damage, keep the stunt car dry and away from water.
- Check the stunt car and accessories for damage. If damage is found, do not use the stunt car until it is repaired.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.