


AC-10 15W用户手册 (产品说明书)

尺寸：350*100mm 单面印刷 材质：157克铜版纸

User Manual 15W Fast Wireless Car Charger



Product Features


1. Top backside touch button, touch to open and easy for one hand operation. Charging indicator on both sides, and the small square LED indicator in the middle indicates the center position of the internal coil.
2. Built-in wireless charging transmitter coil, the two arms and feet will automatically close when the phone is placed on the charger. The transmitter coil automatically starts to find the mobile phone charging coil, and the mobile phone starts wireless charging after coil precise alignment.
3. Suitable for different size phones, anti-slip silicone on both arms and feet, Type-C charging port.
4. Built-in stepper motor, it works with low noise.
5. NPO capacitors, lower charging temperature and high charging efficiency.
6. Standby mode: the green and blue LED indicator light flashes alternately, then the green indicator light keeps on.
7. Charging mode: the blue LED indicator light keeps on, the light turns to green if the receiver is removed.
8. POD function: when metal or magnet objects are placed on the charger, the blue and green LED indicator light will flash for reminder.
9. Perfect protective function based on over-voltage, over-current, over-temperature and short-circuit protection.

Specifications


Input	DC 12V/1.5A, 9V/1.67A, 5V/2A
Output	15W/10W/7.5W/5W
Product Standard	Qi
Charging Distance	≤ 10mm
Charging Efficiency	≤ 80%
Product Dimension	Φ71.35*75.65*127.15mm
Product Material	ABS+Tempered Glass/Leather

※Fast wireless charging requires QC2.0/3.0 quick car charger.

Product Parts Description 1



Product Parts Description 2



Product Operating Guide

1. Please make sure the product is connected to the power before use.
2. The green LED indicator light is on when connected to power.
3. The LED indicator light will flash and the product will stop charging when the current is too large or there is a foreign object. Do not charge the phone if a similar situation occurs.
4. Please touch the backside power button to open the two arms, the wireless charging starts and the two arms/feet will close automatically once you place the phone on the charger. Only need to touch the power button again to release the two arms and easily remove the phone.
5. Please purchase the wireless receiver module or case separately (Not included in the product) if your phone does not support wireless charging.

Attention

1. Please do not vigorously extrude or collide.
2. Please do not dismantle or put it into fire or water when the product is powered on, to avoid short circuit or leakage.
3. Please do not use it in severely high temperature, high humidity or corrosive environment, to avoid damage to the circuit leakage.
4. Please do not put the magnetic strip or chip card (Such as ID card, bank card, etc.) on the charging pad to avoid causing magnetic card loss of efficacy.
5. Please do not put the metal (Such as coin, etc.) on the charging pad when charging, to avoid damage from heating.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

FCC RF exposure statement:

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. During the operation of the device a distance of 15 cm from the device and 20 cm above the top surface of the device must be maintained.

FCC ID : 2A2MY-AC-10.