


Enjoy better life



User Manual


S8

PLEASE READ THIS USER MANUAL CAREFULLY
BEFORE USING THE PRODUCT

1 Package Content

Speaker x1
Type-C Charging Cable x1
User Manual x1

2 Product Overview



1. Multi-function button
2. +-Button
3. Indicator
4. Microphone
5. Type-C charge port

3 Product Information


BT version: V5.4
Talk range:10m /33A
Weight : 66g
Music play time: Up to 14hours (Volume 80%)
Talk time: Up to 12hours
Battery capacity: 560mAh

4 Using Your Earbuds


Turn On & Pairing
Press the multi-function button for 2 seconds to power on and the earphone will enter pairing mode automatically.



For other mobile device:



5 Charging Your Device



Earbud Status Indicator	Status
Red light on	Being charged
White light on	Fully charged
When the battery is low, the speaker emits a "Battery Low" reminder every 1 minute	Low battery

- ! Use the included Type-C charging cable to charge your earphone.
- ! To preserve battery lifespan, fully charge at least once every 45 days.

CONTROLS

X1	Single click multi-function button	Play/Pause
1"	Press " " button for 1 seconds	Previous track
1"	Press "+" button for 1 seconds	Next track
X1	Single click "+" button	Volume plus
X1	Single click " " button	Volume down

X1	Single click multi-function button	Answering a call
X1	Single click multi-function button	Ending a call
1"	Press multi-function button for 1 second	Reject call

	Others	
X3	When the device is not connected after the speaker is turned on, press the multi-function key 3, the speaker will beep, and the red and blue lights will blink alternately.	Clear pairing list

6 Attention

Use original or certified cables
Do not expose to liquids
Do not disassemble
Avoid dropping
Avoid extreme temperatures
Do not Use the product outdoors during a thunderstorm
Do not Use any Corrosive cleaner/oil to clean

7 Considerate Hints

1.Do not turn up the volume to a fair high level constantly as this could shorten the service life of this product or impair your hearing.
2.When encounter any fault during operation, please cut off the power supply and disconnect the USB cable to prevent further damage to the product or other components.
3.The wireless transmission range or connectivity could be affected by low battery power.In that case, please recharge immediately.

8 Caution

1.Risk of explosion if battery is replaced by an incorrect type, dispose of used batteries according to the instructions.
Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion;
Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas;
A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

2.EUT Temperature: 0°C~+45°C(Standalone), 0°C~+40°C(with adapter).



High sound pressure with hearing damage risk.
Do not listen at high volume levels for long periods.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction