


## ► PRELIMINARY CHECKS

### Commissioning

- ▶ Use the controller to recline the backrest to its lowest position, raise and extend the footrest to its top position, make sure there is enough clearance before commissioning.
- ▶ Return the backrest and footrest back to its default position after commissioning and turn off the power switch. To choose the massage program, please check the Instructions of Control Panel and Instructions of Touchscreen Controller for reference.



### Before Sitting in the Chair

- ▶ Ensure the footrest is well assembled before sitting on the massage chair.
- ▶ Ensure the massage chair is returned to its original position before sitting on it.
- ▶ If there is any part not in default position, please turn off the massage chair to allow it to restore.

#### ⚠ CAUTION

- ▶ Do not take seat while the legrest is lifted.
- ▶ Do not put excessive load on the legrest to avoid damage.

### After Use

- ▶ Always unplug the massage chair from the electrical outlet immediately after use.
- ▶ Put the Touchscreen Controller onto the holder.
- ▶ Turn off the power switch and unplug the massage chair from the electrical outlet while not in use to avoid children power on the massage chair accidentally.
- ▶ When not in use for a long period of time, we recommend that the chair be covered, the power cord be coiled and that the unit be placed in an environment free of dust and moisture.

## ► NAME AND FUNCTION OF EACH COMPONENT

### Controller Instructions



**Power On/Off** Press this button to power on/off the controller.

- ▶ Press this button while connected to power to show the menu display, the LCD Screen is lit, use the UP/DOWN/LEFT/RIGHT buttons to navigate the screen, press OK to select.
- ▶ Press this button again to turn off the product.



#### Menu

- ▶ Display the Auto Program, Manual Program, Airbag, Heat, Roller and Settings function. (Check the Display Menu for detailed information)



#### Shoulder Position Adjustment Button (Moves mechanism up and down)

- ▶ Press and hold Position UP/DOWN ADJUST button to adjust the rollers to the desired position while in Manual-Point massage mode.
- ▶ While body scanning is working, use these two buttons to slightly adjust mechanism up/down the shoulder.



#### Auto Program Button

- ▶ Press to start the pre-set auto massage programs. You can choose Extension, Refresh, Recovery, Relax, Neck&Shoulder, Waist&Buttocks massage programs according to your liking. (Check the Display Menu for detailed information).



#### Manual Program Button

- ▶ Display the manual mode menu, press UP or DOWN button to navigate among: Kneading, Knocking, Tapping, Shiatsu and Sync massage techniques. (Check the Display Menu for detailed information)



#### Navigation Button

Use the UP/DOWN/LEFT/RIGHT arrow buttons to navigate the screen, press OK to select.



#### Heat On

- ▶ Press to turn on heat, the heat icon will be lit on display screen;

- ▶ Press again to turn off heat, the heat icon will go dark on display screen;

## ► NAME AND FUNCTION OF EACH COMPONENT



### Back Up

- Press and hold to raise the backrest, release the button to stop.

### Back Down

- Press and hold to lower the backrest, release the button to stop.

1  
2

### Zero Gravity Position 1

- Press Zero Gravity Position 1 to put the chair in Zero Gravity Position 1, press again to close the Zero Gravity Position 1; The Zero 1 icon will be lit on display screen accordingly.


### Zero Gravity Position 2

- Press Zero Gravity Position 2 to put the chair in Zero Gravity Position 2, press again to close the Zero Gravity Position 2; The Zero 2 icon will be lit on display screen accordingly.

## ► PRELIMINARY CHECKS

### Moving the Massage Chair

- Roll the chair on its casters to the desired location.
- Incline the backrest to upright position.
- Turn off the power switch and unplug the appliance from the electrical outlet.
- Using two people, push down on the backrest and lift up on the front side by grabbing the moving Holder located to the front bottom of the armrest, roll the chair on its casters to the desired location (check the sketch for reference).




### ⚠ CAUTION

- Do not move the chair when there is user inside.
- To carry this product, do not lift by the footrest or armrest, hold the chassis and steady the backrest (have 4 or more people to carry the product).

### Connecting to Power

- Connect this appliance to a 3-wire properly grounded outlet.
- Turn on the main power switch by the right hand side of the massage chair.




### ⚠ CAUTION

- Please verify that there is no damage to the supply cord before switching on the massage chair.
- Please verify that the main power switch is turned off before connecting to power.


## ► PRELIMINARY CHECKS

### Step 2, Install the Controller

► Connect the controller cable to the massage chair's plug connector (line up the pins with the port before connection).



► Connect the power cable to the product power connector port.




## ► NAME AND FUNCTION OF EACH COMPONENT

### Display Screen Instructions

#### Auto Massage Program

► Press to display the Auto Program menu, press this button to toggle among 6 Auto Programs: EXTENSION,REFRESH,RECOVERY,RELAX,NECK & SHOULDER and WAIST & BUTTOCKS. The active program displays at the top of the status screen. (Check below Menu display photo for reference)



#### Extension

Designed for people who experience body stiffness and muscle tension. It helps to relieve the body stiffness and improve your body flexibility.

#### Refresh

Focusing on tight and sore muscles, it helps to relieve waist, back and neck pain.

#### Recovery

Recovery: Designed for after work recovery, it helps to release the fatigue and speed recovery.

#### Relax

This massage program is designed for morning or midday relaxing, it helps to de-stress, clear mind and increase productivity.

#### Neck & Shoulder

Designed to help to ease the pain and stiffness in neck and shoulders, combined with curvature design of the backrest, this program targets the rollers at the deep tissue of neck and shoulders.


#### Waist & Buttocks

To relieve the pain of the lower back, this massage mainly focuses on the lumbar vertebra and the rollers will conduct targeted massage to relieve tension in this area.

## ► NAME AND FUNCTION OF EACH COMPONENT

### Manual Program

- Press MANUAL from MENU display, press UP or DOWN button to navigate among:- MODE, PART, WIDTH, SPEED and ZERO GRAVITY.




### Massage Mode:

Press MODE from MANUAL display, press RIGHT button then press UP or DOWN button to navigate among: Kneading, Knocking, Tapping, Shiatsu and Sync massage techniques. Press OK button to enter the setting you desire. Selected mode will show on the home screen.

**Back Mechanism Massage Part:** Press PART from MANUAL display, press Right button then press Up or Down button to navigate among:

Whole, Partial and Point massage regions. Press OK button to enter the setting you desire.



### Back Mechanism Massage Width:

Press WIDTH from MANUAL display, press RIGHT button then press UP or DOWN button to navigate among: Wide, Medium and Narrow mechanism roller width. Press OK button to enter the setting you desire. Selected width will show on the home screen. (Not adjustable in manual mode-kneading/sync)

### Mechanism Massage Speed:


Press SPEED from MANUAL display, press RIGHT button then press UP or DOWN button to navigate among:

level 1,2,3,4,5,6 Mechanism massage speed. Press OK button to enter the speed level you desire. (Not adjustable in Shiatsu mode)

## ► PRELIMINARY CHECKS

### Floor Protection

- We recommend to place a piece of carpet or soft mat underneath it to avoid damaging the floor.



### Surrounding Environment

Do not use the massage chair in high moisture environment such as near swimming pool or bathroom to prevent electric shock accident.

Please keep the massage chair away from heated surfaces to prevent fire hazard or damage to the product.



### Grounding


This product must be grounded, the plug must be plugged into an appropriate 3-wire grounded outlet that is properly installed and grounded in accordance with all local codes and ordinances to reduce risk of electrical shock.

### Preliminary Checks

#### Installation Method

##### Step 1, Take all massage chair units out of the cartons

Unpack the cartons and take out all sewing and other accessories out of the cartons. Before beginning installation, please verify that all components are included (check with the packing list carefully)




## ► PRELIMINARY CHECKS


### Position & Placement for Installation

#### Clearance space for the massage chair:

- Ensure there is an adequate clearance for the installation: It needs 15 cm clearance for the reclining of the backrest; It needs 20 cm clearance space for the extension of footrest and sliding forward of the chair.
- Keep it 1 meter away from the TV, radio or other audio/video appliance to avoid signal interference.



- Keep the distance between the power socket and power switch within 1.5 meter.





#### CAUTION

- Keep the distance between the power socket and power switch within 1.5 meter to avoid damage of power cord while massage chair sliding forward.
- Straighten the power cord while in use to avoid tangle or damage.
- When the massage chair sliding forwards or back, please check to make sure there are no children, pets or other obstacles around to avoid accident.

## ► NAME AND FUNCTION OF EACH COMPONENT

#### Zero Gravity Position

Press ZERO GRAVITY from MANUAL display, press RIGHT button then press UP or DOWN button to navigate among position 1,2 or OFF (deactivate Zero Gravity). Press OK button to enter the setting you desire.



#### Airbags

- Airbag: Press AIRBAG from MENU display to show the Airbag display, press RIRHT button then press UP or DOWN button to navigate between: Part-Air pressure region and Force-Air pressure intensity, Press OK button to enter the setting you desire.





#### Part-Air Pressure Region

Press PART from AIRBAG display, press RIGHT button then press UP or DOWN button to navigate among: Full, Arm&Shoulder, Leg&Foot positions. Press OK button to enter the airbag position you desire.

**Force-Air Pressure Intensity**  
Press FORCE from AIRBAG display, press RIGHT button then press UP or DOWN button to navigate among: 1,2,3,4,5 air pressure intensity, or Off (deactivate the airbag function). Press OK button to enter the airbag setting you desire.

#### Heat


- Press HEAT from MENU display, press RIGHT then press UP or DOWN button to navigate among: heat level 1,2,3 or OFF (turn off heat). Press OK button to enter the heat setting you desire.



## ► NAME AND FUNCTION OF EACH COMPONENT

### Foot Roller

Press ROLLER from MENU display,press RIGHT button then press UP or DOWN button to navigate among:foot roller speed: level 1,2,3 or OFF (deactivate foot roller) . Press OK button to enter the speed level you desire.



### Settings

► Press SETTINGS from MENU display,then press UP or DOWN button to navigate among:TIME,LANGUAGE, BLUETOOTH and POWER SAVE.

### Time

Press TIME from SETTINGS to show available timer: 10mins,20mins,30mins.press RIGHT button then press UP or DOWN button to navigate,press OK button to enter the timer you desire.

### Language

Press LANGUAGE from SETTINGS to show available language: 中文, EN.press RIGHT button then press UP or DOWN button to navigate,press OK button to enter the language you desire.



### Bluetooth

Press BLUETOOTH from SETTINGS display,press RIGHT then press UP or DOWN button to turn On/Off Bluetooth,. Press OK button to enter the setting you desire.

### Power Save

Press POWER SAVE from SETTINGS display,press RIGHT then press UP or DOWN button to turn On/Off Power Save mode,Press OK button to enter the setting you desire.

(In Power Save/Off mode,Bluetooth function is not available)  
Please deactivate Power Save mode to turn on Bluetooth.



Press arrow keys to select


Press arrow keys to select

Press arrow keys to select


## ► NAME AND FUNCTION OF EACH COMPONENT

### Tips:

In the process of Auto or Manual Setting,LCD screen will auto revert back to the homescreen after 10 seconds if there is no operation entered into the controller.



Homescreen display with the Manual program running



Homescreen display with the Auto program running

### Tips

- While appliance is running,press twice MENU button to revert to homescreen.
- At the homescreen display,press LEFT or RIGHT button to adjust the airbag intensity(works in the process of both Auto and Manual program);press UP or DOWN button to adjust the massage intensity(only works in the process of Manual program)
- Press Auto button to select auto massage programs.

### CAUTION

- Do not disassemble this product yourself to avoid product damage.
- Make sure no water or other liquid enters into the controller to avoid fault.
- Do not pinch or squeeze the controller or power cord.