

W0080 Manual

Receiver features:

- 1. Short press the button, the indicator will flash and enter the standby state. Short press again to enter the first mode of vibration, then short press to enter the next mode and switch in sequence (1-2-3-4-5-6-7-1... ...); Press and hold for two seconds to turn off the power, and the indicator light will go out.**
- 2. Low-voltage reminder for charging function: Plug in the charger (5V/1A DC power supply), the LED will flash for charging; the LED will stay on when fully charged.**
- 3. Key lock: In the power-off state, press and hold the button for 3 seconds, the light will flash twice to lock the key; press and hold the button again for 3 seconds, the light will flash twice to unlock.**

Transmitter: After the receiver is turned on, it can be controlled by the transmitter. Press the power button of the transmitter to turn it on. The receiver motor will start to vibrate. Then press the transmitter mode button to switch to

the vibration mode (1-2-3-4-5-6-7-1 ...).

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction

2A2W8-5981780000