




SAMPLE WIRELESS MICROPHONE

USER MANUAL

<https://www.hanovya.net>

PRODUCT INTRODUCTION

WIRELESS RECEIVER



Attention:
Do not install the batteries in reverse order. The correct installation method is as shown in the figure

PRODUCT INTRODUCTION

WIRELESS RECEIVER



BASIC PARAMETERS

Power supply: 3.7V 18650 lithium battery
Working current: ≤180 mA
Battery Life: 8-10 hours (1800mAh)
Carrier Frequency: CHA: 565MHz-572MHz 15CH
CHB: 572.5MHz-579.5MHz 15CH
Frequency response: 45Hz - 10KHz
Display: LED digital display

USE INSTRUCTIONS

1. Power button: Long press it to power on/off; and short press it to mute
2. Frequency modulation button/Up: Press it once to increase the frequency once
Frequency modulation button/Down: Press it once to decrease the frequency once
3. ID pairing: Press and hold the power button and the frequency modulation button at the same time when the product is powered off, until the microphone display starts to flicker; then turn on the receiver, wait for three seconds, and press the frequency modulation button once to confirm the pairing (this operation is used to avoid interference and simultaneous use of multiple devices)

WIRELESS MICROPHONE

Power supply: 3.7V 18650 lithium battery
Working current: Single receiving ≤ 90 mA; dual receiving ≤ 180 mA
Working hours: 2000mA lithium battery
Single receiving can work continuously for 10-12 hours
Dual receiving can work continuously for 8-10 hours
Carrier Frequency: CHA: 565MHz-572MHz 15CH (CHB: 572.5MHz-579.5MHz 15CH)
Frequency response: 45Hz-10KHz
Display: LED digital display

THANK YOU FOR CHOOSING OUR PRODUCT! PLEASE CAREFULLY READ THE FOLLOWING INSTRUCTIONS:

1. To prevent fire or electric shock, do not expose the product to rain, moisture or sun.
2. Do not disassemble the product by yourself, as there may be high pressure inside that may hurt you.
3. Avoid to use the product in blind spots to ensure good signal receiving conditions.
4. Do not toss, drop, or throw the handheld microphone to avoid causing serious damage.
5. If the battery-operated microphone is not going to be used for a long time, please remove the battery to prevent battery leakage.
6. When the lithium battery is used again after it is not used for a long time, it may run out of power, or fail charging temporarily. At this time, you just need to continue to charge the battery for 10-20 minutes to activate it for normal charging or use.
7. The product is not water-proof, please avoid water from directly entering the body.
8. If the product is dropped or foreign bodies enter the product, stop using the product and contact the dealer immediately.
9. The product does not contain modified parts, please do not disassemble it by yourself; otherwise you will lose your warranty rights, or it may cause failure to the product seriously.

Service

Thank you for your trust and support for this product, and we will serve you wholeheartedly.
Please fill in the relevant information to ensure your legal rights

Product model: _____ Purchasing date: _____
Name of customer: _____ Tel of customer: _____
Country: _____ Address of customer: _____
Name of dealer: _____ Address of dealer: _____
Tel of dealer: _____ Website: _____
Reason for changing or refunding: _____

This service card is a product service certificate, and the content cannot be altered without authorization. Please properly keep it to protect your legal rights and interests.

THANK YOU FOR YOUR CHOICE

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.